


## RF-RS-R Battery Powered RH & Temp Sensors



### Features:

- Up to 5 years battery life
- Encrypted data transmission
- Configurable parameters

### Benefits:

- Self-healing tree topology
- Lower installation costs
- Easy to install and commission

### Technical Overview

These battery powered sensors are used in conjunction with the Sontay RF-RX20 or RF-RX40 receiver units, and RF-RR series of 24V powered routers.

Data is transmitted back to the receiver at configurable time intervals, or on a configurable change in measured value. Each sensor retains these configurations even if the battery becomes discharged or requires replacement.

Sensors automatically find the best path back to the receiver, which may be directly to the receiver or via other 'parent' routers.

## Specification:

## Part Codes:

### Common specification:

Radio Output:	
Frequency	2.4GHz
16 channels, automatically selected	
Direct-sequence spread spectrum	
Compliance	IEEE 802.15.4-2006
Data Encryption	AES 128
Power Output	+10dBm
Accuracy:	
RH	±3% (20 to 80%RH)
Temperature	±0.3°C
Operating:	
Temperature	-10 to +50°C
RH	0 to 90%, non-condensing
Country of origin	UK
<b>Plant Housing:</b>	
Material	ABS (flame retardant type VO)
Dimensions	116 x 106 x 52mm
Battery (non-rechargeable):	
Type	3.6V 2/3 Li-SOCl <sub>2</sub>
Life	>3 years (dependent on conf.)
Protection:	
(622 & 632)	
Snap-shut lid	IP54 IP65 (see page 4 note 8)
(631)	IP54
Probe:	
Material	Probe, PVC - End cap, Delrin
Dimensions;	
(622)	210 x 19mm dia.
(631)	90 x 19mm dia.
(632)	200 x 118mm dia. (Shield)
Aerial Characteristics:	
Gain	2.0dBi
VSWR	<2:1
<b>Space Housing:</b>	
Material	ABS (flame retardant)
Dimensions	85 x 85 x 23mm
Battery (non-rechargeable):	
Type	3.6V AA Li-SOCl <sub>2</sub> ,
Life	>3 years (dependent on conf.)
Protection	IP30
Aerial Characteristics:	
Gain	1.2dBi
VSWR	1.5:1

### RF-RS-R-911

Space RH & temperature sensor/router

### RF-RS-R-622

Duct RH & temperature sensor/router

### RF-RS-R-631

Wall RH & temperature sensor/router

### RF-RS-R-632

Outside RH & temperature sensor/router



The products referred to in this data sheet meet the requirements of EU Directive 2004/108/E


## How It Works:

Data is transmitted back to the receiver at configurable time intervals, or on a configurable change in measured value. Each sensor retains these configurations if the battery becomes discharged or requires replacement.

The sensors, routers and receiver automatically select which of the 16 transmission channels available gives the best radio network performance, taking into account both signal strength and interference levels from adjacent channels and equipment (such as Wi-Fi etc.) The sensors automatically find the best path back to the receiver, which may be directly to the receiver or via "parent" routers.

### Aerial Orientation (plant sensor types);

For best results ensure that the main body of the aerial is vertical.



## Installation:

### Duct, Wall & Outside Sensor types:

1. Remove all packaging from the sensor.
2. Note the MAC address printed on the affixed label and note where this MAC address is installed.
3. Mount the sensor in the required position (this will have been determined by the site survey tool, (see the quick start guide and manual).
4. See page 4 for individual installation depending on sensor type.
5. Release the snap-fit lid by gently squeezing the locking tab and install the Li-SOCl<sub>2</sub> battery, observing the correct polarity.
6. Snap shut the lid after the connections have been made if IP65 protection is required, secure the lid with two screws provided.

Tel: +44 (0)1732 861200. - E-mail: [sales@sontay.com](mailto:sales@sontay.com). - Web: [www.sontay.com](http://www.sontay.com).


© 2012 Sontay Limited. All rights reserved

## Installation (continued):

7. Ensure, at a minimum, that all routers and the receiver on the radio network are powered on, and allow about 5 minutes for the network to auto-commission before attempting to read values or make configuration changes.

### Duct

- Select a location in the duct where the sensor probe will give a representative sample of the prevailing air condition.
- Drill a 22mm diameter hole in the duct, then use the housing as a template mark the hole centres or use the dimensions below), drill and fix the housing to the duct with the screws supplied.



### Wall

- Select a location where the sensor probe will give a representative sample of the prevailing air condition.
- Fix the housing to the wall with appropriate screws.

### Outside

- Fix the radiation shield to a suitable mast using the U bolts supplied.
- Insert the probe into the shield and tighten the gland.

### Radiation Shield

The plate profiles are shaped to allow the minimum restriction of airflow while providing the necessary shielding from solar radiation and precipitation.

All sensor shields produce an error due to temperature rise during high solar radiation; the error is reduced with higher wind speeds which provide ventilation. The figures given below are based on a radiation intensity of 1000W/m<sup>2</sup>; typical errors for the specified wind speeds would be:

0.4°C @ 3 m/s    0.65°C @ 2 m/s    1.4°C @ 1 m/s or slower.

### Space Sensor Types:

1. Remove all packaging from the sensor.
2. Note the MAC address printed on the affixed label and note where this MAC address is installed.
3. Mount the sensor in the required position (this will have been determined by the site survey tool, (see the quick start guide and manual).
4. Undo the tamperproof screw at the bottom of the housing and gently pull the front panel from the base.
5. Note the MAC address printed on the affixed label and note where this MAC address is installed.

Tel: +44 (0)1732 861200. - E-mail: sales@sontay.com. - Web: www.sontay.com.

© 2012 Sontay Limited. All rights reserved

## Installation (continued):

### Space Sensor Types:

6. Replace the housing to the base plate.
7. Re-fit the tamperproof screw through the lug at the bottom of the base plate.
8. Ensure, at a minimum, that all routers and the receiver on the radio network are powered on, and allow about 5 minutes for the network to auto-commission before attempting to read values or make configuration changes.

## Battery Fitting & Replacement:

The current battery level of a sensor can be monitored using the CMS software connected to the receiver. When a battery is first installed, or when it is replaced, observe the correct polarity. **Fitting the battery incorrectly may result in permanent damage to the sensor.** Remove the power jumper prior to removing a battery. After fitting a battery, replace the power jumper while pressing the reset button. This resets the hours run counter for the battery.

**NB** Lithium-Thionyl Chloride batteries are **not rechargeable**, and should be stored in a clean, cool (not exceeding +30°C), dry and ventilated area.

### **Disposal of Batteries - Warning! Fire, Explosion and Burn Hazard.**

Do not recharge, short-circuit, crush, disassemble heat above 100°C (212°F), incinerate, or expose the battery contents to water. Do not solder directly to the cell.

All batteries must be disposed of in accordance with EC Directive 2006/66/EC, amended by EU Directive 2008/12/EC.

Whilst every effort has been made to ensure the accuracy of this specification, Sontay cannot accept responsibility for damage, injury, loss or expense from errors or omissions. In the interest of technical improvement, this specification may be altered without notice.

**Tel:** +44 (0)1732 861200. - **E-mail:** sales@sontay.com. - **Web:** www.sontay.com.

© 2012 Sontay Limited. All rights reserved