



**Franklin Electric**

**EN**

**ENGLISH**

# **CERUS X-DRIVE**

## **Installation and Operation Manual**



---

## COPYRIGHT INFORMATION



Franklin Electric  
Technical Publications  
9255 Coverdale Road  
Fort Wayne, IN 46809

### **Copyright © 2020, Franklin Electric, Co., Inc. All rights reserved.**

The entire contents of this publication are copyrighted under United States law and protected by worldwide copyright laws and treaty provisions. No part of this material may be copied, reproduced, distributed, republished, downloaded, displayed, posted or transmitted in any form by any means, including electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of Franklin Electric. You may download one copy of the publication from [www.franklinwater.com](http://www.franklinwater.com) onto a single computer for your personal, non-commercial internal use only. This is a single copy, single use license, not a transfer of title, and is subject to the following restrictions: you may not modify the materials, use them for any commercial purpose, display them publicly, or remove any copyright or other proprietary notices from them.

The information in this publication is provided for reference only and is subject to change without notice. While every effort has been made to ensure the accuracy of this manual at the time of release, ongoing product improvements and updates can render copies obsolete. Refer to [www.franklinwater.com](http://www.franklinwater.com) for the current version.

This publication is provided “as is” without warranties of any kind, either express or implied. To the fullest extent possible pursuant to applicable law, Franklin Electric disclaims all warranties, express or implied, including but not limited to, implied warranties of merchantability, fitness for a particular purpose, and non-infringement of intellectual property rights or other violation of rights. Franklin Electric does not warrant or make any representations regarding the use, validity, accuracy, or reliability of the material in this publication.

Under no circumstances, including but not limited to, negligence, shall Franklin Electric be liable for any direct, indirect, special, incidental, consequential, or other damages, including, but not limited to, loss of data, property damage, or expense arising from, or in any way connected with, installation, operation, use, or maintenance of the product based on the material in this manual.

### **Trademarks used in this publication:**

The trademarks, service marks, and logos used in this publication are registered and unregistered trademarks of Franklin Electric and others. You are not granted, expressly, by implication, estoppel or otherwise, any license or right to use any trademark, service mark, or logo displayed on this site, without the express written permission of Franklin Electric.

FE Logo and Design<sup>®</sup>, and Cerus<sup>™</sup> are registered trademarks of Franklin Electric.

NEMA is a trademark of The Association of Electrical Equipment and Medical Imaging Manufacturers.

UL<sup>®</sup> is a registered trademark of Underwriters Laboratories.

CSA is a registered mark of the CSA Group, formerly the Canadian Standards Association

Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Modbus is a registered trademark of Schneider Electric USA, Inc.

BACnet is a registered trademark of the American Society of Heating, Refrigerating and Air Conditioning Engineers (ASHRAE).

# TABLE OF CONTENTS

PRODUCT INFORMATION	- 7
Description	- 7
Features	- 7
Models	- 8
UNPACKING AND INSPECTION	- 9
INSTALLATION PLANNING	- 11
PHYSICAL INSTALLATION	- 13
Environmental Requirements	- 13
Mounting the Drive	- 14
Conduit Box Installation	- 16
Drive Dimensions	- 22
ELECTRICAL INSTALLATION	- 29
Wiring Guidelines	- 29
Power Wiring Connections	- 35
Control Circuit Connections	- 37
<i>Terminal Identification</i>	- 37
<i>Example Configurations</i>	- 39
<i>NPN and PNP Digital Inputs Configuration</i>	- 42
DRIVE PROGRAMMING	- 43
Using the Control Interface	- 43
Setting Operating Parameters	- 44
<i>Enter Required Parameters Before Starting VFD</i>	- 44
<i>Verify Default Settings</i>	- 44
<i>Verify Control Terminal Settings</i>	- 45
<i>Enter or Verify Optional Settings</i>	- 45
Default Settings Tables	- 45
Default Settings Table - SET Menu	- 45
Default Settings Table - VFD Menu	- 46
Default Settings Table - I/O Menu	- 48
Default Settings Table - ADV Menu	- 49
Default Settings Table - PROT Menu	- 50
Default Settings Table - COMM Menu	- 51
Default Settings Table - PLC Menu	- 52
Default Settings Table - Option Menu	- 52
Default Settings Table - ADV2 Menu	- 53
Default Settings Table - Motor Menu	- 54
INSTALLATION TESTING	- 55
Rotation Check	- 55
Feedback Checks	- 55
Performance Checks	- 55
Sleep Mode Check (Pump Applications)	- 56
OPERATION	- 57
Manual Control Features	- 57
<i>Hand/Off/Auto (HOA) Controls</i>	- 57
<i>Forward or Reverse Selection</i>	- 58
<i>Jog Feature</i>	- 59
<i>Shutdown</i>	- 59

---

Automated Control Features	60
<i>Standard Operation with an Automated Control System</i>	60
<i>Standard Operation with PID Feedback Control</i>	60
<i>Damper Control (HVAC Applications)</i>	61
<i>Fireman's Override</i>	61
<i>Pump Application Features</i>	62
<i>Timers</i>	64
<i>Performance Control Features</i>	65
Monitoring Functions	66
<i>Home Screen Status Displays</i>	66
<i>View Screens</i>	67
Protection Features	69
<i>High Load Detection</i>	69
<i>Overpressure</i>	69
<i>Underload Protection (Dry Well or Belt Loss)</i>	69
<i>Broken Pipe Protection (for Pump Applications)</i>	70
<i>No Flow Protection</i>	70
ADVANCED APPLICATION OPTIONS	71
Multi-Motor Configurations	71
COMMUNICATIONS	73
Modbus RTU Communication	73
BACnet-RTU Communication	74
MAINTENANCE	75
Troubleshooting	75
<i>Diagnostic Fault Codes</i>	75
Fan Replacement	79
PARAMETER REFERENCE TABLES	87
Parameter Descriptions > SET Menu	87
Parameter Descriptions > VFD Menu	91
Parameter Descriptions > I/O Menu	94
Parameter Descriptions > ADV Menu 1	00
Parameter Descriptions > PROTECTION Menu	102
Parameter Descriptions > COMM Menu	104
Parameter Descriptions > PLC Menu	106
Parameter Descriptions > Option Menu	108
Parameter Descriptions > ADV2 Menu	110
Parameter Descriptions > Motor Menu	112
SPECIFICATIONS	115
Common Specifications	115
200~230V Class 1-125HP (0.75-90kW)	116
380~480V Class 1-75HP (5.5-55kW)	117
380~480V Class 100-675HP (75-500kW)	118
525~600V Class 1-150HP (1.5-175kW)	119
525~690V Class 150-675HP (160-630kW)	120
De-Rating Tables	121
Applicable Standards	122
GLOSSARY	123
STANDARD LIMITED WARRANTY	127

# SAFETY INSTRUCTIONS

## Hazard Messages

This manual includes safety precautions and other important information in the following formats:

### **⚠ DANGER**

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

### **⚠ WARNING**

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

### **⚠ CAUTION**

Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate personal injury.

### **NOTICE**

Indicates a potentially hazardous situation which, if not avoided could result in damage to equipment or other property.

**IMPORTANT:** Identifies information that controls correct assembly and operation of the product.

**NOTE:** Identifies helpful or clarifying information.



This symbol alerts the user to the presence of dangerous voltage inside the product that might cause harm or electrical shock.



This symbol alerts the user to the presence of hot surfaces that might cause fire or personal injury.

## Before Getting Started

This equipment should be installed and serviced by technically qualified personnel who are familiar with the correct selection and use of appropriate tools, equipment, and procedures. Failure to comply with national and local electrical and plumbing codes

and within Franklin Electric recommendations may result in electrical shock or fire hazard, unsatisfactory performance, or equipment failure.

Read and follow instructions carefully to avoid injury and property damage. Do not disassemble or repair unit unless described in this manual.

Failure to follow installation or operation procedures and all applicable codes may result in the following hazards:

### **⚠ WARNING**



**High voltages capable of causing severe injury or death by electrical shock are present in this unit.**

- To reduce risk of electrical shock, disconnect power before working on or around the system. More than one disconnect switch may be required to de-energize the equipment before servicing.
- Serious or fatal electrical shock may result from failure to connect the ground terminal to the motor, drive, metal plumbing, or other metal near the motor or cable, using wire no smaller than motor cable wires.

### **⚠ CAUTION**



**Risk of bodily injury, electric shock, or property damage.**

- This equipment must not be used by children or persons with reduced physical, sensory or mental abilities, or lacking in experience and expertise, unless supervised or instructed. Children may not use the equipment, nor may they play with the unit or in the immediate vicinity.
- Equipment can start automatically. Lockout-Tagout before servicing equipment.
- This equipment produces high temperatures during normal operation. Use caution when contacting surfaces.
- Operation of this equipment requires detailed installation and operation instructions provided in this manual for use with this product. Read entire manual before starting installation and operation. End User should receive and retain manual for future use.
- Keep safety labels clean and in good condition.

## Product Specific Precautions

### **⚠ WARNING**



**High voltages capable of causing severe injury or death by electrical shock are present in this unit.**

- Do not remove VFD cover for wiring or periodic inspections while power is applied, or the unit is in operation.
- Capacitors inside the drive can still hold lethal voltage even after power has been disconnected—ALLOW 10 MINUTES FOR DANGEROUS INTERNAL VOLTAGE TO DISCHARGE BEFORE REMOVING COVER OR WORKING WITH INTERNAL COMPONENTS.
- Perform wiring after VFD has been mounted. Otherwise, electric shock or bodily injury can occur.
- Do not apply power to a damaged VFD or to VFD with missing parts.
- Do not use VFD if power or motor cable is damaged.
- Do not handle the VFD or control devices with wet hands or when standing on a wet or damp surface, or in water.

### **⚠ CAUTION**



**Risk of bodily injury, electric shock, or property damage.**

- Install VFD on a non-flammable surface. Do not place flammable materials nearby.
- Disconnect the input power if VFD has been damaged.
- Do not touch VFD after shutting down or disconnecting it. It can remain hot for a few minutes.
- Do not allow lint, paper, wood chips, dust, metallic chips or other foreign material into the drive.
- Some VFD parameters are set as default to automatically start VFD in some applications. Disable these parameters if automatic start is not safe for personnel or equipment.
- If restart after fault reset is selected, the VFD can start automatically after fault reset.
- If required, provide an emergency mechanical brake to prevent any hazardous conditions if VFD fails during operation.

### **NOTICE**

#### **Risk of damage to drive or other equipment.**

- Install and wire VFD according to the instructions in this manual.
- Take protective measures against ESD (Electrostatic Discharge) before touching control boards during inspection, installation or repair.
- Do not connect power factor correction capacitors, surge suppressors, or RFI filter to the VFD output.
- Check if input power voltage is within acceptable range before applying power to VFD.
- Set correct motor data from the motor nameplate and overload protection parameters for proper motor overload protection.
- Do not modify VFD internal components and circuits.
- Power factor capacitors and generators may become overheated and damaged due to harmonics distortion created by VFD.
- The use of any disconnecting device (contactor, disconnect etc.) in motor circuit during VFD run can cause damage to VFD power components. Stop VFD before opening the motor circuit with disconnect or contactor.
- Use, if possible, an inverter rated or motor with insulation Class F or higher. For submersible pump motors, use Class B or higher. The VFD generates high frequency output pulses with spikes, which can deteriorate motor winding insulation and eventually damage the motor. The longer distance to the motor the higher amplitude of these voltage spikes will be applied to motor winding. Any cables with paralleled wires will increase the amplitude of these spikes at motor terminals.
- VFD can operate motor at frequencies higher than 50HZ or 60Hz. Verify the maximum allowed speed with motor and machinery manufacturers prior to increasing output frequency because it can overheat motor or damage machinery.

## PRODUCT INFORMATION

### Description

The Cerus X-Drive is a variable frequency drive (VFD) designed to control and protect three phase motors in industrial, municipal, and agricultural sites. The X-Drive family offers an extensive range of amperage and configuration options, making it versatile enough for nearly any constant or variable torque application.

Industry standard application settings are pre-configured for submersible or centrifugal pumps, supply or exhaust fans, cooling towers, vacuum pumps, and constant torque motors. In addition, many input/output and control options are available for application specific features, such as PID speed control, pressure control, temperature or fluid level controls, and scheduling.

Native Modbus RTU and BACnet MSTP communication protocols allow integration with many automated control and building management systems. In addition, an optional Bluetooth card provides access for programming, operating, and monitoring the drive using the Cerus X-Drive Mobile App.



### Features

#### Configuration

- Compatible with three-phase induction or permanent magnet motors
- Models available from 200 ~ 690 V and 1 ~ 675 HP
- Easy setup with built-in application defaults
- Many programmable Input/Output terminal options
- Available NEMA 1, NEMA 3R or 4X enclosure offerings

#### Application-specific features

- Sleep mode
- Damper control
- Pipe fill mode
- Broken pipe protection
- Multi-function relay outputs

#### Operation

- Integrated HOA functionality
- Integrated display with keypad control of all functions
- Real-time fault logging with date and time stamps

#### Protection

- Protection against short circuit, incorrect wiring, surges, underload, overload, drive overheat, undervoltage, overvoltage, phase loss, phase imbalance, output open phase, overpressure, sensor fault, etc.
- The X-Drive allows your motor to gradually ramp up and down, saving equipment from sudden, harsh rushes of current that can shorten its lifespan

#### Communication


- RS-485 communications (Modbus, BACnet) for remote control or monitoring
- Bluetooth connectivity with Cerus X-Drive Mobile App
- Control up to seven motors with one VFD

## PRODUCT INFORMATION

### Models

## Models

### Model Number Codes

 <p>CX-005A-2V</p>	<p><b>1. Product Family:</b> Cerus X Drive series</p> <p><b>2. Amperage Ratings:</b> 5 to 930 A</p>	<p><b>3. Input Voltage</b> 2V = 200 ~ 230 V 4V = 380 ~ 480 V 6V = 525 ~ 690 V</p>
---	---	---

	Frame A	Frame B	Frame C
<b>200V</b> \ <b>230V</b>	CX-005A-2V; 1 HP, 5A CX-007A-2V; 2 HP, 7.5A CX-010A-2V; 3 HP, 10A CX-015A-2V; 5 HP, 15A CX-021A-2V; 7.5 HP, 21A	CX-031A-2V; 10 HP, 31A CX-046A-2V; 15 HP, 46A CX-061A-2V; 20 HP, 61A	CX-075A-2V; 25 HP, 75A CX-090A-2V; 30 HP, 90A CX-105A-2V; 40 HP, 105A
<b>380V</b> \ <b>480V</b>	CX-003A-4V; 1 HP, 3A CX-004A-4V; 2 HP, 4.2A CX-005A-4V; 3 HP, 5.5A CX-008A-4V; 5 HP, 8.5A CX-010A-4V; 5 HP, 10.5A CX-013A-4V; 7.5 HP, 13A CX-018A-4V; 10 HP, 18A	CX-024A-4V; 15 HP, 24A CX-032A-4V; 20 HP, 32A CX-038A-4V; 25 HP, 38A	CX-045A-4V; 30 HP, 45A CX-060A-4V; 40 HP, 60A CX-073A-4V; 50 HP, 73A
<b>525V</b> \ <b>600V</b>	CX-003A-6V; 2 HP, 3A CX-004A-6V; 3 HP, 4.3A CX-006A-6V; 5 HP, 6.7A	CX-009A-6V; 7.5 HP, 9.9A CX-012A-6V; 10 HP, 12A CX-018A-6V; 15 HP, 18.7A CX-024A-6V; 20 HP, 24.2A	CX-030A-6V; 25 HP, 30A CX-036A-6V; 30 HP, 36A CX-045A-6V; 40 HP, 45A
	Frame D	Frame E	Frame F
<b>200V</b> \ <b>230V</b>	CX-146A-2V; 50 HP, 146A CX-180A-2V; 60 HP, 180A	CX-215A-2V; 75 HP, 215A CX-276A-2V; 90 HP, 276A, 230V CX-322A-2V; 125 HP, 322A	
<b>380V</b> \ <b>480V</b>	CX-091A-4V; 60 HP, 91A <b>(D0)</b> CX-110A-4V; 75 HP, 110A <b>(D0)</b> CX-150A-4V; 100 HP, 150A CX-180A-4V; 125 HP	CX-220A-4V; 150 HP, 220A CX-260A-4V; 175 HP, 260A	CX-310A-4V; 215 HP, 310A CX-370A-4V; 250 HP, 370A
<b>525V</b> \ <b>600V</b>	CX-054A-6V; 50 HP, 54A CX-067A-6V; 60 HP, 67A	CX-086A-6V; 75 HP, 86A CX-104A-6V; 100 HP, 104A CX-125A-6V; 125 HP, 125A CX-150A-6V; 150 HP, 150A	
<b>690V</b>			CX-180A-6V; 150 HP, 180A CX-220A-6V; 200 HP, 220A
	Frame G	Frame H	Frame H (690)
<b>380V</b> \ <b>480V</b>	CX-460A-4V; 300 HP, 460A CX-530A-4V; 375 HP, 530A	CX-616A-4V; 425 HP, 616A CX-683A-4V; 475 HP, 683A CX-770A-4V; 536 HP, 770A CX-930A-4V; 675 HP, 930A	
<b>690V</b>	CX-290A-6V; 250 HP, 290A CX-350A-6V; 350 HP, 350A		CX-430A-6V; 400 HP, 430A CX-465A-6V; 450 HP, 465A CX-590A-6V; 500 HP, 590A CX-675A-6V; 675 HP, 675A



# UNPACKING AND INSPECTION

## Transportation and Storage

### NOTICE

#### Risk of damage to VFD or other equipment.

- Do not stack VFD boxes higher than standard 48" cube height when palleting for storage.
- Do not place heavy items on VFD.
- Do not drop VFD or subject it to hard impact.
- Dispose of VFD properly as industrial equipment waste.

The VFD should be stored in the shipping carton or crate before installation, in a controlled environment that meets the following requirements:

Storage Temperature	-25 to 70 °C (-13 to 158 °F)
Location	Pollution Degree 2 Environment.
Relative Humidity	95% Maximum relative humidity (non-condensing)

The performance of capacitors in the drive will degrade if not charged occasionally. It is recommended to charge a stored drive every 2 years to restore the performance of the capacitors.

**NOTE:** When powering the drive, use an adjustable AC power source (ex. AC autotransformer) to charge the drive at 70 to 80% of the rated voltage for 30 minutes (do not run the drive). Then, charge the drive at 100% of rated voltage for an hour (do not run the drive).


## Unpacking

### CAUTION

#### Risk of personal injury or damage to VFD or other equipment.

- Use suitable lifting equipment, in good condition, rated for at least 5 times the weight of the VFD. Refer to "[Specifications](#)" on [page 115](#) for the weight of each drive by frame size.


1. Inspect exterior of package for shipping damage. If there is damage, notify the shipping agent and your sales representative.
2. Make sure the part number and product ratings on the identification label are correct for the application.
3. When possible, remove the VFD cover and make sure the product ratings on the nameplate match the package label.
4. The VFD comes in various forms of shipping crates. If applicable, remove the top and side fasteners from the packaging.



## UNPACKING AND INSPECTION

### Unpacking


5. Some crates are secured with clips. Remove clips with a suitable prying tool.
6. Remove the crate cover, foam packing inserts, owner's manual, and any other items inside the crate.
7. Remove fasteners securing the drive to the pallet.
8. Inspect the VFD for damage.
9. Allow the drive to remain on the pallet until you are ready to install it in the permanent location. Refer to "[Mounting the Drive](#)" on [page 14](#).



### Lifting

When removing large VFDs from the pallet, use suitable lifting equipment connected to the lifting holes at the top outer edges of the unit.

Use a spreader bar the same width as the drive so the lifting cables are straight up and down.



# INSTALLATION PLANNING

**NOTICE**

**Risk of damage to VFD, or malfunction can occur.**

- An incorrectly applied or installed VFD can result in system malfunction or reduction in product life as well as component damage. You must read and understand this manual thoroughly before proceeding with installation.









Refer to the following table when planning installation of the Cerus X-Drive VFD.

1	2	3	4	5	6
Plan System Goals	Identify Options	Select Control Methods	Install VFD Hardware	Install Wiring	Program Parameters
Intended Function <ul style="list-style-type: none"> <li>• Air Handling</li> <li>• Fluid Circulation</li> <li>• Constant Pressure</li> <li>• Pressure Boosting</li> <li>• Irrigation</li> <li>• Dewatering</li> <li>• Carwashes</li> <li>• Conveyors</li> <li>• Crushers</li> <li>• Grinders</li> </ul> Hardware Application <ul style="list-style-type: none"> <li>• Supply Fan</li> <li>• Exhaust Fan</li> <li>• Cooling Tower</li> <li>• Centrifugal Pump</li> <li>• Submersible Pump</li> <li>• Vacuum Pump</li> <li>• Constant Torque</li> </ul>	Automation <ul style="list-style-type: none"> <li>• Damper Control</li> <li>• Sleep mode</li> <li>• Timers</li> <li>• Scheduling</li> </ul> Protection <ul style="list-style-type: none"> <li>• Shutdown</li> <li>• Redundancy</li> <li>• Broken Pipe</li> <li>• Fire Override</li> </ul> Maintenance <ul style="list-style-type: none"> <li>• Screen clean</li> <li>• Lubrication</li> </ul> Multi-Motor Control <ul style="list-style-type: none"> <li>• Equal Run Time</li> <li>• Soft Start</li> <li>• Lead/Lag</li> <li>• Rotation</li> </ul>	Hand/Off/Auto <ul style="list-style-type: none"> <li>• Keypad</li> <li>• Panel Mounted</li> <li>• Remote</li> </ul> Transducer (PID) <ul style="list-style-type: none"> <li>• Temperature</li> <li>• Pressure</li> <li>• Vacuum</li> <li>• Flow</li> </ul> Switches <ul style="list-style-type: none"> <li>• Potentiometer</li> <li>• Float</li> <li>• On/Off</li> <li>• Speed control</li> </ul> Communications <ul style="list-style-type: none"> <li>• BMS/PLC</li> <li>• Modbus</li> <li>• BACnet</li> <li>• Drive-to-drive</li> <li>• Bluetooth</li> </ul>	Location <ul style="list-style-type: none"> <li>• Inside</li> <li>• Outside</li> </ul> Climate control <ul style="list-style-type: none"> <li>• Temperature</li> <li>• Moisture</li> </ul> Distance <ul style="list-style-type: none"> <li>• Wire sizes</li> <li>• Filtering requirements</li> </ul> Measurements <ul style="list-style-type: none"> <li>• Clearance</li> <li>• Drilling</li> </ul>	Conduit <ul style="list-style-type: none"> <li>• Routing</li> <li>• Separation</li> </ul> High Voltage <ul style="list-style-type: none"> <li>• Grounding</li> <li>• Inputs</li> <li>• Outputs</li> </ul> Control circuits <ul style="list-style-type: none"> <li>• Analog inputs</li> <li>• Switched inputs</li> <li>• Voltage inputs</li> <li>• Programmable outputs</li> <li>• Communication</li> </ul>	Basic <ul style="list-style-type: none"> <li>• Application</li> <li>• Motor ratings</li> <li>• Setpoints</li> <li>• Limits</li> </ul> I/O setup <ul style="list-style-type: none"> <li>• Input functions</li> <li>• Output functions</li> <li>• Scaling</li> </ul> Option settings <ul style="list-style-type: none"> <li>• Enable features</li> <li>• Set targets</li> </ul>

1. The planned usage of the overall system will determine which options and control methods are appropriate, as well as how the VFD should be installed and programmed. Refer to [“Operation” on page 57](#) for examples of how the system might be used.
2. System options define and automate features that support the intended operation. These features may require specialized control methods and programming. For more details, refer to [“Manual Control Features” on page 57](#), [“Automated Control Features” on page 60](#), and [“Protection Features” on page 69](#).
3. The X-Drive supports many different methods for automating motor speed control. Refer to [“Example Configurations” on page 39](#) for possible control setups.
4. The overall function of the system directly affects where and how the VFD should be mounted. Refer to [“Physical Installation” on page 13](#) for guidelines.
5. The selected motor application, along with the control method(s), determines how the VFD should be connected. Refer to [“Electrical Installation” on page 29](#) for more information.
6. The VFD can be quickly and easily programmed for most standard operations. Refer to [“Setting Operating Parameters” on page 44](#). Advanced features or options may require additional parameter adjustments to achieve the desired performance. Refer to [“Advanced Application Options” on page 71](#) and [“Parameter Reference Tables” on page 87](#).

## Basic VFD Configuration

The following table includes the most commonly used devices in a motor control branch operated by a VFD. Adequate peripheral devices and correct connections are essential for proper VFD operation.

	AC Power Source	Use three-phase power source with voltage within the permissible range of VFD input power rating.
	MCCB	Select circuit breakers or fuses in accordance with NEC and applicable local codes.
	Inline Magnetic Contactor	Do not use input power contactor for frequent starting and stopping the VFD, otherwise VFD power components can be damaged.
	AC Line Reactor or Harmonic Filter	A line reactor provides some degree of surge protection and decreases a level of harmonic distortion in the power line. It is recommended when power source kVA rating is more than 10 times higher than VFD rating. A Harmonic filter provides a higher level of harmonic mitigation. Reactors are included in VFDs rated above 50 HP.
	EMI/RFI Filter	Install an EMI/RFI filter to decrease VFD Electromagnetic and Radio Frequency Interference with operation of sensitive electronic equipment.
	Variable Frequency Drive	Install VFD with proper orientation, ventilation, spacing etc. according to the requirements described in this manual with all necessary protective and filtering devices to provide long and reliable VFD operation.
	AC Load Reactor or Output Filter	Install a load (output) reactor or an output filter to protect motor windings if distance from VFD to a motor is in the range 45-100 feet. Install output dV/dt filter for a range of 100-1000 feet (800 feet for submersible pumps), or a sine wave filter for greater distances.
	Three Phase AC Induction Motors or Permanent Magnet Motors, including Franklin Electric pump motors	The X-Series VFD is not compatible with servomotors. Opening the motor circuit by disconnect or contactor during VFD run can damage VFD power components.

### NOTICE

#### Risk of damage to VFD, or malfunction can occur.

- Do not install a magnetic contactor in the motor circuit for start/stop or emergency stop purpose. Opening the motor circuit while the VFD is running above 50% of its rated current capacity may cause VFD power components failure.

# PHYSICAL INSTALLATION

## Environmental Requirements

### NOTICE

**Risk of damage to VFD, or malfunction can occur due to improper handling, installation, or environment.**

- Do not mount VFD on equipment with excessive vibration.
- Install in a location where temperature is within the range of product rating.
- Do not mount VFD in direct sunlight or near other heat sources.
- The VFD should be mounted in a Pollution Degree 2 environment. If VFD will be installed in an environment with a high probability of dust, metallic particles, mists, corrosive gas or other contaminants, the VFD must be mounted inside the appropriate electrical enclosure with proper NEMA, UL or IP rating and adequate cooling.
- When two or more VFDs are installed in a ventilated enclosure, the cooling system should provide adequate airflow for all the VFDs. Do not install VFD above another heat source (another VFD, inductive reactors, etc.).

The VFD must be installed and used in a controlled environment that meets the following requirements:


Ambient Temperature	50 °C (122 °F) UL Open Type/IP20 (Top cover must be removed.) 40 °C (113 °F) in NEMA 3R/IP14 enclosure 40 °C (104 °F) in NEMA 1/IP10 enclosure.
Location	Pollution Degree 2 Environment.
Altitude	1000m (3281 ft) above sea level. De-rate 1% per 100 m (328 ft) from 1000 to 2000 m (3281-6562ft). De-rate 2% per 100 m (328 ft) for installations from 2000-3000 m (6560–9840 ft). Consult factory for installations above 3000 m.
Relative Humidity	95% Maximum relative humidity (non-condensing)
Vibration	1.0mm, peak to peak value range from 2 Hz to 13.2 Hz 0.7G-1.0G range from 13.2 Hz to 55 Hz 1.0G range from 55 Hz to 512 Hz.

The drive electronics are air-cooled. Provide enough clearance for airflow around the VFD. See minimum mounting clearance table below for different VFD frame sizes.

Mount VFD vertically (top up) for proper heat dissipation.

Do not mount VFD in direct sunlight or near other heat sources.

Do not block cooling vents or airflow with any panel components or wires. Prevent debris from adhering to the heat sink.



Frame Size	A	B	C	D
A, B, & C	60 mm/2.4 in.	30 mm/1.2 in.	10 mm/0.4 in.	12 mm/0.5 in.
D, E, & F	100 mm/3.9 in.	50 mm/2.0 in.	10 mm/0.4 in.	25 mm/1.0 in.
G	200 mm/7.9 in.	100 mm/3.9 in.	10 mm/0.4 in.	25 mm/1.0 in.
H	350 mm/13.8 in.	150 mm/6.0 in.	10 mm/0.4 in.	50 mm/2.0 in.

## Mounting the Drive

**⚠ CAUTION**

**Risk of bodily injury or damage to drive or other equipment.**

- The drive should be mounted on a structure such as a wall or post capable of supporting the weight of the unit. Refer to [“Specifications” on page 115](#) for drive weight.
- Install VFD on a non-combustible surface.
- Ensure suitable mounting hardware is used when installing the drive.
- Do not install the drive on unreinforced drywall.
- Use suitable lifting equipment, in good condition, rated for at least 5 times the weight of the drive.

The mounting location should have nearby access to the electrical supply and access to the motor wiring. Refer to [“Electrical Installation” on page 29](#).


Use lag screws or bolts appropriate for supporting the weight of the drive.

1. Mount the drive using the mounting holes on the back side of the drive enclosure.
2. Screws at the top must attach to a solid structure such as a stud or brace.
3. All screw hole locations should be used to ensure the drive is securely mounted.

**IMPORTANT:** Do not drill holes in the drive.

When removing large drives from the pallet, use suitable lifting equipment connected to the lifting holes at the top outer edges of the drive.


1. Use a spreader bar the same width as the drive so the lifting cables are straight up and down.
2. Slowly lift the drive from the pallet.
3. Use lifting equipment to place the drive in the desired installation location.



## Mounting Frames A, B, and C

These frames have four corner mounting holes on the drive. Refer to [“Drive Dimensions” on page 22](#) for mounting hole locations and sizes.


1. Have one person hold the drive in location while another installs the lag screws in each corner, ensuring they go into a solid stud or brace. Install the lower left lag screw first.
2. Place a level on top of the drive. When level, install the upper right corner lag screw.
3. Install the remaining two lag screws.



## Mounting Frames D0, D, and E

These frames have four corner mounting holes on the drive. The bottom two holes are U-shaped slots, allowing the drive to be lowered onto pre-installed lag screws. Refer to [“Drive Dimensions” on page 22](#) for mounting hole locations and sizes.


1. Install two lag screws for the bottom locations, ensuring they are level and enter a solid stud or brace.
2. Use a lifting device to lower the U-shaped mounting slots onto the bottom lag screws. The conduit box is not shown in this image to better show the bottom mounting slots.
3. Hold the drive tight against the backing board, and install the remaining two lag screws in the top mounting holes.



## Mounting Frames F, G, and H

These frames include two keyhole shaped mounting holes at the top, allowing the drive to be set onto pre-installed lag screws. Refer to [“Drive Dimensions” on page 22](#) for mounting hole locations and sizes.

1. Install two lag screws for the top locations, ensuring they are level and enter a solid stud or brace.
2. Use a properly sized lifting device to lower the top keyhole shaped mounting slots onto the lag screws.
3. Hold the drive tight against the backing board, and install the remaining lag screws in the bottom mounting holes, ensuring they enter a solid stud or brace.




## Conduit Box Installation


Frames A, B and C do not require an added conduit box.

### Frames D0 and D Conduit Box Installation


1. Loosen two lower drive cover screws.
2. Press the tabs on each side of the cover.
3. Remove the cover.



4. Remove five screws.




5. Install the conduit box with five screws. Tighten to a torque of 24-26 kg-cm / 20.8-22.6 lb-in. / 2.4-2.5 Nm.
6. Replace the lower drive cover and rotate to the closed position. Secure with two screws from step 1. Tighten to a torque of 12-15 kg-cm / 10.4-13 lb-in. / 1.2-1.5 Nm.






## Frame E Conduit Box Installation

1. Loosen four lower drive cover screws.
2. Remove the cover.



3. Install the conduit box with six screws. Tighten to a torque of 24-26 kg-cm / 20.8-22.6 lb-in. / 2.4-2.5 Nm.
4. Replace the cover and secure with screws from step 1. Tighten to a torque of 12-15 kg-cm / 10.4-13 lb-in. / 1.2-1.5 Nm.




## PHYSICAL INSTALLATION


### Conduit Box Installation

#### Frame F Conduit Box Installation


1. Remove four lower drive cover screws.
2. Remove the cover from the drive.  
Remove four screws from the conduit box cover.



3. Align the conduit box flanges behind the flanges of the drive bottom.
4. Secure the conduit box to the drive (flange to flange) with four screws.  
Tighten the screws to a torque of  
24-26 kg-cm / 20.8-22.6 lb-in. / 2.4-2.5 Nm.




5. Install the conduit box cover using four screws from step 2.  
Tighten to a torque of  
13-16 kg-cm / 20.8-22.6 lb-in. / 2.4-2.5 Nm.
6. Replace the cover and secure with four screws from step 1.  
Tighten to a torque of  
12-15 kg-cm / 10.4-13 lb-in. / 1.2-1.5 Nm.




**Frame G Conduit Box Installation**


- 1. Loosen seven conduit box cover screws, slide it forward, and remove the cover.
- 2. Loosen four lower drive cover screws. Remove the cover.



- 3. Remove the eight screws identified.
- 4. Align the conduit box with the flanges of the drive. Reinstall the eight screws from step 3.  
M5 Screw torque: 24-26 kg-cm / 20.8-22.6 lb-in. / 2.4-2.5 Nm  
M8 Screw torque: 100-120 kg-cm / 86.7-104.1 lb-in. / 9.8-11.8 Nm
- 5. Secure further with eight screws.  
M5 Screw torque: 24-26 kg-cm / 20.8-22.6 lb-in. / 2.4-2.5 Nm  
M8 Screw torque: 100-120 kg-cm / 86.7-104.1 lb-in. / 9.8-11.8 Nm




- 6. Set the conduit box cover on the conduit box and slide it toward the conduit knockouts. Tighten the screws to a torque of 24-26 kg-cm / 20.8-22.6 lb-in. / 2.4-2.5 Nm.
- 7. Place the cover back on the drive, and tighten the screws to a torque of 12-15 kg-cm / 10.4-13 lb-in. / 1.2-1.5 Nm.




**PHYSICAL INSTALLATION**  
**Conduit Box Installation**

**Frame H Conduit Box Installation**


1. Remove all screws holding the covers of the conduit box kit and remove the covers.




2. Remove the screws shown from the bottom of the drive and remove the bracket.




3. Fasten the M6 screws to two locations. Tighten screws to a torque of 35-45 kg-cm / 30.3-39 lb-in. / 3.4-4.4 Nm.



4. Install the conduit box to the drive using the following screws and nuts tightened to a torque of:  
M6 Screws 1 - 6: 55-65 kg-cm / 47.7-56.4 lb-in / 5.4-6.4 Nm  
M8 Screws 7 - 9 and Nuts 14 - 17: 100-110 kg-cm / 86.7-95.4 lb-in / 9.8-10.8 Nm  
M10 Nuts 10 - 13: 250-300 kg-cm / 216.9-260.3 lb-in / 24.5-29.4 Nm




5. Replace the covers and screws removed in Step 1 to the original locations. Tighten to a torque of 35-45 kg-cm / 30.3-39 lb-in. / 3.4-4.4 Nm.




## Drive Dimensions


### Frame A




### Frame B



**Frame C**




**Frame D0**




**PHYSICAL INSTALLATION**  
**Drive Dimensions**

**Frame D**




**Frame E**






Frame F




**PHYSICAL INSTALLATION**  
**Drive Dimensions**

**Frame G**






**Frame H**



**PHYSICAL INSTALLATION**  
**Drive Dimensions**


**Frame H (690 V)**



- 1 - 700 mm (27.6 in)
- 2 - 630 mm (24.8 in)
- 3 - 800 mm (31.5 in)
- 4 - 1745 mm (68.7 in)
- 5 - 1715 mm (67.5 in)
- 6 - 42.5 mm (1.7 in)
- 7 - 109 mm (4.3 in)
- 8 - 404 mm (15.9 in)
- 9 - 51 mm (2 in)
- 10 - 13 mm (0.51 in)/  
- 26.5 mm (1.04 in)
- 11 - 25 mm (0.98 in)
- 12 - 500 mm (19.7 in)
- 13 - 630 mm (24.8 in)
- 14 - 760 mm (30 in)
- 15 - 68 mm (2.7 in)
- 16 - 137 mm (5.4 in)
- 17 - 103 mm (4.1 in)
- 18 - 204 mm (8 in)
- 19 - 117.5 mm (4.6 in)
- 20 - 34 mm (1.3 in)
- 21 - 22 mm (0.87 in)

# ELECTRICAL INSTALLATION

## Wiring Guidelines



### NOTICE

#### Risk of damage to VFD, or malfunction can occur.

Follow all wire routing and grounding instructions carefully. Inductive currents caused by parallel wiring, or close proximity between high voltage and control wiring can cause unexpected behaviors.

- Do not run input power and motor wires in the same conduit.
- Do not run motor wires from multiple VFDs in common conduit.
- Do not run control wiring parallel with high voltage wiring.
- Do not run VFD wiring parallel with building or facility wiring.
- Do not use aluminum wires for VFD connections.
- Do not install power factor correction capacitors, surge suppressors, or RFI filters on the VFD output.
- Do not install a magnetic contactor or disconnect in the motor circuit.
- Do not leave wire fragments, metal shavings or other metal objects inside the VFD.
- Improper splicing or damage to motor cable insulation may expose the conductor(s) to moisture and can produce motor cable failure.
- For retrofit application, check the integrity of power and motor leads. This requires measuring the insulation resistance with a suitable megohm-meter.

1. Mount the drive as close as possible to the service entrance panel. Connect directly to the service entrance, not to a sub-panel.
2. Use a dedicated branch circuit for the drive. Verify that the circuit is equipped with a properly-sized circuit breaker or fuse.
3. Separate input power and motor wiring by at least 8 in. (20.3 cm).
4. Cross over other branch circuits and facility wiring at a 90° angle. If necessary to run wires in parallel, separate by at least 8 in. (20.3 cm).
5. All control wiring—sensors, switches, transducers, etc.—should be in a separate conduit routed individually, not parallel, from high voltage wiring. In addition, any shielded cables should be properly grounded.
6. Treat Open-Delta power configuration (two-transformer utility bank) as single-phase power and size VFD and power wiring accordingly.
7. Install a line reactor for VFDs in pump systems with dedicated service transformer to protect VFD from transient power surges and provide some degree of harmonics distortion mitigation.

## Branch Circuit Protection

Integral solid-state short circuit protection does not provide branch circuit protection. Branch Circuit Protection must be provided in accordance with the National Electrical Code (NEC) and applicable local codes; or equivalent as determined by Authorities Having Jurisdiction (AHJ). The Drive shall be protected by Listed Class J fuses or Listed inverse-time circuit breakers only.

Short-circuit current rating (SCCR): The drive is suitable for use on a circuit capable of delivering not more than 100,000 symmetrical amperes (rms) when protected by suitable Class J fuses. Rated fuse current shall be maximum 3 times the motor output full-load current (FLA) rating. Rated circuit breaker current shall be maximum 2.5 times the motor output FLA rating when using single phase or polyphase AC motors. For all other motors, refer to NEC Sec 430 and the Franklin Electric Aim Manual. When protected by a circuit breaker and placed in a panel, drive SCCR is as follows:

VFD Output Rating	Test Current
Up to 50 HP (0 to 37.3 kW)	5,000 Amperes (rms)
51 to 200 HP (39 to 149 kW)	10,000 Amperes (rms)
201 to 400 HP (150 to 298 kW)	18,000 Amperes (rms)
401 to 600 HP (299 to 447 kW)	30,000 Amperes (rms)
601 to 900 HP (448 to 671 kW)	42,000 Amperes (rms)

## Fuse and Circuit Breaker Sizing

See the table below for maximum current ratings of fuses and circuit breakers per NEC.

	Model	Input Current		Fuse Size		Breaker Size
		Constant Torque	Variable Torque	Vendor P/N		
<b>200V \ 230V</b>	CX-005A-2V	3.9 A	6.4 A	15 A	JJN-15	15 A
	CX-007A-2V	6.4 A	9.6 A	20 A	JJN-20	20 A
	CX-010A-2V	12 A	15 A	30 A	JJN-30	30 A
	CX-015A-2V	16 A	22 A	40 A	JJN-40	40 A
	CX-021A-2V	20 A	25 A	50 A	JJN-50	50 A
	CX-031A-2V	28 A	35 A	60 A	JJN-60	60 A
	CX-046A-2V	36 A	50 A	100 A	JJN-100	100 A
	CX-061A-2V	52 A	65 A	125 A	JJN-125	125 A
	CX-075A-2V	72 A	83 A	150 A	JJN-150	150 A
	CX-090A-2V	83 A	100 A	200 A	JJN-200	200 A
	CX-105A-2V	99 A	116 A	225 A	JJN-225	225 A
	CX-146A-2V	124 A	146 A	250 A	JJN-250	250 A
	CX-180A-2V	143 A	180 A	300 A	JJN-300	300 A
	CX-215A-2V	171 A	215 A	400 A	JJN-400	400 A
	CX-276A-2V	206 A	276 A	450 A	JJN-450	450 A
CX-322A-2V	245 A	322 A	600 A	JJN-600	600 A	

	Model	Input Current		Fuse Size		Breaker Size
		Constant Torque	Variable Torque	Vendor P/N		
<b>380V</b> \ <b>480V</b>	CX-003A-4V	3.5 A	4.3 A	10 A	JJS-10	10 A
	CX-004A-4V	4.3 A	6.0 A	10 A	JJS-10	10 A
	CX-005A-4V	5.9 A	8.1 A	15 A	JJS-15	15 A
	CX-008A-4V	8.7 A	12.4 A	25 A	JJS-20	25 A
	CX-010A-4V	14 A	16 A	30 A	JJS-20	30 A
	CX-013A-4V	15.5 A	20 A	40 A	JJS-30	40 A
	CX-018A-4V	17 A	22 A	40 A	JJS-40	40A
	CX-024A-4V	20 A	26 A	50 A	JJS-50	50 A
	CX-032A-4V	25 A	35 A	60 A	JJS-60	60 A
	CX-038A-4V	35 A	42 A	75 A	JJS-75	75 A
	CX-045A-4V	40 A	50 A	100 A	JJS-100	100 A
	CX-060A-4V	47 A	66 A	125 A	JJS-125	125 A
	CX-073A-4V	63 A	80 A	150 A	JJS-150	150 A
	CX-091A-4V	74 A	91 A	175 A	JJS-175	175 A
	CX-110A-4V	101 A	110 A	250 A	JJS-250	250 A
	CX-150A-4V	114 A	150 A	300 A	JJS-300	300 A
	CX-180A-4V	157 A	180 A	300 A	JJS-300	300 A
	CX-220A-4V	167 A	220 A	400 A	JJS-400	400 A
	CX-260A-4V	207 A	260 A	500 A	JJS-500	500 A
CX-310A-4V	240 A	310 A	600 A	JJS-600	600 A	
<b>380V</b> \ <b>480V</b> Cont.	CX-370A-4V	300 A	370 A	600 A	JJS-600	600 A
	CX-460A-4V	380 A	460 A	800 A	JJS-800	800 A
	CX-530A-4V	400 A	530 A	1000 A	KTU-1000	1000 A
	CX-616A-4V	494 A	616 A	1200 A	KTU-1200	1200 A
	CX-683A-4V	555 A	683 A	1350 A	KTU-1350	1350 A
	CX-770A-4V	625 A	770 A	1500 A	KTU-1500	1500 A
	CX-930A-4V	866 A	930 A	1600 A	170M6019	2000 A
<b>525V</b> \ <b>600V</b>	CX-003A-6V	3.1 A	3.8 A	7 A	KLKD007.T	7 A
	CX-004A-6V	4.5 A	5.4 A	10 A	KLKD010.T	10 A
	CX-006A-6V	7.2 A	10.2 A	15 A	KLKD015.T	15 A
	CX-009A-6V	12.3 A	14.9 A	25 A	25ET	25 A
	CX-012A-6V	15 A	16.9 A	32 A	32ET	32 A
	CX-018A-6V	18 A	21.3 A	50 A	50FE	50 A
	CX-024A-6V	22.8 A	26.3 A	63 A	63FE	63 A
	CX-030A-6V	29 A	36 A	70 A	JJS-70	70 A
	CX-036A-6V	36 A	43 A	80 A	JJS-80	80 A
	CX-045A-6V	43 A	54 A	100 A	JJS-100	100 A
	CX-054A-6V	54 A	65 A	100 A	JJS-100	100 A
	CX-067A-6V	65 A	81 A	125 A	JJS-125	125 A
	CX-086A-6V	66 A	84 A	175 A	JJS-175	175 A
	CX-104A-6V	84 A	102 A	200 A	JJS-200	200 A
	CX-125A-6V	102 A	122 A	250 A	JJS-250	250 A
CX-150A-6V	122 A	147 A	300 A	JJS-300	300 A	

## ELECTRICAL INSTALLATION

### Wiring Guidelines

	Model	Input Current		Fuse Size		Breaker Size
		Constant Torque	Variable Torque	Vendor P/N		
<b>690V</b>	CX-180A-6V	148 A	178 A	350 A	JJS-350	350 A
	CX-220A-6V	178 A	217 A	400 A	JJS-400	400 A
	CX-290A-6V	222 A	292 A	450 A	170M4063	450 A
	CX-350A-6V	292 A	353 A	500 A	170M6058	500 A
	CX-430A-6V	353 A	454 A	700 A	170M6061	700 A
	CX-465A-6V	388 A	469 A	800 A	170M6062	800 A
	CX-590A-6V	504 A	595 A	1250 A	170M6066	1250 A
	CX-675A-6V	681 A	681 A	1400 A	170M6067	1400 A

## Wire Sizing

Size power wire to maintain a voltage drop less than 2% at VFD or motor terminals.

**Frame A:** Use only copper conductors rated for at least 75 °C and 600 V. Use cable with a 90 °C rating if ambient environment is greater than 50 °C.

**Frame B and above:** Use only copper conductors rated for at least 75 °C and 600 V. Use cable with a 90 °C rating if ambient environment is greater than 40 °C (30 °C for models CX-061A-2V, CX-105A-2V, CX-370A-4V, or CX-930A-4V).

Install a load (output) reactor to protect motor windings if distance from VFD to a motor is in the range 45-100 feet. Install output dV/dt filter for a range 100-1000 feet (800 feet for submersible pumps) or a sine wave filter for greater distances.

## Motor Cable Lengths for Submersible Pumping Applications

Refer to the Franklin Electric AIM Manual for wire gauge and distance information.

## Suggested Maximum Motor Cable Lengths for Non-Submersible Applications

	Model	Rated Current (Arms)		Without output reactor		(3%) With output reactor	
		Constant Torque	Variable Torque	Shielded Cable	Unshielded Cable	Shielded Cable	Unshielded Cable
<b>200V 230V</b>	CX-005A-2V	3	5	50 m	75 m	75 m	115 m
	CX-007A-2V	5	7.5	50 m	75 m	75 m	115 m
	CX-010A-2V	8	10	50 m	75 m	75 m	115 m
	CX-015A-2V	11	15	50 m	75 m	75 m	115 m
	CX-021A-2V	17	21	100 m	150 m	150 m	225 m
	CX-031A-2V	25	31	100 m	150 m	150 m	225 m
	CX-046A-2V	33	46	100 m	150 m	150 m	225 m
	CX-061A-2V	49	61	100 m	150 m	150 m	225 m
	CX-075A-2V	65	75	100 m	150 m	150 m	225 m
	CX-090A-2V	75	90	100 m	150 m	150 m	225 m
	CX-105A-2V	90	120	100 m	150 m	150 m	225 m
	CX-146A-2V	120	146	100 m	150 m	150 m	225 m
	CX-180A-2V	146	180	150 m	225 m	225 m	325 m
	CX-215A-2V	180	215	150 m	225 m	225 m	325 m
	CX-276A-2V	215	276	150 m	225 m	225 m	325 m
	CX-322A-2V	255	322	150 m	225 m	225 m	325 m



	Model	Rated Current (Arms)		Without output reactor		(3%) With output reactor	
		Constant Torque	Variable Torque	Shielded Cable	Unshielded Cable	Shielded Cable	Unshielded Cable
<b>380V</b> \ <b>480V</b>	CX-003A-4V	1.7	3	50 m	75 m	75 m	115 m
	CX-004A-4V	3	4.2	50 m	75 m	75 m	115 m
	CX-005A-4V	4	5.5	50 m	75 m	75 m	115 m
	CX-008A-4V	6	8.5	50 m	75 m	75 m	115 m
	CX-010A-4V	9	10.5	50 m	75 m	75 m	115 m
	CX-013A-4V	10.5	13	50 m	75 m	75 m	115 m
	CX-018A-4V	12	18	100 m	150 m	150 m	225 m
	CX-024A-4V	18	24	100 m	150 m	150 m	225 m
	CX-032A-4V	24	32	100 m	150 m	150 m	225 m
	CX-038A-4V	32	38	100 m	150 m	150 m	225 m
	CX-045A-4V	38	45	100 m	150 m	150 m	225 m
	CX-060A-4V	45	60	100 m	150 m	150 m	225 m
	CX-073A-4V	60	73	100 m	150 m	150 m	225 m
	CX-091A-4V	73	91	150 m	225 m	225 m	325 m
	CX-110A-4V	91	110	150 m	225 m	225 m	325 m
	CX-150A-4V	110	150	150 m	225 m	225 m	325 m
	CX-180A-4V	150	180	150 m	225 m	225 m	325 m
	CX-220A-4V	180	220	150 m	225 m	225 m	325 m
	CX-260A-4V	220	260	150 m	225 m	225 m	325 m
	CX-310A-4V	260	310	150 m	225 m	225 m	325 m
CX-370A-4V	310	370	150 m	225 m	225 m	325 m	
CX-460A-4V	370	460	150 m	225 m	225 m	325 m	
CX-530A-4V	460	530	150 m	225 m	225 m	325 m	
CX-616A-4V	550	616	150 m	225 m	225 m	325 m	
CX-683A-4V	616	683	150 m	225 m	225 m	325 m	
CX-770A-4V	683	770	150 m	225 m	225 m	325 m	
CX-930A-4V	866	912	150 m	225 m	225 m	325 m	

**ELECTRICAL INSTALLATION**  
**Wiring Guidelines**

	Model	Rated Current (Arms)		Without output reactor		(3%) With output reactor	
		Constant Torque	Variable Torque	Shielded Cable	Unshielded Cable	Shielded Cable	Unshielded Cable
<b>525V</b> \ <b>600V</b>	CX-003A-6V	2.5	3	35 m	30 m	45 m	20 m
	CX-004A-6V	3.6	4.3	35 m	30 m	45 m	20 m
	CX-006A-6V	5.5	6.7	35 m	30 m	45 m	20 m
	CX-009A-6V	8.2	9.9	35 m	30 m	45 m	20 m
	CX-012A-6V	10	12.1	35 m	30 m	45 m	20 m
	CX-018A-6V	15.4	18.7	35 m	30 m	45 m	20 m
	CX-024A-6V	20	24.2	35 m	30 m	45 m	20 m
	CX-030A-6V	24	30	20 m	35 m	30 m	45 m
	CX-036A-6V	30	36	20 m	35 m	45 m	60 m
	CX-045A-6V	36	45	20 m	45 m	60 m	75 m
	CX-054A-6V	45	54	20 m	45 m	60 m	75 m
	CX-067A-6V	54	67	20 m	45 m	60 m	100 m
	CX-086A-6V	67	86	20 m	45 m	60 m	100 m
	CX-104A-6V	86	104	20 m	45 m	75 m	100 m
	CX-125A-6V	104	125	20 m	45 m	75 m	100 m
CX-150A-6V	125	150	20 m	45 m	75 m	100 m	
<b>690V</b>	CX-180A-6V	150	180	20 m	45 m	90 m	100 m
	CX-220A-6V	180	220	20 m	45 m	90 m	100 m
	CX-290A-6V	220	290	20 m	45 m	90 m	100 m
	CX-350A-6V	290	350	20 m	45 m	90 m	100 m
	CX-430A-6V	350	430	20 m	45 m	90 m	100 m
	CX-465A-6V	385	465	20 m	45 m	90 m	100 m
	CX-590A-6V	465	590	20 m	45 m	75 m	90 m
	CX-675A-6V	675	675	20 m	45 m	75 m	90 m

## Power Wiring Connections

### ⚠ WARNING



**Contact with hazardous voltage could result in death or serious injury.**

- Disconnect and lock out all power before installing or servicing equipment.
- Always check if DC bus charge LED is off and DC voltage on the terminals DC (+) and DC (-) is less than 30VDC before working on VFD wiring. The DC bus capacitors may hold high-voltage charge for several minutes after the VFD power is disconnected.
- Connect the motor, the drive, metal plumbing, and all other metal near the motor or cable to the power supply ground terminal using wire no smaller than motor cable wires.
- All wiring must comply with the National Electrical Code and local codes.


### NOTICE

**Risk of damage to VFD, or malfunction can occur.**

- Do not connect input power to VFD output terminals U, V, and W otherwise VFD can be damaged.
- Ensure that the system is properly grounded all the way to the service entrance panel. Improper grounding may result in loss of voltage surge protection and interference filtering.
- Do not connect any wires except dynamic braking resistor to (B1) and (B2) terminals.
- Do not remove the jumper between terminals (2+) and (1+) except for dynamic braking unit or DC link choke, otherwise the VFD can be damaged.
- When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200mA or above and not less than 0.1-second operation time to avoid nuisance tripping.

### Power Wiring Diagram

1. Main Connection, Power
2. VFD
3. Motor
4. Ground Terminals
5. Power input terminals
6. Output to Motor terminals
7. Jumper (optional DC reactor, dynamic brake or DC choke unit)
8. Optional brake resistor terminals



Use ring type terminals for the VFD power wiring.

Power line ground and motor ground wires should be connected to designated ground terminals.

Three-phase power, including Open-Delta, must be connected to the R(L1), S(L2), and T(L3) terminals. Proper phase sequencing is not required.

- For single-phase power, connect L1 to R and L2 to S terminals.
- G and H frame VFDs have double-pole power terminals or lugs to accommodate two smaller gauge wires.

Connect three-phase motor wires to the U(T1), V(T2), and W(T3) terminals. When in forward rotation, the motor shaft should turn clockwise when viewed from the motor to the load. If rotation is not correct, reverse any two motor leads.

## ELECTRICAL INSTALLATION

### Power Wiring Connections

---

**Frame A:** Power terminals accept wire sizes up to 8 AWG and should be tightened to a torque of 17.4 in-lbs (1.96 Nm).

**Frame B:** Power terminals accept wire sizes up to 4 AWG and should be tightened to a torque of 30.4 in-lbs (3.43 Nm).

**Frame C:** Power terminals accept wire sizes up to 1/0 AWG and should be tightened to a torque of 69.4 in-lbs (7.84 Nm).

**Frame D0:** Power terminals accept wire sizes up to 2/0 AWG and should be tightened to a torque of 69.4 in-lbs (7.84 Nm).

**Frame D:** Power terminals accept wire sizes up to 300 MCM or 4/0 AWG and should be tightened to a torque of 156 in-lbs (18 Nm).

**Frame E:** Power terminals accept wire sizes up to 4/0 AWG\*2 and should be tightened to a torque of 174 in-lbs (20 Nm).


**Frame F:** Power terminals accept wire sizes up to 300 MCM\*2 or 4/0 AWG\*2 and should be tightened to a torque of 156 in-lbs (18 Nm).

**Frame G:** Terminals R, S & T accept wire sizes up to 250 MCM\*4 and should be tightened to a torque of 156 in-lbs (18 Nm). Terminals U, V, & T accept wire sizes up to 500 MCM\*2 and should be tightened to a torque of 354 in-lbs (40 Nm).

**Frame H:** Power terminals accept wire sizes up to 350 MCM\*4 and should be tightened to a torque of 156 in-lbs (18 Nm).

## Control Circuit Connections

### Terminal Identification



The control board is divided into 5 groups of terminals and connectors, plus a group of micro switches that control individual terminal configurations.

- Always insulate bare control or shield wires with shrink tubing or electrical tape to prevent short circuit.
- The ideal length of stripped wire for control terminals is 5 mm.

1. **Analog Inputs/Outputs** – These connections are used for transducers, sensors, and control systems such as a BAS, BMS, or PLC. Use shielded cable with shield connected to the ground  $\perp$  terminal. Terminals accept 26-16 AWG (0.13-1.3mm<sup>2</sup>) wires, and should be tightened to a torque of 1.73 lb-in (0.19 Nm).

- **ACI** is a 0-10 VDC or 4-20 mA input, adjustable by micro switch. Set [10-00] to match the switch setting.
- **AVI1** is a 0-10 VDC or 4-20 mA input, adjustable by micro switch. Set [10-05] to match the switch setting.
- **AVI2** is a 0-10VDC input.

When an input source has been connected, select the appropriate terminal in either **Auto Speed Ref** [SET-07], **Hand Speed Ref** [SET-09], or **PID F/B Source** [SET-18].

- **AFM1 & AFM2** are programmable, multi-function analog outputs. Refer to [10-59] and [10-61] for options. Each output can be set by micro switch to 0-10V (min load 5k  $\Omega$  at 2 mA) or 0/4-20 mA (max load 500  $\Omega$ ).
- **+10V** terminal (with common ACM) provides a +10 VDC 50 mA power supply for input devices.
- **ACM** terminals are the common for analog inputs, outputs and +10 VDC power supply. All ACM terminals are connected internally.


## ELECTRICAL INSTALLATION

### Control Circuit Connections

---

2. **Digital Inputs & RS-485 Communication** – These connections provide input for a wide selection of switches or programmable controls. Use shielded cable or twisted wires for 24 VDC digital control circuits wiring and separate these wires from the main power and motor wiring and other high voltage circuits. Terminals accept wire sizes from 24-14 AWG (0.2-1.5mm<sup>2</sup>), and should be tightened to a torque of 6.9 lb-in (0.78 Nm).

#### NOTES:


- Digital inputs are configured for NPN (Sink) mode by default, with a jumper across +24 and COM terminals. Refer to [“NPN and PNP Digital Inputs Configuration” on page 42.](#)
  - All digital inputs can be re-programmed from Normally Open to Normally Closed.
  - Digital inputs are activated by voltage 11 VDC or greater. Maximum input voltage rating is 27 VDC at 3.5 mA.
  - **M11-M18** are programmable, multi-function digital inputs that can be used for a variety of switching features with common terminal DCM. Refer to [10-21] through [10-28] for options.
  - **FWD & REV** are dedicated Forward and Reverse run commands. If any digital input is programmed for FWD or REV, corresponding dedicated FWD or REV input will be disabled automatically.
  - **+SG+, SG-, & SGND** are communication terminals for Modbus RS485 with a shielded cable. Termination resistance is controlled by micro switch. Set the switch to the **Down** position to connect 120 Ω termination resistance for long distance or for an electrically noisy environment.
  - **+24** terminal provides 24 VDC (with DCM common) 50 mA power for digital control circuits and 150 mA for external transducers.
  - **COM** terminal is a digital inputs common. By default, it is connected by jumper to +24 to configure NPN (Sink) mode.
  - **DCM** is the internal 24 VDC power supply common.
  -  Earth ground. Use this terminal to connect shield wires.
- IMPORTANT:** DCM and ACM terminals are isolated from each other and from the ground. Do not connect these terminals to earth ground, which can cause electrical noise in control circuits and unstable VFD operation.

3. **Relay Outputs** – These are configurable, multi-function, dry contact relays. Refer to [10-47] through [10-49] for options. Terminals accept wire sizes from 24-14 AWG (0.2-1.5mm<sup>2</sup>), and should be tightened to a torque of 4.3 lb-in (0.49 Nm).
  - Relays ratings are 1.25A at 250 VAC, or 3A at 30 VDC.
  - RA1-RB1-RC1 is a single-pole, double throw relay. RA1-RC1 is N.O. (normally open), and RB1-RC1 is N.C. (normally closed).
  - RA2-RC2 and RA3-RC3 are independent single pole, single throw, normally open relays.
4. **Safety Off Inputs** – These connections provide emergency stop control from an external system. By default, the inputs are closed through jumper wires, allowing the drive to run.
5. **RJ-45 Sockets** – These connections are communication terminals for PLC, Modbus, or BACnet. Use [PLC-23] to set the Com Type. Then set both Speed Reference and Run Command to **RS485**. Both RJ-45 sockets are connected internally.

## Example Configurations


### 4-20mA Speed Control Signal from an External BMS or PLC:

- Connect the BMS or PLC output signal to the ACI or AVI1 terminal. The ACI micro switch should be in the **UP** position. If using the AVI1 terminal, the AVI1 micro switch should be **DOWN**.
- Connect the BMS Com wire to the ACM terminal (signal ground).
- Any shield wire should be connected to  $\perp$  Earth ground.
- **ACI Input Select [I0-00]** or **AVI1 Input Select [I0-05]** should be set to the correct signal type.
- **Auto Speed Reference [SET-07]** should be set to the chosen input.




### 0-10V Speed Control Signal from an External BMS or PLC:

- Connect the BMS or PLC output signal to the AVI1, AVI2, or ACI terminal. The AVI1 micro switch should be in the **UP** position. If using the ACI terminal, the ACI micro switch should be **DOWN**.
- Connect the BMS Com wire to the ACM terminal (signal ground).
- Any shield wire should be connected to  $\perp$  Earth ground.
- **AVI1 Input Select [I0-05]** or **ACI Input Select [I0-00]** should be set to 0-10V.
- **Auto Speed Reference [SET-07]** should be set to the chosen input.




### 4-20mA Transducer with VFD 10 VDC Power:

- Connect the transducer positive (Ppower) wire to the VFD +10V terminal.
- Connect the transducer output (Out) wire to the ACI or AVI1 terminal. The ACI micro switch should be in the **UP** position. If using the AVI1 terminal, the AVI1 micro switch should be **DOWN**.
- Any shield wire should be connected to  $\perp$  Earth ground.
- **ACI Input Select [I0-00]** or **AVI1 Input Select [I0-05]** should be set to the correct signal type.
- **Auto Speed Reference [SET-07]** should be set to **PID Output, PID Feedback Source [SET-18]** should be set to the chosen input, and **PID Feedback Units [SET-19]** should be set to the appropriate scale (psi, temp, flow, etc.).



### 4-20mA Transducer with VFD 24 VDC Power:

- Connect the transducer positive (Power) wire to the VFD +24V terminal.
- Connect the transducer output (Out) wire to the ACI or AVI1 terminal. The ACI micro switch should be in the **UP** position. If using the AVI1 terminal, the AVI1 micro switch should be **DOWN**.
- Use a jumper wire to connect the ACM and DCM terminals.
- Any shield wire should be connected to  $\perp$  Earth ground.
- **ACI Input Select [I0-00]** or **AVI1 Input Select [I0-05]** should be set to the correct signal type.
- **Auto Speed Reference [SET-07]** should be set to **PID Output, PID Feedback Source [SET-18]** should be set to the chosen input, and **PID Feedback Units [SET-19]** should be set to the appropriate scale (psi, temp, flow, etc.).




## ELECTRICAL INSTALLATION

### Control Circuit Connections


#### 4-20mA Transducer with External 24 VDC Power:

- Connect the transducer positive (Power) wire to the external source positive [+24V]. Connect the external source negative to the VFD ACM terminal.
- Connect the transducer output (Out) wire to the ACI or AVI1 terminal. The ACI micro switch should be in the **UP** position. If using the AVI1 terminal, the AVI1 micro switch should be **DOWN**.
- Any shield wire should be connected to  $\perp$  Earth ground.
- **ACI Input Select [I0-00]** or **AVI1 Input Select [I0-05]** should be set to the correct signal type.
- **Auto Speed Reference [SET-07]** should be set to **PID Output**, **PID Feedback Source [SET-18]** should be set to the chosen input, and **PID Feedback Units [SET-19]** should be set to the appropriate scale (psi, temp, flow, etc.).




#### 0-10VDC Transducer with VFD 10 VDC Power:

- Connect the transducer positive (Power) wire to the VFD +10V terminal.
- Connect the transducer output (Out) wire to the AVI1, AVI2, or ACI terminal. The AVI1 micro switch should be in the **UP** position. If using the ACI terminal, the ACI micro switch should be **DOWN**.
- Connect the transducer Com wire to the ACM terminal (signal ground).
- Any shield wire should be connected to  $\perp$  Earth ground.
- **AVI1 Input Select [I0-05]** or **ACI Input Select [I0-00]** should be set to **0-10V**.
- **Auto Speed Reference [SET-07]** should be set to **PID Output**, **PID Feedback Source [SET-18]** should be set to the chosen input, and **PID Feedback Units [SET-19]** should be set to the appropriate scale (psi, temp, flow, etc.).




#### 0-10VDC Transducer with VFD 24 VDC Power:

- Connect the transducer positive (Power) wire to the VFD +24V terminal.
- Connect the transducer output (Out) wire to the AVI1, AVI2, or ACI terminal. The AVI1 micro switch should be in the **UP** position. If using the ACI terminal, the ACI micro switch should be **DOWN**.
- Connect the transducer Com wire to the ACM terminal (signal ground).
- Use a jumper wire to connect the ACM and DCM terminals.
- Any shield wire should be connected to  $\perp$  Earth ground.
- **AVI1 Input Select [I0-05]** or **ACI Input Select [I0-00]** should be set to **0-10V**.
- **Auto Speed Reference [SET-07]** should be set to **PID Output**, **PID Feedback Source [SET-18]** should be set to the chosen input, and **PID Feedback Units [SET-19]** should be set to the appropriate scale (psi, temp, flow, etc.).



#### 0-10VDC Transducer with External 24 VDC Power:


- Connect the transducer positive (Power) wire to the external source positive [+24V].
- Connect the transducer Com wire to the external source negative.
- Connect the transducer output (Out) wire to the AVI1, AVI2, or ACI terminal. The AVI1 micro switch should be in the **UP** position. If using the ACI terminal, the ACI micro switch should be **DOWN**.
- Any shield wire should be connected to  $\perp$  Earth ground.
- **AVI1 Input Select [I0-05]** or **ACI Input Select [I0-00]** should be set to **0-10V**.
- **Auto Speed Reference [SET-07]** should be set to **PID Output**, **PID Feedback Source [SET-18]** should be set to the chosen input, and **PID Feedback Units [SET-19]** should be set to the appropriate scale (psi, temp, flow, etc.).






**Temperature Protection or PID Control with PT-100 or PTC Sensor:**

- Connect the sensor Positive wire to the AFM2 terminal. Place the AFM2 micro switch in the **DOWN** position.
- Connect the sensor Negative wire to the ACM terminal.
- Use a jumper wire to connect the AFM2 and AVI1 terminals. The AVI1 micro switch should be in the **UP** position.
- Any shield wire should be connected to  $\perp$  Earth ground.
- **AFM2 Out Select [10-61]** should be set to Output Voltage.
- **AVI1 Input Select [10-05]** should be set to **PT100** or **PTC**.
- For PID control, **Auto Speed Reference [SET-07]** should be set to **PID Output**, **PID Feedback Source [SET-18]** should be set to the chosen input, and **PID Feedback Units [SET-19]** should be set to the appropriate scale (psi, temp, flow, etc.).
- For temperature protection, make appropriate settings to **[PROT-30-33]**.




**Speed Control using 0-10 VDC Potentiometer:**

- Connect the potentiometer Positive wire to the VFD +10V terminal.
- Connect the potentiometer Output wire to the AVI1, AVI2, or ACI terminal. The AVI1 micro switch should be in the **UP** position. If using the ACI terminal, the ACI micro switch should be **DOWN**.
- Connect the potentiometer Com wire to the ACM terminal (signal ground).
- Any shield wire should be connected to  $\perp$  Earth ground.
- **AVI1 Input Select [10-05]** or **ACI Input Select [10-00]** should be set to **0-10V**.
- **Auto Speed Reference [SET-07]** or **Hand Speed Reference [SET-09]** should be set to the chosen input.



## NPN and PNP Digital Inputs Configuration

Cerus X-Series drive control can be configured to Sink (NPN) or Source (PNP) modes by providing proper wiring and installing/removing jumper on terminals +24, COM and DCM.



The picture above shows four possible digital inputs configurations:

- 1. Sink (NPN) mode with internal 24VDC power source (Default).** Install jumper between +24 and COM terminals. Connect dry contact or NPN transistor output from external control device to desired digital input and DCM terminals. When contact is closed or transistor is in conducting state, digital input will be activated by internal power supply.
- 2. Source (PNP) mode with internal 24VDC power source.** Install jumper between DCM and COM terminals. Connect dry contact or PNP transistor output from external control device to desired digital input and +24 terminals. When contact is closed or transistor is in conducting state, digital input will be activated by internal power supply.
- 3. Sink (NPN) mode with external 24VDC power source.** Remove any jumpers between +24 and COM or DCM and COM terminals. Connect positive terminal of external power supply to COM terminal. Connect dry contact or NPN transistor output from external control device to desired digital input and negative terminal of external power supply. When contact is closed or transistor is in conducting state, digital input will be activated by external power supply.
- 4. Source (PNP) mode with external 24VDC power source.** Remove any jumpers between +24 and COM or DCM and COM terminals. Connect negative terminal of external power supply to COM terminal. Connect dry contact or PNP transistor output from external control device to desired digital input and positive terminal of external power supply. When contact is closed or transistor is in conducting state, digital input will be activated by external power supply.

# DRIVE PROGRAMMING

## Using the Control Interface

**LCD Display Screen**

**Function Keys** provide access to (F1) Jog Function, (F2) View Mode, and (F3) Fault history.

The **HAND** LED indicates when the VFD is in Hand mode.

The **Back** key returns display to the previous screen.

**Left and Right Arrow** keys allow navigation between parameter groups, cursor movement when setting a value, and for increment of numeric values.

The **HAND** key places the VFD in Hand mode when keypad control is enabled.

The **START** key starts the motor when keypad control is enabled. The LED indicates that a Start command is present.

The **FWD/REV** key selects motor direction when enabled. The LED lights either green or red to indicate selection.

The **ESC** key returns to the Home Screen from any menu.

The **RUN** LED indicates that power is being sent to the motor.

**Up and Down Arrow** keys allow navigation within a parameter group.

The **MENU** key provides access for editing all parameter groups.

The **ENTER** key places the VFD in programming mode and confirms changes to parameters.

The **AUTO** key places the VFD in Auto mode when keypad control is enabled.

The **STOP/RESET** key stops the motor when keypad control is enabled, or if enabled in remote mode. The LED indicates that the VFD is stopped. RESET can be used to clear some faults.

## Home Screen Display Options

### 1. Operating Status


Run/Stop  
Limit by PID 2  
Ctrl by PID 2  
Stopped by AI  
Backspin Timer  
Lubrication  
Limit by Level  
Limit by Temp  
Stall

### 2. Command Source

K = Keypad  
T = Terminal control  
R = RS485  
O = Option board

### 3. Frequency Source

K = Keypad/PID  
V1 = from AV1  
V2 = from AV2  
C = from ACI  
R = RS485  
O = Option board  
1-15 = Step speed  
J = Jog frequency



### 4. Mode = Hand or Auto

### 5. User selectable display.

Use Arrow and Enter keys to step through selections and to change setpoints.  
H = Output speed when running (Hz).  
P = PID Setpoint in application based units (PSI, inWC, etc.) [SET-21]. This is adjustable using the keypad.  
F = Keypad Setpoint (Hz). This is adjustable using the keypad.

### 6. Output Current.

Other options available through [VFD-48].

### 7. User selectable display.

Use Arrow keys to step through choices. This display corresponds to choices in [SET-57].

## Setting Operating Parameters

### Enter Required Parameters Before Starting VFD

1. **Application [SET-00]:** Use the keypad to select the type of application the drive will control. When a selection has been made, application related parameters will be automatically updated to proper defaults. Enter the following parameters to ensure best performance for the specific installation.


**NOTE:** the **BASIC** application provides standard VFD control with start/stop command from keypad and speed reference from a remote analog signal. For systems using a transducer or other control sensors, choose the relevant motor type to ensure that correct defaults are set.

2. **Input Power Phase [SET-01]:** Verify that the setting matches the type of power supply—3-phase (default).
3. **Motor Horsepower [SET-02]:** Enter the rated horsepower from the motor nameplate.
4. **Motor FLA (SFA) [SET-03]:** Enter the FLA (Full Load Amps) rating from the motor nameplate; or, enter SFA (Service Factor Amps) if using a submersible pump motor.
5. **Motor RPM [SET-04]:** Enter the rated motor RPM from the motor nameplate.
6. **Motor Voltage [SET-05]:** Enter the rated voltage from the motor nameplate.

#### Main Menu



#### Set Menu



### Verify Default Settings

After the initial parameters have been entered, the following default settings should be checked and adjusted to ensure expected operation. Refer to the [“Default Settings Tables” on page 45](#) for a list of automatically populated settings per application.

1. **Auto Speed Ref [SET-07]:** Select the source of frequency (speed) setpoint the drive will use when in Auto mode.
  - When using one of the analog inputs with an automated BAS, BMS, or PLC system, be sure to configure the terminal for the correct impedance. Refer to [“Terminal Identification” on page 37](#).
  - When using feedback from an analog sensor, such as a transducer, select PID Output. When PID mode is selected, additional parameters must be verified for setpoints, inputs, and limits.
2. **Auto Run Command [SET-08]:** Select the source of RUN command when VFD is in Auto Mode—Keypad or external.
3. **Hand Speed Ref [SET-09]:** Select the source of frequency (speed) setpoint the drive will use when in Hand mode. PID is disabled in Hand mode. Be sure to configure any selected input terminals for the correct impedance.
4. **Hand Run Command [SET-10]:** Select the source of RUN command when VFD is in Hand Mode—Keypad or external.
5. **Low Frequency Limit [SET-13]:** The lowest frequency (speed in Hz) allowed by the VFD in any mode.
6. **High Frequency Limit [SET-14]:** Enter the highest frequency (speed in Hz) allowed by the VFD in any mode.
7. **PID Mode [SET-17]:** Enables or disables PID control, either direct or inverse.
8. **PID Feedback Source [SET-18]:** Selects an input terminal for PID Feedback source. Be sure to configure the terminal for the correct impedance.
9. **PID Feedback Unit [SET-19]:** Selects a measurement unit for PID feedback.
10. **Feedback Max [SET-20]:** Enter the maximum reading of the feedback source. This is used to scale the sensor.
11. **PID Setpoint [SET-21]:** Enter the desired value for the drive to maintain in PID mode, running in Auto. This parameter can also be changed through keypad control.
12. **PID Low Frequency Limit [SET-22]:** PID frequency output will be limited to this value.
13. **PID High Frequency Limit [SET-23]:** PID frequency output will be limited to this value.

## Verify Control Terminal Settings

For each type of control hardware that has been connected to the system—sensors, switches, BAS, etc., make sure that the matching function parameters have been identified for the input terminals. For more information, refer to [“Example Configurations” on page 39](#) or to [“Parameter Descriptions > I/O Menu” on page 94](#).

## Enter or Verify Optional Settings

If using any of the optional features available in the system, make sure that all related parameters are set for the desired operation. Refer to the application descriptions in [“Operation” on page 57](#) for information about these features:

- **Automation features:** Refer to [“Automated Control Features” on page 60](#).
- **Protection features:** Refer to [“Protection Features” on page 69](#).
- **Multi-Motor applications:** Refer to [“Multi-Motor \(MMC\) Relay Control for Pump Applications” on page 71](#).
- **Communications features:** Refer to [“Communications” on page 73](#).

For more details on individual parameter settings, refer to [“Parameter Reference Tables” on page 87](#).

## Default Settings Table - SET Menu

Parameters in highlighted rows are reset when the application is changed [SET-00].

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
SET-01	Input Phase	3-Phase	3-Phase	3-Phase	3-Phase	3-Phase	3-Phase	3-Phase	3-Phase
SET-02	Motor HP	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating
SET-03	Motor FLA (SFA)	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating
SET-04	Motor RPM	1750	1750	1750	1750	1750	3450	1750	1750
SET-05	Motor Voltage	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating
SET-06	Carrier Frequency	2 kHz	2 kHz	2 kHz	2 kHz	2 kHz	2 kHz	2 kHz	2 kHz
SET-07	Auto Speed Ref	ACI Analog	PID Output	PID Output	PID Output	PID Output	PID Output	PID Output	ACI Analog
SET-08	Auto Run Cmd	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad
SET-09	Hand Speed Ref	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad
SET-10	Hand Run Cmd	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad
SET-11	Accel Time	20 Sec	20 Sec	20 Sec	20 Sec	20 Sec	2 Sec	20 Sec	20 Sec
SET-12	Decel Time	30 Sec	30 Sec	30 Sec	30 Sec	30 Sec	2 Sec	30 Sec	30 Sec
SET-13	Low Freq Limit	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	30 Hz	20 Hz	0 Hz
SET-14	High Freq Limit	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
SET-15	Load Rotation	FWD Only	FWD Only	FWD Only	FWD Only	FWD Only	FWD Only	FWD Only	FWD Only
SET-16	Stop Mode	Coast	Coast	Coast	Coast	Decel	Decel	Coast	Decel
SET-17	PID Mode	PID Direct	PID Direct	PID Inverse	PID Inverse	PID Direct	PID Direct	PID Direct	PID Direct
SET-18	PID F/B Source	ACI	ACI	ACI	ACI	ACI	ACI	ACI	ACI
SET-19	PID F/B Unit	PSI	inWC	inWC	°F	PSI	PSI	inWC	PSI
SET-20	PID F/B Max	1 PSI	1 inWC	1 inWC	150 °F	100 PSI	100 PSI	407 inWC	100 PSI
SET-21	PID Setpoint	0.5 PSI	0.5 inWC	0.5 inWC	76 °F	60 PSI	60 PSI	60 PSI	60 PSI
SET-22	PID Lo Hz Limit	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	30 Hz	20 Hz	20 Hz
SET-23	PID Hi Hz Limit	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
SET-24	PID P-Gain	1%	1%	1%	1%	2%	2%	1%	1%
SET-25	PID I-Time	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec	0.5 Sec
SET-26	Sleep Mode	Disabled	Disabled	Disabled	Disabled	Sleep Only	Sleep Only	Disabled	Disabled
SET-27	Sleep Check Time	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec

## DRIVE PROGRAMMING

### Default Settings Table - VFD Menu

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
SET-28	Sleep Delay Time	6 Sec	6 Sec	6 Sec	6 Sec	6 Sec	6 Sec	6 Sec	6 Sec
SET-29	Sleep Boost Value	3%	3%	3%	3%	3%	3%	3%	3%
SET-30	Sleep Boost Timer	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec
SET-31	Wake-Up Level	0.5 PSI	0.5 inWC	0.5 inWC	75 °F	55 PSI	55 PSI	55 inWC	55 PSI
SET-32	Sleep Bump Timer	5 Sec	5 Sec	5 Sec	5 Sec	5 Sec	5 Sec	5 Sec	5 Sec
SET-33	Pipe Fill Timer	0 Min	0 Min	0 Min	0 Min	0 Min	0 Min	0 Min	0 Min
SET-34	Pipe Fill Exit Level	0.4 PSI	0.4 inWC	0.4 inWC	74 °F	25 PSI	25 PSI	25 inWC	25 PSI
SET-35	Pipe Fill Freq	47 Hz	47 Hz	47 Hz	47 Hz	47 Hz	47 Hz	47 Hz	47 Hz
SET-36	Broken Pipe Level	0 PSI	0 inWC	0 inWC	0 °F	15 PSI	15 PSI	0 inWC	0 PSI
SET-37	Broken Pipe Freq	59.5 Hz	59.5 Hz	59.5 Hz	59.5 Hz	59.5 Hz	59.5 Hz	59.5 Hz	59.5 Hz
SET-38	Broken Pipe Delay	180 Sec	180 Sec	180 Sec	180 Sec	180 Sec	180 Sec	180 Sec	180 Sec
SET-39	Overpressure Set	Disabled	Disabled	Disabled	Disabled	OP Auto Reset	OP Auto Reset	Disabled	OP Auto Reset
SET-40	Overpressure Lvl	1 PSI	1 inWC	1 inWC	80 °F	80 PSI	80 PSI	80 inWC	80 PSI
SET-41	Underload Select	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop
SET-42	Underload Level	45%	45%	45%	45%	45%	70%	45%	45%
SET-43	Underload Freq	30 Hz	30 Hz	30 Hz	30 Hz	30 Hz	59 Hz	30 Hz	20 Hz
SET-44	Underload Delay	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec
SET-45	ULD Recovery T	0 Min	0 Min	0 Min	0 Min	30 Min	30 Min	0 Min	0 Min
SET-46	ULD Recovery Cnt	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
SET-47	High Load Select	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop
SET-48	High Load Level	110%	110%	110%	110%	110%	110%	110%	150%
SET-49	High Load Freq	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	30 Hz	20 Hz	20 Hz
SET-50	High Load Delay	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec
SET-51	HLD Recovery T	0 Min	0 Min	0 Min	0 Min	0 Min	0 Min	0 Min	0 Min
SET-52	HLD Recovery Cnt	0 Min	0 Min	0 Min	0 Min	0 Min	0 Min	0 Min	0 Min
SET-53	ACC Change Freq	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz
SET-54	Second ACC	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec
SET-55	Second DCC	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec
SET-56	ACC/DCC Hyster	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz
SET-57	User Display	PID Feedback	PID Feedback	PID Feedback	PID Feedback	PID Feedback	PID Feedback	PID Feedback	PID Feedback
SET-58	PLC Menu	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
SET-59	ADV2 Menu Hide	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
SET-60	HOA Mode Source	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad

### Default Settings Table - VFD Menu

Parameters in highlighted rows are reset when the application is changed [SET-00].

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
VFD-00	VFD Max Freq	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
VFD-01	VFD Start Freq	0.50 Hz	0.50 Hz	0.50 Hz	0.50 Hz	0.50 Hz	0.50 Hz	0.50 Hz	0.50 Hz
VFD-02	VFD Base Freq	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
VFD-03	V/F Pattern	Linear	Linear	Linear	Linear	Linear	Linear	Linear	Linear
VFD-04	Step Freq-1	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-05	Step Freq-2	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-06	Step Freq-3	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-07	Step Freq-4	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-08	Step Freq-5	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-09	Step Freq-6	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-10	Step Freq-7	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-11	Step Freq-8	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz

**DRIVE PROGRAMMING**  
**Default Settings Table - VFD Menu**

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
VFD-12	Step Freq-9	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-13	Step Freq-10	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-14	Step Freq-11	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-15	Step Freq-12	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-16	Step Freq-13	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-17	Step Freq-14	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-18	Step Freq-15	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-19	ACC-2 Time	40 Sec	40 Sec	40 Sec	40 Sec	40 Sec	2 Sec	40 Sec	40 Sec
VFD-20	DEC-2 Time	40 Sec	40 Sec	40 Sec	40 Sec	40 Sec	2 Sec	40 Sec	40 Sec
VFD-21	ACC-3 Time	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec
VFD-22	DEC-3 Time	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec
VFD-23	ACC-4 Time	30 Sec	30 Sec	30 Sec	30 Sec	30 Sec	30 Sec	30 Sec	30 Sec
VFD-24	DEC-4 Time	40 Sec	40 Sec	40 Sec	40 Sec	40 Sec	40 Sec	40 Sec	40 Sec
VFD-25	S Start Time 1	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
VFD-26	S Start Time 2	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
VFD-27	S End Time 1	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
VFD-28	S End Time 2	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
VFD-29	Skip Freq 1 High	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-30	Skip Freq 1 Low	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-31	Skip Freq 2 High	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-32	Skip Freq 2 Low	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-33	Skip Freq 3 High	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-34	Skip Freq 3 Low	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-35	VFD Duty Select	Variable Torque	Variable Torque	Variable Torque	Variable Torque	Variable Torque	Variable Torque	Variable Torque	Constant Torque
VFD-36	Reset Restart	Enable	Enable	Enable	Enable	Enable	Enable	Enable	Disable
VFD-37	DC Brake CrvLvl	0%	0%	0%	0%	0%	0%	0%	0%
VFD-38	DC Time at Run	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
VFD-39	DC Time at Stop	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
VFD-40	DC Stop Freq	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-41	Dwell T at Acc	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
VFD-42	Dwell Hz at Acc	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-43	Dwell T at Dec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
VFD-44	Dwell Hz at Dec	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
VFD-46	ID Code	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
VFD-47	VFD Rated Amps	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating
VFD-48	Display Select	Frequency Command	Frequency Command	Frequency Command	Frequency Command	Frequency Command	Frequency Command	Frequency Command	Frequency Command
VFD-49	Firmware Version	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
VFD-50	Disp Filter A	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec
VFD-51	Disp Filter KPD	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec
VFD-52	FW Code	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
VFD-53	Jog ACC Time	20 Sec	20 Sec	20 Sec	20 Sec	20 Sec	2 Sec	20 Sec	20 Sec
VFD-54	Jog DEC Time	30 Sec	30 Sec	30 Sec	30 Sec	30 Sec	2 Sec	30 Sec	30 Sec
VFD-55	JOG Frequency	6.0 Hz	6.0 Hz	6.0 Hz	6.0 Hz	6.0 Hz	6.0 Hz	6.0 Hz	6.0 Hz
VFD-56	Zero-speed Mode	Standby	Standby	Standby	Standby	Standby	Standby	Standby	Standby
VFD-57	Power-on Start	Enable	Enable	Enable	Enable	Enable	Enable	Enable	Enable

**DRIVE PROGRAMMING**  
**Default Settings Table - I/O Menu**

## Default Settings Table - I/O Menu

Parameters in highlighted rows are reset when the application is changed [SET-00].

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
IO-00	ACI Input Sel	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA
IO-01	ACI Loss Trip	Decel Stop	Decel Stop	Decel Stop	Decel Stop	Decel Stop	Decel Stop	Decel Stop	Decel Stop
IO-04	ACI Filter T	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec
IO-05	AVI1 Input Sel	0-10V	0-10V	0-10V	0-10V	0-10V	0-10V	0-10V	0-10V
IO-09	AVI1 Filter T	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec
IO-10	AVI2 Filter T	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec
IO-11	PID Filter Time	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec
IO-12	PID Delay Time	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
IO-13	AI Upper Level	50%	50%	50%	50%	50%	50%	50%	50%
IO-14	AI Lower Level	10%	10%	10%	10%	10%	10%	10%	10%
IO-20	DI Filter	0.005 Sec	0.005 Sec	0.005 Sec	0.005 Sec	0.005 Sec	0.005 Sec	0.005 Sec	0.005 Sec
IO-21	MI1 Define	Speed-L	Speed-L	Speed-L	Speed-L	Speed-L	Speed-L	Speed-L	Speed-L
IO-22	MI2 Define	Speed-M	Speed-M	Speed-M	Speed-M	Speed-M	Speed-M	Speed-M	Speed-M
IO-23	MI3 Define	Speed-H	Speed-H	Speed-H	Speed-H	Speed-H	Speed-H	Speed-H	Speed-H
IO-24	MI4 Define	Fault Reset	Fault Reset	Fault Reset	Fault Reset	Fault Reset	Fault Reset	Fault Reset	Fault Reset
IO-25	MI5 Define	E-Stop	E-Stop	E-Stop	E-Stop	E-Stop	E-Stop	E-Stop	E-Stop
IO-26	MI6 Define	XCEL-L	XCEL-L	XCEL-L	XCEL-L	XCEL-L	XCEL-L	XCEL-L	XCEL-L
IO-27	MI7 Define	None	None	None	None	None	None	None	None
IO-28	MI8 Define	None	None	None	None	None	None	None	None
IO-29	FO Enable	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
IO-30	FO Frequency	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
IO-31	FO Fault Retry	10	10	10	10	10	10	10	10
IO-32	FO Retry Delay	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec
IO-33	FO Mode & Reset	PID Off Auto	PID On Auto	PID On Auto	PID On Auto	PID On Auto	PID On Auto	PID On Auto	PID Off Auto
IO-34	FO PID Setpoint	0%	0%	0%	0%	0%	0%	0%	0%
IO-35	E-Stop Mode	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop	Coast Stop
IO-36	Damper Mode	Disable	Enable	Enable	Disable	Disable	Disable	Disable	Disable
IO-37	Damper T-Delay	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec
IO-38	No-Flow Mode	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
IO-39	No Flow Delay	20 Sec	20 Sec	20 Sec	20 Sec	20 Sec	20 Sec	20 Sec	20 Sec
IO-40	No-Flow Freq	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz
IO-41	Lube/S-Clean	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
IO-42	S-Clean Timer	60 Min	60 Min	60 Min	60 Min	60 Min	60 Min	60 Min	60 Min
IO-43	Pre-Lube Timer	30 Sec	30 Sec	30 Sec	30 Sec	30 Sec	30 Sec	30 Sec	30 Sec
IO-44	Run-Lube Timer	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
IO-45	Post-Lube Timer	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
IO-46	DI NO/NC	N.O.	N.O.	N.O.	N.O.	N.O.	N.O.	N.O.	N.O.
IO-47	Relay RA1	Fault	Fault	Fault	Fault	Fault	Fault	Fault	Fault
IO-48	Relay RA2	Run	Run	Run	Run	Run	Run	Run	Run
IO-49	Relay RA3	FDT-4	FDT-4	FDT-4	FDT-4	FDT-4	FDT-4	FDT-4	FDT-4
IO-50	CNT Attained 0	0	0	0	0	0	0	0	0
IO-51	CNT Attained 1	0	0	0	0	0	0	0	0
IO-52	FDT-2 Freq	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
IO-53	FDT-2 Bandwidth	2.0 Hz	2.0 Hz	2.0 Hz	2.0 Hz	2.0 Hz	2.0 Hz	2.0 Hz	2.0 Hz
IO-54	FDT-3 Freq	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
IO-55	FDT-3 Bandwidth	2.0 Hz	2.0 Hz	2.0 Hz	2.0 Hz	2.0 Hz	2.0 Hz	2.0 Hz	2.0 Hz
IO-56	I Hi/Lo Setting	0%	0%	0%	0%	0%	0%	0%	0%
IO-57	FDT-4/5 Setting	3.0 Hz	3.0 Hz	3.0 Hz	3.0 Hz	3.0 Hz	3.0 Hz	3.0 Hz	3.0 Hz
IO-58	Relay NO/NC	N.O.	N.O.	N.O.	N.O.	N.O.	N.O.	N.O.	N.O.



**DRIVE PROGRAMMING**  
**Default Settings Table - ADV Menu**

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
IO-59	AFM1 Out Select	Output Hz	Output Hz	Output Hz	Output Hz	Output Hz	Output Hz	Output Hz	Output Hz
IO-60	AFM1 Gain	100%	100%	100%	100%	100%	100%	100%	100%
IO-61	AFM2 Out Select	ACI %	ACI %	ACI %	ACI %	ACI %	ACI %	ACI %	ACI %
IO-62	AFM2 Gain	100%	100%	100%	100%	100%	100%	100%	100%
IO-63	AFM1 mA Select	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA
IO-64	AFM2 mA Select	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA	4-20mA
IO-65	AFM1 Filter Time	0.01 Sec	0.01 Sec	0.01 Sec	0.01 Sec	0.01 Sec	0.01 Sec	0.01 Sec	0.01 Sec
IO-66	AFM2 Filter Time	0.01 Sec	0.01 Sec	0.01 Sec	0.01 Sec	0.01 Sec	0.01 Sec	0.01 Sec	0.01 Sec
IO-67	MO by AI Level	AVII	AVII	AVII	AVII	AVII	AVII	AVII	AVII
IO-68	Fault Out Opt 1	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
IO-69	Fault Out Opt 2	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
IO-70	Fault Out Opt 3	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
IO-71	Fault Out Opt 4	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
IO-72	FO Bypass	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
IO-73	FO Bypass Delay	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
IO-74	D-Inputs Status	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
IO-75	D-Relays Status	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only

## Default Settings Table - ADV Menu

Parameters in highlighted rows are reset when the application is changed [SET-00].

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
ADV-00	Upper Bound Int	100%	100%	100%	100%	100%	100%	100%	100%
ADV-01	PID Out Limit	100%	100%	100%	100%	100%	100%	100%	100%
ADV-02	Password Input	0	0	0	0	0	0	0	0
ADV-03	Parameter Reset	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
ADV-05	Password Lock	Unlocked	Unlocked	Unlocked	Unlocked	Unlocked	Unlocked	Unlocked	Unlocked
ADV-06	Acc/Dec Type	Linear	Linear	Linear	Linear	Linear	Linear	Linear	Linear
ADV-07	Acc/Dec Format	Unit 0.1 sec	Unit 0.1 sec	Unit 0.1 sec	Unit 0.1 sec	Unit 0.1 sec	Unit 0.1 sec	Unit 0.1 sec	Unit 0.1 sec
ADV-08	Energy Saving	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
ADV-09	EnergySave Gain	100%	100%	100%	100%	100%	100%	100%	100%
ADV-10	MMC Mode	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
ADV-11	Motor Quantity	1	1	1	1	1	1	1	1
ADV-12	Aux Mtr Stop Hz	0	0	0	0	0	0	0	0
ADV-13	Alt Run Time	720 min	720 min	720 min	720 min	720 min	720 min	720 min	720 min
ADV-14	S-Start ON Dly	1 sec	1 sec	1 sec	1 sec	1 sec	1 sec	1 sec	1 sec
ADV-15	S-Start Off Dly	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec
ADV-16	Mtr Switch Tmr	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec
ADV-17	Mtr Switch Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
ADV-18	Lag Start Freq	59.5 Hz	59.5 Hz	59.5 Hz	59.5 Hz	59.5 Hz	59.5 Hz	59.5 Hz	59.5 Hz
ADV-19	Lag Start Delay	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec
ADV-20	Lag Start Level	2%	2%	2%	2%	2%	2%	2%	2%
ADV-21	Lead Freq Drop	10 Hz	10 Hz	10 Hz	10 Hz	10 Hz	10 Hz	10 Hz	10 Hz
ADV-22	MMC Dec Time	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec
ADV-23	Lag Stop Freq	35 Hz	35 Hz	35 Hz	35 Hz	35 Hz	35 Hz	35 Hz	35 Hz
ADV-24	Lag Stop Delay	4 Sec	4 Sec	4 Sec	4 Sec	4 Sec	4 Sec	4 Sec	4 Sec
ADV-25	Lag Stop Level	0.3%	0.3%	0.3%	0.3%	0.3%	0.3%	0.3%	0.3%
ADV-26	Lead Freq Bump	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz	0.0 Hz
ADV-27	MMC Accel Time	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec
ADV-28	Power on Delay T	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec
ADV-29	Run Delay Timer	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
ADV-30	Backspin Timer	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
ADV-31	Aux Timer Type	On-Delay	On-Delay	On-Delay	On-Delay	On-Delay	On-Delay	On-Delay	On-Delay
ADV-32	Aux Timer Time	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec	10 Sec
ADV-33	Aux Timer Input	FWD DI	FWD DI	FWD DI	FWD DI	FWD DI	FWD DI	FWD DI	FWD DI

## DRIVE PROGRAMMING

### Default Settings Table - PROT Menu

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
ADV-34	Min Run Timer	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
ADV-55	AVR Select	Enable	Enable	Enable	Enable	Enable	Enable	Enable	Enable

### Default Settings Table - PROT Menu

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
PROT-00	Decel Method	Normal	Normal	Normal	Normal	Normal	Normal	Normal	Normal
PROT-01	Preheat Level	0%	0%	0%	0%	0%	0%	0%	0%
PROT-02	Preheat Duty	0%	0%	0%	0%	0%	0%	0%	0%
PROT-03	LV Level	By VFD rating	By VFD rating	By VFD rating	By VFD rating	By VFD rating	By VFD rating	By VFD rating	By VFD rating
PROT-04	OV Stall level	By VFD rating	By VFD rating	By VFD rating	By VFD rating	By VFD rating	By VFD rating	By VFD rating	By VFD rating
PROT-05	OV Stall Prevent	Standard	Standard	Standard	Standard	Standard	Standard	Standard	Standard
PROT-06	SW Brake V Lvl	By VFD model	By VFD model	By VFD model	By VFD model	By VFD model	By VFD model	By VFD model	By VFD model
PROT-07	OCA Level	120%	120%	120%	120%	120%	120%	120%	120%
PROT-08	OCN Level	120%	120%	120%	120%	120%	120%	120%	120%
PROT-12	OL-2 Type	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
PROT-13	OL-2 Level	120%	120%	120%	120%	120%	120%	120%	120%
PROT-14	OL-2 Delay	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec
PROT-16	ETH Type	Self Cooled	Self Cooled	Self Cooled	Self Cooled	Self Cooled	Self Cooled	Self Cooled	Self Cooled
PROT-17	ETH Delay	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec
PROT-18	OH Warn	105 °C	105 °C	105 °C	105 °C	105 °C	105 °C	105 °C	105 °C
PROT-19	PTC Select	Alarm and Run	Alarm and Run	Alarm and Run	Alarm and Run	Alarm and Run	Alarm and Run	Alarm and Run	Alarm and Run
PROT-20	PTC Level	50%	50%	50%	50%	50%	50%	50%	50%
PROT-21	OPO Trip	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
PROT-22	OPO Delay	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec
PROT-23	OPO Current	1%	1%	1%	1%	1%	1%	1%	1%
PROT-24	OPO Decel	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
PROT-25	LvX Auto Reset	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
PROT-26	IPO Check	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec
PROT-27	IPO Ripple	By VFD voltage	By VFD voltage	By VFD voltage	By VFD voltage	By VFD voltage	By VFD voltage	By VFD voltage	By VFD voltage
PROT-28	IPO Trip	Alarm and Decel	Alarm and Decel	Alarm and Decel	Alarm and Decel	Alarm and Decel	Alarm and Decel	Alarm and Decel	Alarm and Decel
PROT-29	Derating Type	Carrier by I_T	Carrier by I_T	Carrier by I_T	Carrier by I_T	Carrier by I_T	Carrier by I_T	Carrier by I_T	Carrier by I_T
PROT-30	PT100 Level 1	5 V	5 V	5 V	5 V	5 V	5 V	5 V	5 V
PROT-31	PT100 Level 2	7 V	7 V	7 V	7 V	7 V	7 V	7 V	7 V
PROT-32	PT100 L- 1 Freq	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz	0 Hz
PROT-33	PT100 L- 1 Delay	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec
PROT-34	Ground Fault Lvl	60%	60%	60%	60%	60%	60%	60%	60%
PROT-35	G-Fault Delay	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec
PROT-36	STO Alarm Type	STO Latching	STO Latching	STO Latching	STO Latching	STO Latching	STO Latching	STO Latching	STO Latching
PROT-37	IPF S-Search	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
PROT-38	Max IPF Time	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec	2 Sec
PROT-39	SS Current Lmt	100%	100%	100%	100%	100%	100%	100%	100%
PROT-40	SS After Fault	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
PROT-41	Auto Restarts	3	3	3	3	3	3	3	3
PROT-42	SS Normal Start	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
PROT-43	Spd Search Gain	40%	40%	40%	40%	40%	40%	40%	40%

**DRIVE PROGRAMMING**  
**Default Settings Table - COMM Menu**

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
PROT-44	IPF Restart Dly	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec
PROT-45	Fan Control	At power up	At power up	At power up	At power up	At power up	At power up	At power up	At power up

**Default Settings Table - COMM Menu**

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
Comm-00	COM1 Address	1	1	1	1	1	1	1	1
Comm-01	COM1 Speed	9.6 Kbps	9.6 Kbps	9.6 Kbps	9.6 Kbps	9.6 Kbps	9.6 Kbps	9.6 Kbps	9.6 Kbps
Comm-02	COM1 Loss	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Comm-03	COM1 Loss	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
Comm-04	COM1 Protocol	8, N, 1 RTU	8, N, 1 RTU	8, N, 1 RTU	8, N, 1 RTU	8, N, 1 RTU	8, N, 1 RTU	8, N, 1 RTU	8, N, 1 RTU
Comm-05	Response Delay	2 ms	2 ms	2 ms	2 ms	2 ms	2 ms	2 ms	2 ms
Comm-06	Main Frequency	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz	60 Hz
Comm-24	BACnet MAC ID	10	10	10	10	10	10	10	10
Comm-25	BACnet Speed	38.4 Kbps	38.4 Kbps	38.4 Kbps	38.4 Kbps	38.4 Kbps	38.4 Kbps	38.4 Kbps	38.4 Kbps
Comm-26	Device ID Lo	10	10	10	10	10	10	10	10
Comm-27	Device ID Hi	0	0	0	0	0	0	0	0
Comm-28	Max Address	127	127	127	127	127	127	127	127
Comm-29	Password	0	0	0	0	0	0	0	0
Comm-30	Com Card ID	No Card	No Card	No Card	No Card	No Card	No Card	No Card	No Card
Comm-31	Comm Card FW	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
Comm-32	Product code	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
Comm-33	Error code	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
Comm-34	D-Net Card Addr	1	1	1	1	1	1	1	1
Comm-35	D-Net Speed	500 Kbps	500 Kbps	500 Kbps	500 Kbps	500 Kbps	500 Kbps	500 Kbps	500 Kbps
Comm-36	D-Net Type	Standard	Standard	Standard	Standard	Standard	Standard	Standard	Standard
Comm-37	M-bus IP Type	Static IP	Static IP	Static IP	Static IP	Static IP	Static IP	Static IP	Static IP
Comm-52	Mbus Card Reset	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Comm-53	Mbus TCP Config	IP Filter	IP Filter	IP Filter	IP Filter	IP Filter	IP Filter	IP Filter	IP Filter
Comm-54	Mbus TCP Status	0	0	0	0	0	0	0	0

**DRIVE PROGRAMMING**  
**Default Settings Table - PLC Menu**

**Default Settings Table - PLC Menu**

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
PLC-00	DI used by PLC	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
PLC-01	DO used by PLC	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
PLC-02	Analog by PLC	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
PLC-03	PLC Buffer 0	0	0	0	0	0	0	0	0
PLC-04	PLC Buffer 1	0	0	0	0	0	0	0	0
PLC-05	PLC Buffer 2	0	0	0	0	0	0	0	0
PLC-06	PLC Buffer 3	0	0	0	0	0	0	0	0
PLC-07	PLC Buffer 4	0	0	0	0	0	0	0	0
PLC-08	PLC Buffer 5	0	0	0	0	0	0	0	0
PLC-09	PLC Buffer 6	0	0	0	0	0	0	0	0
PLC-10	PLC Buffer 7	0	0	0	0	0	0	0	0
PLC-11	PLC Buffer 8	0	0	0	0	0	0	0	0
PLC-12	PLC Buffer 9	0	0	0	0	0	0	0	0
PLC-13	PLC Buffer 10	0	0	0	0	0	0	0	0
PLC-14	PLC Buffer 11	0	0	0	0	0	0	0	0
PLC-15	PLC Buffer 12	0	0	0	0	0	0	0	0
PLC-16	PLC Buffer 13	0	0	0	0	0	0	0	0
PLC-17	PLC Buffer 14	0	0	0	0	0	0	0	0
PLC-18	PLC Buffer 15	0	0	0	0	0	0	0	0
PLC-19	PLC Buffer 16	0	0	0	0	0	0	0	0
PLC-20	PLC Buffer 17	0	0	0	0	0	0	0	0
PLC-21	PLC Buffer 18	0	0	0	0	0	0	0	0
PLC-22	PLC Buffer 19	0	0	0	0	0	0	0	0
PLC-23	PLC Com Type	Modbus 485	Modbus 485	Modbus 485	Modbus 485	Modbus 485	Modbus 485	Modbus 485	Modbus 485
PLC-24	PLC force to 0	0	0	0	0	0	0	0	0
PLC-25	PLC Address	2	2	2	2	2	2	2	2

**Default Settings Table - Option Menu**

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
Option-00	M10 Define	None	None	None	None	None	None	None	None
Option-01	M11 Define	None	None	None	None	None	None	None	None
Option-02	M12 Define	None	None	None	None	None	None	None	None
Option-03	M13 Define	None	None	None	None	None	None	None	None
Option-04	M14 Define	None	None	None	None	None	None	None	None
Option-05	M15 Define	None	None	None	None	None	None	None	None
Option-06	Relay exp. RA10	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-07	Relay exp. RA11	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-08	Relay exp. RA12	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-09	Relay exp. RA13	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-10	Relay exp. RA14	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-11	Relay exp. RA15	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-12	Relay exp. RA16	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-13	Relay exp. RA17	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-14	Relay exp. RA18	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-15	Relay exp. RA19	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-16	Relay exp. RA20	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
Option-17	IO Card Type	No Card	No Card	No Card	No Card	No Card	No Card	No Card	No Card

## Default Settings Table - ADV2 Menu

Parameters in highlighted rows are reset when the application is changed [SET-00].

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
ADV2-00	PID D-Gain	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
ADV2-01	Sleep Ctrl By	PID Output	PID Output	PID Output	PID Output	PID Output	PID Output	PID Output	PID Output
ADV2-03	Mtr Brake Delay	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
ADV2-04	AFM1 Rev Value	0-10 V	0-10 V	0-10 V	0-10 V	0-10 V	0-10 V	0-10 V	0-10 V
ADV2-05	AFM2 Rev Value	0-10 V	0-10 V	0-10 V	0-10 V	0-10 V	0-10 V	0-10 V	0-10 V
ADV2-06	AFM1 DC Lvl	50%	50%	50%	50%	50%	50%	50%	50%
ADV2-07	AFM2 DC Lvl	50%	50%	50%	50%	50%	50%	50%	50%
ADV2-08	Analog Curve	3x Als 3-Point	3x Als 3-Point	3x Als 3-Point	3x Als 3-Point	3x Als 3-Point	3x Als 3-Point	3x Als 3-Point	3x Als 3-Point
ADV2-09	AVII Low Value	0	0	0	0	0	0	0	0
ADV2-10	AVII Low %	0%	0%	0%	0%	0%	0%	0%	0%
ADV2-11	AVII Mid Value	5	5	5	5	5	5	5	5
ADV2-12	AVII Mid %	50%	50%	50%	50%	50%	50%	50%	50%
ADV2-13	AVII High Value	10	10	10	10	10	10	10	10
ADV2-14	AVII High %	100%	100%	100%	100%	100%	100%	100%	100%
ADV2-15	ACI Low Value	4	4	4	4	4	4	4	4
ADV2-16	ACI Low %	0%	0%	0%	0%	0%	0%	0%	0%
ADV2-17	ACI Mid Value	12	12	12	12	12	12	12	12
ADV2-18	ACI Mid %	50%	50%	50%	50%	50%	50%	50%	50%
ADV2-19	ACI High Value	20	20	20	20	20	20	20	20
ADV2-20	ACI High %	100%	100%	100%	100%	100%	100%	100%	100%
ADV2-21	AVI Low Value	0 V	0 V	0 V	0 V	0 V	0 V	0 V	0 V
ADV2-22	AVI Low %	0%	0%	0%	0%	0%	0%	0%	0%
ADV2-23	AVI Mid Value	5 V	5 V	5 V	5 V	5 V	5 V	5 V	5 V
ADV2-24	AVI Mid %	50%	50%	50%	50%	50%	50%	50%	50%
ADV2-25	AVI High Value	10 V	10 V	10 V	10 V	10 V	10 V	10 V	10 V
ADV2-26	AVI High %	100%	100%	100%	100%	100%	100%	100%	100%
ADV2-27	dEb Offset V	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating	By VFD Rating
ADV2-28	dEb Mode Select	Disable	Disable	Disable	Disable	Disable	Disable	Disable	Disable
ADV2-30	PID Mode Select	Serial	Serial	Serial	Serial	Serial	Serial	Serial	Serial
ADV2-31	PID Unit Format	0.01	0.01	0.01	0.1	0.1	0.1	0.1	0.1
ADV2-32	PID Ref Source	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad	Keypad
ADV2-52	LD Set Point	0.5 (unit)	0.5 (unit)	0.5 (unit)	70 (unit)	70 (unit)	70 (unit)	70 (unit)	70 (unit)
ADV2-53	LD Max Freq	48 Hz	48 Hz	48 Hz	48 Hz	48 Hz	48 Hz	48 Hz	48 Hz

## DRIVE PROGRAMMING

### Default Settings Table - Motor Menu

## Default Settings Table - Motor Menu

CODE	Display	Basic	Supply Fan	Exhaust Fan	Cooling Tower	Centrifugal Pump	Submersible Pump	Vacuum Pump	Constant Torque
Motor-00	Motor A Tuning	None	None	None	None	None	None	None	None
Motor-01	Motor Rs Value	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm
Motor-02	Motor Rr Value	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm
Motor-03	Motor Lm Value1	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH
Motor-04	Motor Lx Value	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH
Motor-05	Control Method	VF	VF	VF	VF	VF	VF	VF	VF
Motor-06	Motor Type	Induction	Induction	Induction	Induction	Induction	Induction	Induction	Induction
Motor-07	PM Poles	4	4	4	4	4	4	4	4
Motor-08	PM Inertia	By Motor Rating	By Motor Rating	By Motor Rating	By Motor Rating	By Motor Rating	By Motor Rating	By Motor Rating	By Motor Rating
Motor-09	PM Rs	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm	0 Ohm
Motor-10	PM Ld	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH
Motor-11	PM Lq	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH	0 mH
Motor-12	PM PG Angle	0 degree	0 degree	0 degree	0 degree	0 degree	0 degree	0 degree	0 degree
Motor-13	PM Ke Coeff	0	0	0	0	0	0	0	0
Motor-14	Rotor Zeroing	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
Motor-15	Torque Filter T	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec	0.5 Sec
Motor-16	Slip Filter T	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec	0.1 Sec
Motor-17	Torque Cmp Gain	0	0	0	0	0	0	0	0
Motor-18	Slip Cmp Gain	0	0	0	0	0	0	0	0
Motor-19	Slip Dev Level	0%	0%	0%	0%	0%	0%	0%	0%
Motor-20	Slip Dev Det T	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec	1 Sec
Motor-21	Over Slip Trip	Alarm and Run	Alarm and Run	Alarm and Run	Alarm and Run	Alarm and Run	Alarm and Run	Alarm and Run	Alarm and Run
Motor-22	Motor Hunt Gain	1000	1000	1000	1000	1000	1000	1000	1000
Motor-23	Auto restart	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec	60 Sec
Motor-24	I/F Current	40%	40%	40%	40%	40%	40%	40%	40%
Motor-25	PM Bandwidth HS	5 Hz	5 Hz	5 Hz	5 Hz	5 Hz	5 Hz	5 Hz	5 Hz
Motor-26	PMSVC Fltr Gain	1	1	1	1	1	1	1	1
Motor-27	Freq I/F to PM	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz
Motor-28	Freq PM to I/F	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz	20 Hz
Motor-29	I/F fltr time	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec	0.2 Sec
Motor-30	Angle Det Pulse	1	1	1	1	1	1	1	1
Motor-31	Zero voltage T	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec	0 Sec
Motor-32	Injection Freq	500 Hz	500 Hz	500 Hz	500 Hz	500 Hz	500 Hz	500 Hz	500 Hz
Motor-33	Injection V	15 V	15 V	15 V	15 V	15 V	15 V	15 V	15 V
Motor-34	Run Time Min	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only
Motor-35	Run Time Days	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only

# INSTALLATION TESTING

## Rotation Check

Start VFD in forward direction and check the motor rotation. If the motor is running backwards, disconnect power to the VFD and reverse any two motor leads to change the motor rotation.

- For submersible pumps or other applications that cannot be checked visually, rotation can be determined by evaluating performance. For example, if the system is not building the expected pressure, or the motor is running at less than 80% FLA or SFA at full speed, or if current does not go down as expected, it may be running backwards.
- Performance comparisons can also be made using the Load Rotation settings available in the drive. Refer to [“Forward or Reverse Selection” on page 58](#).

**IMPORTANT:** Do not use the Load Rotation setting to correct a motor that is running backwards because of incorrect wiring.

## Feedback Checks

Check the motor run current on the VFD display while running at full speed. If it is higher than motor FLA (or SFA), check motor wiring and for any mechanical problems (valves, dampers, etc.) that could create extra load on the motor shaft.

When running in PID mode, check to see that transducer feedback (i.e. pressure) matches any gauges that may be installed. If the target is not accurate, verify that the transducer scaling (Feedback Max) has been set correctly.

## Performance Checks

If PID is disabled, run the system and vary speed from VFD Low Frequency Limit to VFD High Frequency Limit. Monitor output current, which should not exceed motor FLA or SFA. Check that equipment produces the proper output (air flow, water flow, etc.) at nominal speed.

If PID is enabled, run the system with constant demand. Then change demand and monitor how system pressure or temperature reaches the setpoint value. If the system responds very slowly, or very quickly with overshooting, PID parameters P-Gain and I-Time should be adjusted.

## Sleep Mode Check (Pump Applications)

All default settings related to Sleep mode have been calculated for best system performance for most applications. However, some well conditions may require a slight adjustment.

During system setup it is recommended to test the Sleep feature by closing a main valve to simulate a no-demand condition. The system should be running at normal demand, maintaining pressure setpoint, then flow should be decreased slowly until stopped.

- If the system does not enter Sleep mode, it may be necessary to increase the **PID Lo Hz Limit [SET-22]** to ensure that system pressure reaches **PID Setpoint [SET-21]** (plus boost, if enabled).
- If, during normal operation, the system enters Sleep mode, but cycles on and off rapidly as it nears the Setpoint, it may be necessary to slightly lower the **PID Lo Hz Limit [SET-22]** to prevent Sleep mode problems.

Refer to [“Sleep Mode with Pressure Boost” on page 62](#).



# OPERATION

## Manual Control Features

### Hand/Off/Auto (HOA) Controls

The drive can be operated in either **HAND** or **AUTO** mode as follows:

- **HAND** mode runs the motor based on **Hand Speed Ref [SET-09]** (frequency source) and **Hand Run Cmd [SET-10]** (command source). Defaults for both settings are Keypad, which runs the motor at a fixed speed (**Keypad Setpoint**) set on the Home Screen. Both settings can be reprogrammed for external control. PID control is disabled in Hand mode.
- **AUTO** mode runs the motor based on **AUTO Speed Ref [SET-07]** (frequency source) and **AUTO Run Cmd [SET-08]** (command source). The speed reference default is set per application. The run command default is Keypad. Both settings can be reprogrammed as required.

There are several options to consider for operation of the VFD through HOA controls:

**HOA Mode Source [SET-60]:** This setting selects whether Hand/Auto control will come from the Keypad, a Digital Input, or Communications. When switching modes with the keypad, the VFD will stop, and will start when the **Start** key is pressed. When switching modes with a DI or Comm source, the VFD will start based on the presence of a run command.

- **Keypad (Default):** The VFD Keypad HOA buttons, including **Start** and **Stop**, are fully functional.
- **Digital Input:** Enables HOA control through an external switch wired to two digital inputs [MI1 to MI8]. These inputs should be set to **26\_Hand** and **27\_Auto** through parameters [10-21 to 28]. HOA mode is then determined as follows:

26_HOA Hand	27_HOA Auto	HOA Mode
OFF	OFF	OFF
ON	OFF	Hand
OFF	ON	Auto
ON	ON	OFF

- **RS485 Serial:** Enables HOA control through Modbus communications.
- **Com Card:** Enables HOA control through BACNet communications. The combinations of 0x2002 bit 3 and bit 4 are defined as follows:

Bit 3	Bit 4	HOA Mode
0	0	No change
1	0	Hand
0	1	Auto
1	1	OFF

**Hand Speed Ref [SET-09]:** Source of Speed Reference in Hand mode. When in Hand mode, PID is disabled and the VFD frequency is based on the following inputs:

- **Keypad (Default):** VFD runs at a fixed frequency set on the Home Screen.
- **RS485 Serial:** Frequency input through Modbus control.
- **AVI1 Analog:** Input from external controller, potentiometer, or other device.
- **ACI Analog:** Input from external controller, potentiometer, or other device.
- **AVI2 Analog:** Input from external controller, potentiometer, or other device.
- **COM Card:** Frequency input through communications protocol.



## OPERATION

### Manual Control Features

---

**Hand Run Command [SET-10]:** Source of Run Command in Hand mode. VFD starts based on input from:

- **Keypad (Default):** Run command from Start/Stop buttons.
- **Digital Input:** Run command from digital input FWD, REV, or M1-8 set to FWD [IO-21-28]. If Digital Input [IO-21-28] is set, then dedicated FWD input is disabled. Keypad STOP is disabled.
- **RS485:** Run command from RS485 interface. Keypad STOP is disabled.
- **Com Card:** Run command from communications card.
- **Ext HOA in Hand:** Run command from digital input [IO-21-28] set to HAND.

**Auto Speed Ref [SET-07]:** Source of Speed Reference in Auto mode. VFD runs at a frequency based on the following inputs:

- **Keypad:** VFD runs at a fixed frequency set on the Home Screen.
- **Up/Down DI:** Digital input increases or decreases speed when DI terminals [IO-21-28] set to Up and Down.
- **AV11 Analog:** Input from external controller, potentiometer, or other device.
- **ACI Analog:** Input from external controller, potentiometer, or other device.
- **AV12 Analog:** Input from external controller, potentiometer, or other device.
- **RS485 Serial:** Frequency input through Modbus control.
- **COM Card:** Frequency input through communications protocol.
- **PID Output:** VFD speed reference will be provided by PID control based on the difference between **PID Setpoint** [SET-21] and transducer feedback values.

**IMPORTANT:** When PID Mode is selected, additional parameter settings should be verified to ensure correct operation. Refer to [“Standard Operation with PID Feedback Control” on page 60](#) for more information.

**Auto Run Command [SET-08]:** Source of Run Command in Auto mode. VFD starts based on input from:

- **Keypad (Default):** Run command from Start/Stop buttons.
- **Digital Input:** Run command from digital input FWD, REV, or M1-8 set to FWD (or REV) [IO-21-28]. If Digital Input [IO-21-28] is set, then dedicated FWD input is disabled. Keypad STOP is disabled.
- **RS485:** Run command from RS485 interface. Keypad STOP is disabled.
- **Com Card:** Run command from communications card.
- **Ext HOA in Auto:** Run command from digital input [IO-21-28] set to AUTO.

### Forward or Reverse Selection

This feature provides the ability to change the direction of rotation of a motor used in an industrial application. The direction can be set using either the keypad **FWD/REV** button, or by setting the following parameter:

**Load Rotation [SET-15]:** Setting this parameter to **FWD & REV** enables the keypad button. Selection of either **FWD Only** or **REV Only** permanently sets the direction and disables the keypad button. This provides protection to prevent a motor from running in a direction that could damage equipment, such as a pump or fan.

**IMPORTANT:** Do not use the Load Rotation setting to correct a motor that is running backwards because of incorrect wiring.

## Jog Feature

The Jog feature provides the ability to activate a motor momentarily. The command can be executed using either the keypad **F1** button, or switches connected to a digital input.

- When using the keypad, the motor direction depends on the **Load Rotation [SET-15]** setting. Digital inputs can be set to either forward or reverse.
- The jog command cannot be used when the drive is running.
- When the jog command is active, other run commands are unavailable.

**Jog Frequency [VFD-55]:** This sets the speed the motor will run when the jog command is active.

**Jog ACC Time [VFD-53]:** This sets the acceleration time from 0 Hz to [VFD-55].

**Jog DEC Time [VFD-55]:** This sets the deceleration time from [VFD-55] to 0 Hz.

**FWD Jog [IO-21 through 28]:** To execute a forward jog command externally, connect a momentary switch to one of the Digital Inputs (MI1-8) and set the corresponding parameter to **21 FWD Jog**.

**REV Jog [IO-21 through 28]:** To execute a reverse jog command externally, connect a momentary switch to one of the Digital Inputs (MI1-8) and set the corresponding parameter to **22 REV Jog**.

**NOTE:** If an external HOA switch is set to **OFF**, the keypad **F1** button is disabled.

## Shutdown

The Shutdown feature uses a Digital Input signal [**MI1 through MI8**] from an external source to stop VFD output in the event of an emergency. The VFD will trip on Shutdown when the DI signal is activated. This function overrides all other functions and VFD cannot be started with any HOA change until stop signal is removed.

Two options are available for restarting:

**Latching Mode [IO-21 through 28]:** The Shutdown signal must be removed and the Shutdown fault must be manually reset; no auto restarts or retries are available. The VFD can then be restarted with a **RUN** command. To enable this function, connect the external emergency stop signal to one of the Digital Inputs (MI1-8) and set the corresponding parameter to **36 Shutdown Latched**.

**Non-Latching Mode [IO-21 through 28]:** If a **RUN** command is present when the Shutdown signal is removed, the VFD will restart based on HOA mode. To enable this function, connect the external emergency stop signal to one of the Digital Inputs (MI1-8) and set the corresponding parameter to **35 Shutdown N-Latch**.

Only one Digital Input can be set to Shutdown.

## **Automated Control Features**

### **Standard Operation with an Automated Control System**

In many VFD applications, including ventilation, water supply, or irrigation, motor speed is often determined by an automated system such as a BAS, BMS, or PLC. These systems provide control information to the VFD either through a communications protocol such as Modbus or BACnet, or through direct electrical connection to one of the analog input terminals.

When the drive is in **AUTO** mode, it runs the motor at a variable frequency based on information from the automation system through the input selected in **Auto Speed Ref [SET-07]**.

### **Standard Operation with PID Feedback Control**

A PID controlled application, such as a fan system or a constant pressure pump system, uses feedback from a transducer to measure system performance against a user defined Setpoint (target) to control motor speed. The VFD can use several types of measurement, including pressure, flow, level, air volume, temperature, speed, etc.

For example:

- In a pumping application, the default measurement unit is **PSI**. As user demand (flow) causes pressure changes, the drive varies the output frequency (motor speed) to maintain pressure at the target setpoint. When the drive determines a no-demand condition, it enters Sleep mode and stops the motor.
- In a fan application, the default measurement unit is **inWC** (air pressure).

When the drive is in **AUTO** mode, it runs the motor at a variable frequency based on a comparison between the **PID Setpoint [SET-21]** and feedback from the PID transducer, up to the **PID Hi Hz Limit [SET-23]**. PID operation is disabled in **HAND** mode.

When basic setup is complete, including motor specifications, verify or set the following parameters for PID operation:

**Auto Speed Ref [SET-07]:** This should be set to **PID Output**.

**Auto Run Command [SET-08]:** Select source of Run Command, either Keypad or external. If using a Digital Input (M1-8) with a switch, set the terminal to **FWD** (or **REV**) [**10-21 ~ 28**].

**PID Mode [SET-17]:** Set to **PID Direct** for most PID operations (exceptions are noted in the tables).

**Feedback Source [SET-18]:** Set to the terminal used for transducer connection. Make sure impedance is set correctly.

**PID Feedback Units [SET-19]:** Set to the appropriate measurement unit for the transducer type.

**PID Feedback Max [SET-20]:** Set to the maximum rating of the transducer.

**PID Setpoint [SET-21]:** Set to the desired measurement target.

**Sleep Mode [SET-26]:** This should be enabled for most pump applications, and **Disabled** for most HVAC applications.

**PID P-Gain [SET-24]:** Proportional Gain controls motor speed adjustments based on the proportional difference between the PID setpoint and PID feedback. Higher settings result in faster response. However, if the value is too high, it may cause system oscillation and instability. Used along with PID I-Time [SET-25] to smooth and balance system response.

**PID I Time [SET-25]:** Integral Time determines PID response time. Lower values increase system response to the feedback signal, which reduces overshoot, but may cause system oscillation if set too low. Greater values provide slower response, which may cause overshoot of the setpoint and oscillation of output frequency.

## Damper Control (HVAC Applications)

The VFD can provide a relay output to open a damper actuator before starting a fan motor. When enabled, the damper relay output is activated when the system receives a **RUN** command and the motor will start based on the following configurations:

- **With Damper Limit Switch:** If any Digital Input [10–21 through 28] is set to **Damper Limit Sw** and the VFD receives a **RUN** command, the damper relay is activated and when the damper limit switch is closed (damper is fully open and DI is activated), the VFD will start the motor.  
  
If the limit switch is not closed within the **Damper Time Delay [10–37]**, the VFD will trip on Damper Fault. If at any point during run mode damper limit switch is open for more than 2 seconds, the VFD will trip on Damper Fault. VFD will try to restart based on the retry number setting [PROT–41].
- **Without Damper Limit Switch.** If no Digital Input is configured for a damper limit switch and the VFD receives a **RUN** command, the damper relay is activated and when **Damper Time Delay [10–37]** is complete, the VFD will start the motor. There is no damper fault detection because there is no damper limit switch feedback.

**NOTE:** If any other delay timer is set and the VFD receives a **RUN** command, the damper relay will start after the first timer expires.

During run mode the damper relay stays activated. When a **STOP** command is received, the damper relay will be deactivated only in VFD stop state. If stop mode is set to deceleration, the relay will be deactivated after VFD reaches zero speed (0.00Hz).

Set the following parameters to use the Damper Control function:

**Damper Mode [10–36]:** This setting enables or disables damper mode. When enabled, the damper relay is activated before every start, including auto restarts.

**Damper T-Delay [10–37]:** This setting provides a run time delay without a damper limit switch; or, provides a Damper Fault delay for systems that include a damper limit switch. The delay should be greater than damper opening time.

**Damper Output Terminal [10–47 through 49]:** Connect the damper actuator to one of the Relay Outputs (RA1–3), and set the corresponding parameter to **38 Damper Output**.

**Damper Limit SW Terminal [10–21 through 28]:** If the system includes a damper limit switch, connect the switch to one of the Digital Inputs (MI1–8) and set the corresponding parameter to **34 Damper Limit SW**.

## Fireman’s Override

Fireman’s Override provides the ability to force the drive to run in an emergency situation.

In FO mode, if Damper Mode is enabled [10–36], the damper relay output will be activated, but damper time delay [10–37] will be reduced by half before VFD starts. The VFD will not monitor a Damper Switch, if present, and no damper faults will be available. Set the following parameters to use the Fireman’s Override function:

**FO Input Terminal [10–21 through 28]:** Connect the Fireman’s Override switch to one of the Digital Inputs (MI1–8) and set the corresponding parameter to either **32 FO with RUN Cmd** or **33 FO w/o RUN Cmd**.

**FO Enable [10–29]:** This setting enables Fireman’s Override in either Forward or Reverse.

**FO Frequency [10–30]:** Setpoint for non-PID operation during Fire Override.

**FO Fault Retry [10–31]:** Number of fault resets allowed during Fire Override.

**FO Retry Delay [10–32]:** Delay until restart during Fire Override.

**FO Mode & Reset [10–33]:** Sets control method and reset method during Fire Override: PID Off Manual, PID Off Auto, PID On Manual, or PID On Auto.

**FO PID S-Point [10–34]:** Setpoint for PID operation during Fire Override.

**FO Bypass [10–72]:** Enables Bypass for Fire Override.

**FO Bypass Delay [10–73]:** Time delay between Fire Override becoming active and enabling relay output.

## OPERATION

### Automated Control Features

---

## Pump Application Features

### Sleep Mode with Pressure Boost

The Sleep feature monitors pressure and frequency to detect a no-demand condition, at which point it stops the motor. The Sleep Feature also has the option to boost system pressure by a set amount before stopping.

The Sleep feature works only in Auto mode using PID Direct (Sleep is disabled when PID mode is set to Inverse). PID2 operation does not have Sleep function.

The following parameters control Sleep functions:

**Sleep Mode [SET-26]:** This setting enables or disables sleep mode and the sleep plus boost option. The default value for submersibles and surface/boost applications is **Sleep Only**. If a pressure boost is desired while the system is at rest, select **Sleep + Boost** and set a **Sleep Boost Value [SET-29]**.

**Sleep Check Time [SET-27]:** Time delay (sleep check cycle time) before each Sleep Check procedure. Default = 10 sec.

**Sleep Delay [SET-28]:** Delay before VFD triggers Sleep Mode when all other conditions are met. Default = 6 sec.

**Sleep Boost Value [SET-29]:** Value added to original setpoint to provide pressure boost—0.0 to 10.0% of Feedback Max Value [SET-20]. Default = 3%.

**Sleep-Boost Timer [SET-30]:** Timer that limits sleep boost duration if Sleep Boost setpoint is not reached—5 to 120 seconds. Default = 10 sec.

**Wakeup Level [SET-31]:** Sets a wakeup level for VFD to quit Sleep mode and start running—0.0 to [SET-21]. Default = 55 PSI.

**Sleep Bump Timer [SET-32]:** Sets a duration time for pressure bump to increase system pressure as part of the no-demand calculation. Default = 5 sec.

**No Flow Mode [IO-38]:** If a flow switch is installed on one of the Digital Inputs (MI1-8) and [IO-38] is set to Sleep, the flow switch becomes an additional condition for sleep mode.

All default settings related to Sleep mode have been calculated for best system performance for most applications. However, some well conditions may require a slight adjustment.

During system setup it is recommended to test the Sleep feature by closing a main valve to simulate a no-demand condition. The system should be running at normal demand, maintaining pressure setpoint, then flow should be decreased slowly until stopped.

- If the system does not enter Sleep mode, it may be necessary to increase the **PID Lo Hz Limit [SET-22]** to ensure that system pressure reaches **PID Setpoint [SET-21]** (plus boost, if enabled).
- If, during normal operation, the system enters Sleep mode, but cycles on and off rapidly as it nears the Setpoint, it may be necessary to slightly lower the **PID Lo Hz Limit [SET-22]** to prevent Sleep mode problems.

### Pipe Fill Feature

This feature automates the process of building pressure in an empty pipe system at a reduced speed before the VFD switches to PID control. This can reduce water hammer in some systems, and can also help prevent an Underload fault if the drive runs for an extended period at low pressure. The VFD must be running with PID Control in Auto mode for this feature to be active.

Set the following parameters to activate the Pipe Fill Feature:

**Pipe Fill Timer [SET-33]:** Pipe Fill mode exit timer to switch to PID control.

- Enter a time between 0.1 and 60 minutes to allow the pipe system to fill.
- If set to 0.0, Pipe Fill is disabled.
- When the timer expires, the VFD cancels Pipe Fill mode and switches to PID control, regardless of whether [SET-34] pressure has been reached.

**Pipe Fill Exit Level [SET-34]:** Pipe Fill mode exit pressure to switch to PID control.

- Enter a pressure setting between 0 and the PID Setpoint [SET-21] (default = 25 psi).
- During Pipe Fill mode, if pressure reaches the set value, VFD switches to PID control.

**Pipe Fill Freq [SET-35]:** Pipe Fill mode High frequency limit setting.

- Range is between PID Low Freq Limit [SET-22] and PID Hi Hz Limit [SET-23] (default = 47 Hz).
- The Pipe Fill mode frequency should be equal to or greater than [SET-22] +2 Hz to provide enough system pressure at the end of pipe fill mode to switch to PID control.

Upon start, if system pressure is less than [SET-34], VFD will ramp up to Low Freq Limit + 2 and start pipe fill mode.

- If system pressure is less than  $0.5 \times [\text{SET-34}]$ , the frequency reference will be increased at a rate of 0.5 Hz per second.
- If system pressure is equal to or greater than  $0.5 \times [\text{SET-34}]$  but less than  $0.6 \times [\text{SET-34}]$ , the frequency reference will stay at the current value.
- If system pressure is equal to or greater than  $0.6 \times [\text{SET-34}]$  but less than [SET-34] setting, the frequency reference will be decreased at a 0.5Hz per second rate. However, the rate will not be decreased below PID Low Hz Limit [SET-22] +2 Hz
- If at any point system pressure is equal to or greater than [SET-34], VFD will cancel Pipe Fill mode and switch to PID control.

## Lubrication Relay

The VFD has the capability to automatically activate a lubrication solenoid for line shaft turbine pumps, or for industrial machines with an external lubrication supply, before starting the motor.

Timers are available to enable lubrication before, during, or after running the motor, in any combination.

To enable the lubrication function, set the following parameters:

**Lubrication Output Terminal [IO-47 through 49]:** Connect the lubrication actuator to one of the Relay Outputs (RA1-3), and set the corresponding parameter to **41 Lube/S-Clean**.

**Lube/S-Clean [IO-41]:** Select the **Lubrication** option.

**Pre-Lube Timer [IO-43]:** 0 to 6000 seconds. This setting determines relay activation time after a run command is received and before the VFD starts. When the timer expires, the lubrication solenoid will be deactivated and the VFD will start the motor. If a stop command is received, or the VFD trips during Pre-lubrication, the relay will be deactivated and the timer accumulated value will be reset.

**Run-Lube Timer [IO-44]:** 0 to 6000 seconds. This setting determines relay activation time while the VFD is running.

- When set to a value greater than 0 and less than 6000, the relay will be activated at VFD start and will deactivate when the timer expires. If the VFD stops while the timer is active, the relay will deactivate and the timer will be reset.
- If the timer is set to the maximum 6000 sec, the relay will be activated during run mode until the VFD stops (no timing). If the VFD stops or trips, the relay will deactivate.

**Post-Lube Tmr [IO-45]:** 0 to 6000 seconds. This setting determines relay activation time after the VFD comes to a stop (0 Hz).

## Screen Clean Relay

When water is pumped from a lake or pond, the suction screen requires periodic cleaning. The VFD can automate this process by providing a relay output to an external solenoid valve that will discharge pressurized water to clean the screen.

This feature works only in run mode in HOA Hand or Auto. If HOA is in OFF, or the VFD stops or trips on a fault, the Clean Screen mode will be deactivated and related timers will be reset.

## OPERATION

### Automated Control Features

---

The VFD provides a one minute (non-adjustable) cleaning pulse at every start. When the cleaning pulse is done, the **S-Clean Timer [IO-42]** starts. When the timer ends, another cleaning pulse is activated. This cycle continues until the VFD stops.

To enable the Clean Screen function, set the following parameters:

**Screen Clean Output Terminal [IO-47 through 49]:** Connect the lubrication actuator to one of the Relay Outputs (RA1-3), and set the corresponding parameter to **41 Lube/S-Clean**.

**Lube/S-Clean [IO-41]:** Select the **Screen Clean** option.

**S-Clean Timer [IO-42]:** 0 to 600 minutes. Time between cleaning pulses.

## Timers

**IMPORTANT:** If two or more timers are activated with different time settings, the greater value timer will override other timers with a similar function.

### Power On Run Delay

This timer provides run delay at VFD power-up with run command present to prevent multiple starts during power surges.

Set the following parameter to activate this feature:

**Power On Delay [ADV-28]:** Range from 0 to 6000 sec. (Default=10sec). When set to 0 sec, it is disabled.

When set to a value greater than 0 and VFD is powered up in any HOA mode, the timer will start counting and VFD start will be disabled until the timer expires.

### Run Delay Timer (For Auto Mode)

This timer provides a delay at every VFD start when a run command is applied. The timer takes effect before every VFD start by run command, auto-restarts, fault reset, sleep wake-up, etc.

**NOTE:** FO (Fire Override) mode will disable this timer.

Set the following parameter to activate this feature:

**Run Delay Timer [ADV-29]:** Range from 0 to 6000 sec. (Default=0 sec). When set to 0 sec, it is disabled.

When set to value greater than 0 and VFD receives a start command, wakes up, auto resets, or restarts after a fault reset, the Start Delay timer will start counting. During timer counting, start is disabled and the VFD cannot be started in Hand or Auto mode. Stop command, Sleep mode, or tripping on a fault will reset this timer.

### Minimum Run Timer

The Minimum Run timer delays VFD stop when a run command is removed. This timer is useful in vacuum pump, pressure washer and similar applications.

Submersible motors should run for a minimum of one minute to dissipate heat build-up from starting current.

Set the following parameter to activate this feature:

**Minimum Run [ADV-34]:** Range from 0 to 6000 seconds. When set to 0 sec, it is disabled.

When set to value greater than 0 and VFD is started in Auto mode, Minimum Run timer will start counting. During timer counting VFD will continue to run even if start command is removed.

Shutdown feature will override this timer.



## Backspin Timer

The Backspin timer is designed to protect the VFD from tripping when starting a reverse spinning motor caused by water backflow through a pump (no check valve) right after it was stopped.

Set the following parameter to activate this feature:

**Backspin Timer [ADV-30]:** Range from 0 to 6000 seconds. When set to 0 sec, it is disabled.

When set to value greater than 0 and VFD stops, Backspin timer will start counting. During backspin time VFD is disabled and cannot be started in Hand or Auto mode.

## Performance Control Features

### Acceleration/Deceleration Control

#### Standard Rates

The VFD accelerates and decelerates a motor at a controlled rate based on the following parameters:

**Accel Time [SET-11]:** Time in seconds for the drive to accelerate from 0 Hz to maximum frequency.

**Decel Time [SET-12]:** When **Stop Mode [SET-16]** is set to Decelerate, time in seconds to slow down from maximum frequency to 0 Hz.

The defaults for these parameters are determined by the **Application [SET-00]** setting, but can be adjusted as required.

**IMPORTANT:** Setting acceleration or deceleration times that are too short may trigger over-current or over-voltage faults. Use of a suitable brake resistor can help with short deceleration times.

#### Change by Frequency

Acceleration and deceleration speeds can be modified when the VFD reaches a target frequency. For example: It may be desirable to start a motor quickly, as with a submersible pump, and then slow the response at higher speeds.


The VFD starts at the Standard rate and switches to **Second ACC [SET-54]** and **Second DCC [SET-55]** when it reaches **ACC Change Freq [SET-53]**. When the VFD decreases frequency below [SET-53]-[SET-56] it will switch back to the Standard rates.

**ACC Change Freq [SET-53]:** Frequency to switch from first acceleration/deceleration rate to second acceleration/deceleration rate.

**Second ACC [SET-54]:** Time in seconds for drive to accelerate from 0 Hz to maximum frequency. This rate takes effect when frequency is above [SET-53]. Default = 60 sec.

**Second DEC [SET-55]:** When **Stop Mode [SET-16]** is set to Decelerate, time in seconds to slow down from maximum frequency to 0 Hz. This rate takes effect when frequency is above [SET-53]. Default = 60 sec.


**ACC/DEC Hyster [SET-56]:** Hysteresis added to [SET-53] in changing the deceleration rate. This setting is subtracted from [SET-53] to delay the switch back to the [SET-12] rate. Default = 1.0 Hz.



## Monitoring Functions

### Home Screen Status Displays

The Home Screen displays default and user-selectable information about the operational status of the VFD. The keypad **ESC** key returns to the Home Screen from any menu.



- Operating Status:** This field indicates the system actions currently active:
  - Run/Stop
  - Limit by PID 2
  - Ctrl by PID 2
  - Stopped by AI
  - Backspin Timer
  - Lubrication
  - Limit by Level
  - Limit by Temp
  - Stall
- Command Source:** This field identifies the currently configured source for RUN commands:
  - K = Keypad
  - T = Terminal control
  - R = RS485
  - O = Option board
- Frequency Source:** This field identifies the currently configured source for speed (frequency) control:
  - K = Keypad/PID
  - V1 = from AV1
  - V2 = from AV2
  - C = from ACI
  - R = RS485
  - O = Option board
  - 1-15 = Step speed (DI)
  - J = Jog frequency
- Control Mode:** This field identifies whether the VFD is currently configured for **HAND** or **AUTO** control.
- User selectable display 1:** Use Arrow and Enter keys to step through selections and to change set-points.
  - (H) Actual output speed when running (Hz) for both **HAND** and **AUTO** modes.
  - (F) Keypad Setpoint (Hz) for **HAND** mode. This is adjustable using the keypad. In **AUTO** mode, the running frequency is displayed.
  - (P) PID Setpoint in application based units (PSI, inWC, etc.) [SET-21]. This is adjustable using the keypad.
- User selectable display 2:** Displays Output Current by default. Other user options are available through [VFD-48]:
  - 0\_Freq Command
  - 1\_Output Frequency
  - 2\_Multi-Fn Display
  - 3\_Output Current
- User selectable display 3:** Use Arrow keys to step through choices. This display corresponds to choices in [SET-57]. Refer to "[Parameter Descriptions > SET Menu](#)" on page 87 for a complete list of options.

## View Screens

In addition to the Home Screen status information, nine predefined user information screens are available. From any menu location, press the keypad **F2** key repeatedly to cycle through the view screens.

**View Screen 1:** This screen displays the following:


- Freq = The actual output frequency (Hz) at the time
- Ref = The PID target setpoint [SET-21]
- Fbk = The actual feedback level from the transducer.




**View Screen 2:** This screen displays feedback from the analog inputs as a percentage.



**View Screen 3:** This screen displays the status of the multi-function (digital) inputs in hex format. Solid boxes indicate that the input is active.



**View Screen 4:** This screen displays the status of the multi-function (digital) outputs in hex format. Solid boxes indicate that the output is active.



## OPERATION

### Monitoring Functions

---

**View Screen 5:** This screen displays the following:

- Temperature of the IGBTs in °C
- Temperature of the capacitors in °C.

Run	K/K	Auto
IGBT		24.1 oC
CapT		23.6 oC
JOG	View5	Faults

**View Screen 6:** This screen displays the following:

- The actual output frequency (Hz) at the time
- The actual motor speed (RPM) at the time.

Run	K/K	Auto
Freq		60.00 Hz
Spd		3600 RPM
JOG	View6	Faults

**View Screen 7:** This screen displays the following:

- DC-Bus voltage ripple
- DC-Bus voltage ripple
- Output voltage.

Run	K/K	Auto
Rple		8.3 %
DCB		675.7 V
Vout		460.0 V
JOG	View7	Faults

**View Screen 8:** This screen displays the following:

- Counter value
- Output power
- Ground fault.

Run	K/K	Auto
Cnt		0
Pout		1.4 kW
GndF		0.02 %
JOG	View8	Faults

**View Screen 9:** If a Bluetooth card has been installed, this screen displays the code for connecting with the mobile application.

Run	K/K	Auto
BT Card Name =		
123456789BCC1E5D		
MAC Address =		
12345679876		
JOG	View9	Faults

## Protection Features

### High Load Detection

High Load Detection (HLD) protects the VFD and equipment against damage from an over-torque condition. When current reading is greater than set value and speed is equal or greater than set value, the VFD will trip on HLD.

To enable this feature, adjust the following parameters:

**HLD Select [SET-47]:** Disable, Coast to stop, or Decel to stop.

**HLD Level [SET-48]:** Set as a percentage of motor FLA (SFA) (default = 110%). If all conditions are met, VFD will trip above this level.

**HLD Frequency [SET-49]:** If VFD runs at this frequency or above, and current is greater than [Set-48], HLD Delay timer [Set-50] will start.

**HLD Delay [SET-50]:** Delay range from 0 to 360 seconds. When timer expires, if current is still above [Set-48], and frequency is still above [Set-49], VFD will trip based on [Set-47].

**HLD Recovery Time [SET-51]:** 0 to 720 min (default = 0 min). If timer is set to value greater than 0 minutes, VFD will restart after timer expires. If set to 0 and the VFD trips, manual or remote reset is required (no auto retries).

If the VFD trips the first time on high load, it will restart after the Recovery timer expires. If VFD trips again, the timer value will be doubled. The VFD will continue restart attempts, doubling the timer value until it reaches 720 minutes (12 hours). Then every restart will be in 720 min. **HLD Recover Cnt [SET-52]** displays the countdown before the next restart attempt.

When the VFD finally runs without tripping for 180 sec, the recovery timer will be reset to original setting and at next high load trip VFD will wait for original [Set-51] time value.

If the run command is removed, or HOA is set to OFF, the high load feature is canceled and the [Set-51] timer is reset to its original setting.

### Overpressure

The Overpressure feature stops the VFD when PID feedback exceeds a set value in either Hand or Auto.

To enable this feature, adjust the following parameters:

**OverPress Set [SET-39]:** Disable, OP Trip, or OP Auto Reset.

- When enabled, if PID Feedback exceeds OverPress Level [SET-40], the VFD trips on Overpressure fault.
- If setting is OP Trip, manual or remote reset is required. If Reset Restart [VFD-36] is enabled and a run command is present, the VFD will restart when reset.
- If setting is OP Auto Reset, the VFD will restart when PID feedback falls below Wake-Up Level [SET-31] and a run command is still present.

**OverPress Level [SET-40]:** Overpressure trigger level in PID feedback units, 0.0 to SET-20 (Unit) PID F/B Max.

### Underload Protection (Dry Well or Belt Loss)

Underload Detection (ULD) monitors motor current and frequency to protect against conditions such as a dry well, broken pump, or broken drive belt. When current reading is less than set value and speed is equal or greater than set value, the VFD will trip on ULD.

To enable this feature, adjust the following parameters:

**ULD Select [SET-41]:** Disable, Coast to stop, or Decel to stop.

**ULD Level [SET-42]:** Set as a percentage of motor FLA (SFA) (default = 45%). If all conditions are met, VFD will trip below this level.

## OPERATION

### Protection Features

---

**ULD Frequency [SET-43]:** If VFD runs at this frequency or greater, and current is less than [Set-42], ULD Delay timer [Set-44] will start.

**ULD Delay [SET-44]:** Delay range from 1 to 360 seconds (default = 2 sec). When timer expires, if current is still below [Set-42], and frequency is still above [Set-43], VFD will trip based on [Set-41].

**ULD Recovery Time [SET-45]:** 0 to 720 min (default = 30 min). If timer is set to value greater than 0 minutes, VFD will restart after timer expires. If set to 0 and the VFD trips, manual or remote reset is required (no auto retries).

For dry well protection, **Recovery Time** should be long enough to allow the well to be filled. If VFD trips the first time on Underload, it will restart after the Recovery timer expires. If VFD trips again, the timer value will be doubled. The VFD will continue restart attempts, doubling the timer value until it reaches 720 minutes (12 hours). Then every restart will be in 720 min. **ULD Recover Cnt [SET-46]** displays the countdown before the next restart attempt.

When VFD finally runs without tripping for 180 sec, the recovery timer will be reset to original setting and at next underload trip VFD will wait for well fill for original [Set-45] time value.

If the run command is removed, or HOA is set to OFF, the Underload feature is canceled and the [Set-45] timer is reset to its original setting.

### Broken Pipe Protection (for Pump Applications)

The VFD has the ability to detect a broken pipe in the system. The VFD must be running with PID Control in Auto mode for this feature to be active.

To enable this feature, adjust the following parameters:

**Broken Pipe Level [SET-36]:** 0.0 to PID F/B Max [Set-20]. Setting of 0.0 disables the feature. When pressure falls below this level and VFD continues to run above [Set-37], delay timer [SET-38] starts.

**Broken Pipe Freq [SET-37]:** PID Low Freq [Set-22] to PID High Freq [Set-23] (default = 59.5 Hz).

**Broken Pipe Delay [SET-38]:** 0.0 to 6000 seconds (default = 180 sec). If either of the first two conditions is removed, the timer will reset. If the timer expires with both conditions still active, the VFD will trip on Broken Pipe fault.

Manual or remote reset is required.

### No Flow Protection

The VFD can monitor a system flow switch to provide pump protection and more reliable sleep mode operation.

**Flow Switch Terminal [IO-21 through 28]:** Connect the flow switch to one of the Digital Inputs (MI1-8) and set the corresponding parameter to **37 Flow Switch**.

**No Flow Mode [IO-38]:** Disabled, Trip, or Sleep. Default = Disabled.

**No Flow Delay [IO-39]:** Duration motor runs above No Flow Freq until No Flow protection becomes active. Range from 1 to 6000 seconds. Default= 20 sec.

**No Flow Freq [IO-40]:** Range from PID/VFD Freq Low Limit to PID/VFD Freq High Limit. Default= 20.0Hz or 40Hz based on application.

When [IO-38] is set to **Trip** and the VFD runs at a frequency greater than [IO-40] longer than [IO-39] with the flow switch contact open, the VFD will trip on No Flow Fault. If the switch closes during the delay, the delay timer will be reset and will start again if the flow switch contact opens again.

When [IO-38] is set to **Sleep**, the flow switch will become an additional condition for sleep mode. When VFD runs with PID control and determines that all sleep mode conditions are met and the flow switch is open during Sleep delay, VFD will go into sleep mode.

## ADVANCED APPLICATION OPTIONS

### Multi-Motor Configurations

Several multi-motor configurations are available:

- Equal Run Time
- Soft Start Mode
- Lead-Lag
- Run Time Alt
- Rotate Lead

### Multi-Motor (MMC) Relay Control for Pump Applications

The multi-motor configuration for constant pressure systems provides control for up to 4 pump motors (8 with optional I/O board) in a Lead, Lag configuration.

The VFD controls speed of the Lead pump using its own PID feedback loop and the VFD motor output. If the Lead pump cannot maintain setpoint pressure, the VFD uses relay outputs to trigger Lag pumps through a starter, soft-starter, or another VFD. Relay output function [10-47, -48, or -49 etc.] should be set to 47\_MMC Out. The lowest number relay set to MMC will be Lag 1.

This feature does not provide an alternation or Lead pump replacement in case of pump or VFD failure.

To enable Lead, Lag Relay Control, set the following parameters:

**MMC Mode [ADV-10]:** Set to 3\_Lead-Lag.

**Lag Start Freq [ADV-18]:** When the lead pump runs above this frequency, it sets the first condition for starting a Lag pump. Range is Lag Stop Freq [ADV-23] to PID Hi Hz Limit [SET-23]. Default = 59.5 Hz.

**Lag Start Delay [ADV-19]:** Sets a delay time to start Lag pump when both frequency and pressure conditions are met. Default = 10 sec.

**Lag Start Level [ADV-20]:** Sets a percentage below PID F/B Max [SET-20] (pressure) to calculate MMC Below Setpoint as the second condition for starting a Lag pump. Range is 0.1 to 10%. Default = 2%.

$MMC\ Below\ Setpoint = [SET-21] - \{[SET-20] \times [ADV-20]/100\}$ .

**Lead Freq Drop [ADV-21]:** PID Hi Hz Limit [SET-23] drop value with [ADV-22] at Lag pump start to prevent system overpressure condition. Default = 10 Hz.

**MMC Decel Time [ADV-22]:** Sets the deceleration time for the [ADV-21] frequency drop. Default = 2 sec.

**Lag Stop Freq [ADV-23]:** When the Lead runs below this frequency, it sets the first condition for stopping Lag pumps. Default = 35 Hz.

**Lag Stop Delay [ADV-24]:** Sets a delay time to stop Lag pump when both frequency and pressure conditions are met. Default = 4 sec.

**Lag Stop Level [ADV-25]:** Sets a percentage above PID F/B Max [SET-20] (pressure) to calculate MMC At Setpoint as the second condition for stopping a Lag pump. Default = 0.3%.

$MMC\ At\ Setpoint = [SET-21] + \{[SET-20] \times [ADV-25]/100\}$ .

**Lead Freq Bump [ADV-26]:** PID Lo Hz Limit [SET-22] increase value with [ADV-27] at Lag pump stop to prevent system underpressure condition. Range is 0 to [SET-23]\*0.4. Default = 0 Hz.

**MMC Accel Time [ADV-27]:** Sets the acceleration time for the [ADV-26] frequency bump. Default = 2 sec.

**Lag Pump Start sequence:** If the Lead motor runs at a speed equal or greater than [ADV-18] with system pressure less than MMC Below Setpoint for [ADV-19] delay, the VFD will decrease PID High Freq Limit [SET-23] by [ADV-21] value for [ADV-22] time and then activate relay output to start the first Lag Pump in sequence. After a non-adjustable 1 sec delay, the VFD will change [SET-23] to its original value and check for Lag Start/Stop conditions. If demand is still high, the VFD will repeat Lag Start sequence for additional Lag pumps.

## ADVANCED APPLICATION OPTIONS

### Multi-Motor Configurations

---

**Lag Pump Stop sequence:** If the Lead motor runs at a speed equal or less than [ADV-23] with system pressure equal or greater than MMC At Setpoint for [ADV-24] delay, the VFD will increase PID Lo Hz Limit [SET-22] by [ADV-26] value for [ADV-27] time and then it will deactivate relay output to stop the first Lag Pump. After a non-adjustable 1 sec delay, the VFD will change [SET-22] to its original value and check for Lag Start/Stop conditions. If demand is still low, the VFD will repeat Lag Stop sequence for additional Lag pumps. If all Lag pumps are stopped, the VFD will check for Sleep Mode conditions.

If the VFD run command is removed during MMC operation, all Lag pump relays will deactivate in sequence with a 1 sec delay between each relay. The delay will protect from voltage surges in the power line when Lag pumps stop. The VFD will then stop the Lead based on the selected method (Decel or Coast).

If the VFD trips on a fault during MMC operation, the VFD will immediately deactivate all Lag pump relays and it will coast stop.



# **COMMUNICATIONS**

## **Modbus RTU Communication**

The VFD can be controlled and monitored through the Modbus RTU protocol over an RS-485 connection. Modbus follows a simple client-server model. Server devices perform data read/write requests which are issued from a client device such as a Programmable Logic Controller (PLC) or Building Management System (BMS). Assignable addresses for server devices range from an address of 1 to a theoretical maximum of 247.

As a server device, the VFD communicates all data using only 16-bit holding registers. Addressing for the registers is partitioned into blocks that are multiples of 100 to group functionally similar data. If the drive is configured to accept commands via remote communications, it can be commanded to start, stop, run at a specified output frequency, target a setpoint in PID control, and reset faults.

Modbus addresses can be found in the parameter tables throughout this publication.

## **BACnet-RTU Communication**

The VFD can be controlled and monitored through the BACnet MS/TP protocol over an RS-485 connection. The VFD operates as an MS/TP master device, for which the protocol can support addressing for up to 128 master devices in a single MS/TP network.

BACnet conveys control and monitoring data as a collection of BACnet objects. The VFD supports Analog Input, Analog Value, Positive Integer Value, Binary Input, Multi-State Value, and Character String object types. The Read Property and Write Property services can be used to interface to these objects. If the drive is configured to accept commands via remote communications, it can be commanded to start, stop, run at a specified output frequency, target a setpoint in PID control, and reset faults.

- **PLC Com Type [PLC-23]:** This should be set to **BACnet**.
- **BACnet MAC ID [COMM-24]:** This should be set to BACnet's MS/TP station number.
- **BACnet Speed [COMM-25]:** This should be set to the BACnet communication baud rate.
- **Device ID Lo [COMM-26]**
- **Device ID Hi [COMM-27]**
- **Max Address [COMM-28]**
- **Password [COMM-29]**

# MAINTENANCE

## Troubleshooting

### Diagnostic Fault Codes

Fault	Description	Corrective Action
Analog current input loss (ACE)	<ul style="list-style-type: none"> <li>• ACI loss</li> </ul>	<ul style="list-style-type: none"> <li>• Check the ACI wiring</li> <li>• Check if the ACI signal is less than 4mA</li> </ul>
Auto-tuning error (AUE)	<ul style="list-style-type: none"> <li>• Auto tuning error</li> </ul>	<ul style="list-style-type: none"> <li>• Check cabling between drive and motor</li> <li>• Check motor capacity and parameter setting</li> </ul>
Auto-tuning error 1 (no feedback current error) (AUE1)	<ul style="list-style-type: none"> <li>•</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Auto-tuning error 2 (motor phase loss error) (AUE2)	<ul style="list-style-type: none"> <li>•</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Auto-tuning error 3 (no-load current IO measuring error) (AUE3)	<ul style="list-style-type: none"> <li>•</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Auto-tuning error 4 (leakage inductance Lsigma measuring error) (AUE4)	<ul style="list-style-type: none"> <li>•</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Brake transistor error (bF)	<ul style="list-style-type: none"> <li>• Brake resistor fault</li> </ul>	<ul style="list-style-type: none"> <li>• If the fault code is still displayed on the keypad after pressing "RESET" key, please call technical support.</li> </ul>
CAN open software disconnect 2 (CHbE)	<ul style="list-style-type: none"> <li>• CANopen heartbeat error</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
CANopen hardware disconnect (CbFE)	<ul style="list-style-type: none"> <li>• CANopen bus off error</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
CANopen index setting error (CIdE)	<ul style="list-style-type: none"> <li>• CANopen index error</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
CANopen index setting exceed limit (CFrE)	<ul style="list-style-type: none"> <li>• CANopen memory error</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
CANopen slave station number setting error (CAeE)	<ul style="list-style-type: none"> <li>• CANopen station address error</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
CANopen software disconnect 1 (CGdE)	<ul style="list-style-type: none"> <li>• CANopen guarding error</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
CANopen synchronous error (CSyE)	<ul style="list-style-type: none"> <li>• CANopen synchronous error</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Capacitance over-heat (oH2)	<ul style="list-style-type: none"> <li>• Capacitance overheating temperature causes heatsink overheating.</li> </ul>	<ul style="list-style-type: none"> <li>• Ensure that the ambient temperature falls within the specified temperature range.</li> <li>• Make sure heat sink is not obstructed. Check if the fan is operating</li> <li>• Check if there is enough ventilation clearance for the drive.</li> </ul>
Channel 1 (STO1-SCM1) safety loop error (STL1)	<ul style="list-style-type: none"> <li>• STO1-SCM1 internal hardware detect error</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Channel 2 (STO2-SCM2) safety loop error (STL2)	<ul style="list-style-type: none"> <li>• STO2-SCM2 internal hardware detect error</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Clamp current detection error (Hd0)	<ul style="list-style-type: none"> <li>• CC (current clamp)</li> </ul>	<ul style="list-style-type: none"> <li>• Reboots the power. If fault code is still displayed on the keypad, please call technical support.</li> </ul>
Communication error (CE1)	<ul style="list-style-type: none"> <li>• Illegal function code</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Communication error (CE2)	<ul style="list-style-type: none"> <li>• Illegal data address (00H to 254H)</li> </ul>	<ul style="list-style-type: none"> <li>• Check if the communication address is correct</li> </ul>
Communication error (CE3)	<ul style="list-style-type: none"> <li>• Illegal data value</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Communication error (CE4)	<ul style="list-style-type: none"> <li>• Data is written to read-only address</li> </ul>	<ul style="list-style-type: none"> <li>• Check if the communication address is correct</li> </ul>
Communication time-out (CE10)	<ul style="list-style-type: none"> <li>• Modbus transmission time-out</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>

## MAINTENANCE

### Troubleshooting

Fault	Description	Corrective Action
CPU error	•	•
CPU instruction error (TRAP)	• CPU trap error	•
Deceleration energy backup error (dEb)	• When ADV2-28 is not disabled and power is off or momentarily off, VFD will display dEb during accel./decel. stop.	• Check if input power is stable
Drive over-load (oL)	• The VFD detects excessive drive output current.	• Check if the motor is overloaded.
Electromagnet switch error (ryF)	• Electric valve switch error when executing Soft Start. (Frame E and above.)	• Do not disconnect RST when drive is still operating.
Electronics thermal relay protection 1 (EoL1)	• Electronics thermal relay 1 protection	• Check the setting of electronics thermal relay (Prot-17).
Electronics thermal relay protection 2 (EoL2)	• Electronics thermal relay 2 protection	•
Emergency stop (EF1)	• Emergency stop	• When the multi-function input terminals MI1 to MI6 are set to emergency stop, the AC motor drive stops output U, V, W and the motor coasts to stop. • Press RESET after fault has been cleared.
External base block (bb)	• External Base Block	• When the external input terminal (B.B) is active, the AC motor drive output will be turned off. • Deactivate the external input terminal (B.B) to operate the AC motor drive again
External fault input (EF)	• External Fault	• Input EF (N.O.) on external terminal is closed to GND. Output U, V, W will be turned off. • Give RESET command after fault has been cleared.
External safety gate (SI)	• Emergency stop for external safety	•
FIRE mode output	• Fire mode	•
Firmware version error	• Software version error	•
Ground fault (GFF)	• Ground fault	• When one of the output terminals is grounded, short circuit current is more than 50% of AC motor drive rated current, the VFD power module may be damaged. • <b>NOTE:</b> The short circuit protection is provided for VFD protection, not for protecting the user. • Check the wiring connections between the VFD and motor for possible short circuits, also to ground. • Check whether the IGBT power module is damaged. • Check for possible poor insulation at the output.
ictE Internal communication over-time error (InerCOM)	• Internal communication time-out	•
IGBT over-heat (oHI)	• IGBT temperature exceeds protection level	• Ensure that the ambient temperature falls within the specified temperature range. • Make sure that the ventilation holes are not obstructed. • Remove any foreign objects from the heatsinks and check for possible dirty heat sink fans. • Check the fan and clean it. • Provide enough spacing for adequate ventilation.
IGBT short-circuit (occ)	• Short-circuit is detected between upper bridge and lower bridge of the IGBT module	• Please call technical support.

<b>Fault</b>	<b>Description</b>	<b>Corrective Action</b>
IGBT short-circuit detection error (Hd3)	<ul style="list-style-type: none"> <li>• Occ hardware error</li> </ul>	<ul style="list-style-type: none"> <li>• Reboots the power. If fault code is still displayed on the keypad, please call technical support.</li> </ul>
Inner PLC function is forced to stop	<ul style="list-style-type: none"> <li>• Internal PLC forced to stop</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Internal loop error (STL3)	<ul style="list-style-type: none"> <li>• STO1-SCM1 and STO2-SCM2 internal hardware detect error</li> </ul>	<ul style="list-style-type: none"> <li>•</li> </ul>
Low current (uC)	<ul style="list-style-type: none"> <li>• Low current detection</li> </ul>	<ul style="list-style-type: none"> <li>• Check SET-42, SET-44, SET-41.</li> </ul>
Low-voltage at stop (LvS)	<ul style="list-style-type: none"> <li>• DC BUS voltage is less than PROT-03 at stop</li> </ul>	<ul style="list-style-type: none"> <li>• Check if the input voltage is normal</li> <li>• Check for possible sudden load</li> <li>• Adjust setting of PROT-03</li> </ul>
Low-voltage during acceleration (LvA)	<ul style="list-style-type: none"> <li>• DC BUS voltage is less than PROT-03 during acceleration</li> </ul>	<ul style="list-style-type: none"> <li>• Check if the input voltage is normal</li> <li>• Check for possible sudden load</li> <li>• Adjust setting of PROT-03</li> </ul>
Low-voltage during constant speed (Lvn)	<ul style="list-style-type: none"> <li>• DC BUS voltage is less than PROT-03 in constant speed</li> </ul>	<ul style="list-style-type: none"> <li>• Check if the input voltage is normal</li> <li>• Check for possible sudden load</li> <li>• Adjust setting of PROT-03</li> </ul>
Low-voltage during deceleration (Lvd)	<ul style="list-style-type: none"> <li>• DC BUS voltage is less than PROT-03 during deceleration</li> </ul>	<ul style="list-style-type: none"> <li>• Check if the input voltage is normal</li> <li>• Check for possible sudden load</li> <li>• Adjust setting of PROT-03</li> </ul>
Memory read-out error (cF2)	<ul style="list-style-type: none"> <li>• Internal EEPROM can not be read.</li> </ul>	<ul style="list-style-type: none"> <li>• Press "RESET" key to the factory setting.</li> </ul>
Memory write-in error (cF1)	<ul style="list-style-type: none"> <li>• Internal EEPROM can not be programmed.</li> </ul>	<ul style="list-style-type: none"> <li>• Press "RESET" key to the factory setting.</li> </ul>
Motor overheat (oH3) (PTC / PT100)	<ul style="list-style-type: none"> <li>• The internal temperature of the VFD exceeds the setting of PROT-20 (PTC level) or PROT-31 (PT100 level 2).</li> </ul>	<ul style="list-style-type: none"> <li>• Make sure that the motor is not obstructed.</li> <li>• Ensure that the ambient temperature falls within the specified temperature range.</li> <li>• Change to a higher power motor.</li> </ul>
Over-current at stop (oCS)	<ul style="list-style-type: none"> <li>• Hardware failure in current detection</li> </ul>	<ul style="list-style-type: none"> <li>• Please call technical support.</li> </ul>
Over-current detection error (Hd1)	<ul style="list-style-type: none"> <li>• OC hardware error</li> </ul>	<ul style="list-style-type: none"> <li>• Reboots the power. If fault code is still displayed on the keypad, please call technical support.</li> </ul>
Over-current during acceleration (oCA)	<ul style="list-style-type: none"> <li>• Output current exceeds 2.4 rated current during acceleration.</li> </ul>	<ul style="list-style-type: none"> <li>• Short-circuit at motor output: Check for possible poor insulation at the output.</li> <li>• Acceleration Time too short: Increase the Acceleration Time.</li> <li>• VFD output power is too small for the application.</li> </ul>
Over-current during constant speed (ocn)	<ul style="list-style-type: none"> <li>• Output current exceeds 2.4 rated current during constant speed.</li> </ul>	<ul style="list-style-type: none"> <li>• Short-circuit at motor output: Check for possible poor insulation at the output.</li> <li>• Acceleration Time too short: Increase the Acceleration Time.</li> <li>• VFD output power is too small for the application.</li> </ul>
Over-current during deceleration (ocd)	<ul style="list-style-type: none"> <li>• Output current exceeds 2.4 rated current during deceleration.</li> </ul>	<ul style="list-style-type: none"> <li>• Short-circuit at motor output: Check for possible poor insulation at the output.</li> <li>• Acceleration Time too short: Increase the Acceleration Time.</li> <li>• VFD output power is too small for the application.</li> </ul>
Over-torque 1 (ot1)	<ul style="list-style-type: none"> <li>• Current exceeds detection criteria.</li> </ul>	<ul style="list-style-type: none"> <li>• Check whether the motor is overloaded.</li> <li>• Check whether motor rated current setting (SET-03) is suitable.</li> </ul>
Over-torque 2 (ot2)	<ul style="list-style-type: none"> <li>• Current exceeds detection criteria.</li> </ul>	<ul style="list-style-type: none"> <li>• Check whether the motor is overloaded.</li> <li>• Check whether motor rated current setting (SET-03) is suitable.</li> </ul>
Over-voltage at stop (ovS)	<ul style="list-style-type: none"> <li>• Hardware failure in voltage detection</li> </ul>	<ul style="list-style-type: none"> <li>• Check if the input voltage falls within the rated VFD input voltage range.</li> <li>• Check for possible voltage transients.</li> </ul>
Over-voltage detection error (Hd2)	<ul style="list-style-type: none"> <li>• OV hardware error</li> </ul>	<ul style="list-style-type: none"> <li>• Reboots the power. If fault code is still displayed on the keypad, please call technical support.</li> </ul>

## MAINTENANCE

### Troubleshooting

Fault	Description	Corrective Action
Over-voltage during acceleration (ovA)	<ul style="list-style-type: none"> <li>DC BUS over-voltage during acceleration (230V: 410VDC; 460V: 820VDC; 575V: 1116VDC; 690V: 1318VDC).</li> </ul>	<ul style="list-style-type: none"> <li>Check if the input voltage falls within the rated VFD input voltage range.</li> <li>Check for possible voltage transients.</li> <li>If DC BUS over-voltage is due to regenerative voltage, increase the acceleration time or add an optional brake resistor.</li> </ul>
Over-voltage during constant speed (ovn)	<ul style="list-style-type: none"> <li>DC BUS over-voltage at constant speed (230V: 410VDC; 460V: 820VDC; 575V: 1116VDC; 690V: 1318VDC).</li> </ul>	<ul style="list-style-type: none"> <li>Check if the input voltage falls within the rated VFD input voltage range.</li> <li>Check for possible voltage transients.</li> <li>If DC BUS over-voltage is due to regenerative voltage, please increase the Deceleration Time or add an optional brake resistor.</li> </ul>
Over-voltage during deceleration (ovd)	<ul style="list-style-type: none"> <li>DC BUS over-voltage at constant speed (230V: 410VDC; 460V: 820VDC; 575V: 1116VDC; 690V: 1318VDC).</li> </ul>	<ul style="list-style-type: none"> <li>Check if the input voltage falls within the rated VFD input voltage range.</li> <li>Check for possible voltage transients.</li> <li>If DC BUS over-voltage is due to regenerative voltage, please increase the Deceleration Time or add an optional brake resistor.</li> </ul>
Password error (Pcod)	<ul style="list-style-type: none"> <li>Password is locked.</li> </ul>	<ul style="list-style-type: none"> <li>Power off and restart the driver before entering the correct password</li> </ul>
Phase loss protection (OrP)	<ul style="list-style-type: none"> <li>Phase Loss</li> </ul>	<ul style="list-style-type: none"> <li>Check that all 3 input phases are connected without loose contacts.</li> <li>For models 40hp and above, please check if the AC input circuit fuse.</li> </ul>
PID feedback loss (AFE)	<ul style="list-style-type: none"> <li>PID loss (ACI)</li> </ul>	<ul style="list-style-type: none"> <li>Check the wiring of the PID feedback</li> <li>Check the PID parameters settings</li> </ul>
RoPd initial rotor position detection error	<ul style="list-style-type: none"> <li></li> </ul>	<ul style="list-style-type: none"> <li></li> </ul>
Safe torque off (STO)	<ul style="list-style-type: none"> <li>Safe Torque Off function active</li> </ul>	<ul style="list-style-type: none"> <li></li> </ul>
Slip error (oSL)	<ul style="list-style-type: none"> <li>Slip exceeds Motor-19 setting and time exceeds Motor-20 setting.</li> </ul>	<ul style="list-style-type: none"> <li>Check if motor parameter is correct (please decrease the load if overload)</li> <li>Check the settings of Motor-19 and Motor-20.</li> </ul>
TH1 open: IGBT over-heat protection error (th1o)	<ul style="list-style-type: none"> <li>IGBT Hardware Error</li> </ul>	<ul style="list-style-type: none"> <li>Please call technical support.</li> </ul>
TH2 open: capacitance over-heat protection error (th2o)	<ul style="list-style-type: none"> <li>Capacitor Hardware Error</li> </ul>	<ul style="list-style-type: none"> <li>Please call technical support.</li> </ul>
U phase output phase loss (OPHL)	<ul style="list-style-type: none"> <li>Output phase loss (Phase U)</li> </ul>	<ul style="list-style-type: none"> <li></li> </ul>
Uoc (U-phase output short-circuit)	<ul style="list-style-type: none"> <li>U phase short circuit</li> </ul>	<ul style="list-style-type: none"> <li></li> </ul>
U-phase current detection error (cd1)	<ul style="list-style-type: none"> <li>U-phase error</li> </ul>	<ul style="list-style-type: none"> <li>Reboots the power. If fault code is still displayed on the keypad, please call technical support.</li> </ul>
V phase output phase loss (OPHL)	<ul style="list-style-type: none"> <li>Output phase loss (Phase V)</li> </ul>	<ul style="list-style-type: none"> <li></li> </ul>
Voc (V-phase output short-circuit)	<ul style="list-style-type: none"> <li>V phase short circuit</li> </ul>	<ul style="list-style-type: none"> <li></li> </ul>
V-phase current detection error (cd2)	<ul style="list-style-type: none"> <li>V-phase error</li> </ul>	<ul style="list-style-type: none"> <li>Reboots the power. If fault code is still displayed on the keypad, please call technical support.</li> </ul>
W phase output phase loss (OPHL)	<ul style="list-style-type: none"> <li>Output phase loss (Phase W)</li> </ul>	<ul style="list-style-type: none"> <li></li> </ul>
Watchdog	<ul style="list-style-type: none"> <li></li> </ul>	<ul style="list-style-type: none"> <li></li> </ul>
Woc (W-phase output short-circuit)	<ul style="list-style-type: none"> <li>W phase short circuit</li> </ul>	<ul style="list-style-type: none"> <li></li> </ul>
W-phase current detection error (cd3)	<ul style="list-style-type: none"> <li>W-phase error</li> </ul>	<ul style="list-style-type: none"> <li>Reboots the power. If fault code is still displayed on the keypad, please call technical support.</li> </ul>
Y-connection / d-connection switch error (ydc)	<ul style="list-style-type: none"> <li>Y-connection/<math>\Delta</math>-connection switch error</li> </ul>	<ul style="list-style-type: none"> <li>Check the wiring of the Y-connection/<math>\Delta</math>-connection</li> </ul>

## Fan Replacement


### **⚠ WARNING**



**Risk of bodily injury or damage to drive or other equipment. Contact with hazardous voltage could result in death or serious injury.**


- Disconnect and lock out all power before installing or servicing equipment.
- Do not attempt to replace fans until power has been removed and 10 minutes have passed to allow internal voltage to discharge.
- Fans cannot be replaced with power applied. Damage to VFD may occur.

### Frame A Heat Sink Fan



1. Press the tabs on both sides of the fan to release and slide out the fan.
2. Disconnect the power connector before completely removing the fan.

### Frame B Heat Sink Fan




1. Press the tabs on both sides of the fan to release and slide out the fan.
2. Disconnect the power connector before completely removing the fan.

## MAINTENANCE


### Fan Replacement

#### Frame B and C Capacitor Fan



1. Disconnect fan power connector.
2. Lift the fan out using a flathead screwdriver.

#### Frame C Heat Sink Fan




Some Frame C models use one fan and some use two.

1. Before removing fans, remove the cover using a flathead screwdriver.
2. Disconnect fan power connectors.
3. Remove screws and remove fans. When replacing screws, tighten to a torque of 8.67 to 10.4 in. lbs. (0.98 to 1.18 Nm).
4. When installing new fans, make sure label faces the inside of the drive.




## Frame D Heat Sink Fan




1. Remove four screws to release and slide out the fan assembly. When replacing screws, tighten to a torque of 20.8 to 22.1 in. lbs. (2.35 to 2.5 Nm).
2. Disconnect the power connectors before completely removing the fan.

## Frame D Capacitor Fan



1. Remove two screws and press the tabs on both sides to remove the lower cover. When replacing screws, tighten to a torque of 10.4 to 13 in. lbs. (1.18 to 1.47 Nm).
2. Press the top of the keypad and remove the keypad.
3. Remove two screws and press the tabs on both sides to remove the upper cover. When replacing screws, tighten to a torque of 5.2 to 6.9 in. lbs. (0.59 to 0.78 Nm).
4. Disconnect fan power connector.
5. Remove one screw and pull out the fan. When replacing the screw, tighten to a torque of 8.9 to 10.4 in. lbs. (1.0 to 1.18 Nm).


## **Frame E Heat Sink Fan**



Frame E models use multiple heat sink fan styles. Be sure to order the correct part when replacing the fan.


1. Remove four screws to release and slide out the fan assembly. When replacing screws, tighten to a torque of 20.8 to 22.1 in. lbs. (2.35 to 2.5 Nm).
2. Disconnect the power connectors before completely removing the fan.

## **Frame E Capacitor Fan**




1. Remove four screws to release and slide out the fan assembly. When replacing screws, tighten to a torque of 20.8 to 22.1 in. lbs. (2.35 to 2.5 Nm).
2. Disconnect the power connectors before completely removing the fan.

## Frame F Heat Sink Fan




1. Remove four screws to release and slide out the fan assembly. When replacing screws, tighten to a torque of 10.4 to 13 in. lbs. (1.18 to 1.47 Nm).
2. Disconnect the power connectors before completely removing the fan.

## Frame F Capacitor Fan




1. Remove four screws and remove the lower cover. When replacing screws, tighten to a torque of 10.4 to 13 in. lbs. (1.18 to 1.47 Nm).
2. Remove four screws and remove the upper cover. When replacing screws, tighten to a torque of 20.8 to 22.1 in. lbs. (2.35 to 2.5 Nm).
3. Disconnect fan power connector and remove three screws. When replacing the screw, tighten to a torque of 20.8 to 22.1 in. lbs. (2.35 to 2.5 Nm).
4. Pull out the fan.

**Frame G Heat Sink Fan**



1. Remove four screws and remove the lower cover. When replacing screws, tighten to a torque of 10.4 to 13 in. lbs. (1.18 to 1.47 Nm).
2. Remove eight screws from the top cover. When replacing screws, tighten to a torque of 30 to 34.5 in. lbs. (3.4 to 3.9 Nm).
3. Remove two screws from the bottom of the upper front cover. When replacing screws, tighten to a torque of 12 to 14 in. lbs. (1.37 to 1.57 Nm).  
Remove upper front cover.
4. Release clip and disconnect fan power connector.
5. Remove three screws from fan. When replacing the screws, tighten to a torque of 12 to 14 in. lbs. (1.37 to 1.57 Nm).
6. Remove protective covers and pull out the fan by placing fingers through the lifting holes.

## Frame H Heat Sink Fan



1. Remove four screws and remove the lower front cover. When replacing screws, tighten to a torque of 12 to 14 in. lbs. (1.37 to 1.57 Nm).
2. Remove eight screws and remove the upper front cover. When replacing screws, tighten to a torque of 20.8 to 22.1 in. lbs. (2.35 to 2.5 Nm).
3. Disconnect two fan power connectors.
4. Remove three screws from each fan and pull out the fans. When replacing the screws, tighten to a torque of 20.8 to 22.1 in. lbs. (2.35 to 2.5 Nm).



# PARAMETER REFERENCE TABLES

## Parameter Descriptions > SET Menu

AR = Adjustable while Running.

CODE	AR	Display Name	Range	Description
SET-00	N	Application Sel	0_Basic 1_Supply Fan 2_Exhaust Fan 3_Cooling Tower 4_Centrifugal Pump 5_Submersible Pump 6_Vacuum Pump 7_Constant Torque Motor	Mechanical application the VFD is running. Must be set when powered up the first time. Selection automatically adjusts many default parameters to common values for the application. Additional adjustments may be required for optimum performance. Refer to the application descriptions in <a href="#">“Automated Control Features” on page 60</a> for more information. <b>Important:</b> Whenever the application is changed, many default parameters are changed. Be sure to verify settings to ensure proper operation. Refer to the Default Settings tables in <a href="#">“Default Settings Tables” on page 45</a> .
SET-01	N	Input Phase	0_3-Phase	The VFD is capable of using 3-Phase input power.
SET-02	N	Motor HP	0.5-655 HP	Default is set based on VFD rating. User should enter the rated motor HP, found on the motor nameplate.
SET-03	N	Motor FLA/SFA	1/10 of max capacity~999.9A	Default is set based on VFD rating. User should enter the rated motor FLA, found on the motor nameplate. If [SET-00] is set to Submersible, enter the SFA rating from the motor nameplate. All internal overload protection features for the VFD and motor are calculated based on the value in this parameter.
SET-04	N	Motor RPM	0-3600 RPM	Rated Motor RPM from motor nameplate when running at nameplate frequency.
SET-05	N	Motor Voltage	230V: 0 to 255 V 460V: 0 to 510 V 575V: 0 to 637 V 690V: 0 to 720 V	Rated voltage of the motor, found on the motor nameplate. The VFD can produce output voltage equal to or less than input power voltage.
SET-06	Y	Carrier Freq	2.0 to 15.0 kHz Varies by VFD rating	VFD switching frequency. Higher frequencies create more precise wave forms, but generate higher heat. Lower frequencies run cooler, but could potentially cause audible noise, which can be eliminated by adjusting this carrier frequency during stop or run mode.
SET-07	N	Auto Speed Ref	0_Keypad 1_Up/Down DI 2_AV11 Analog Input 3_ACI Analog Input 4_AV12 Analog 5_RS485 Serial 6_Com Card 7_PID Output	Source of speed reference when in Auto mode. Keypad input. Digital Input when DI terminal [IO-21-28] set to Up and Down. Analog input from BMS, PLC, Potentiometer or other control device. RS-485 Interface Communications card control. PID output. When PID mode is selected, additional parameters must be verified for setpoints, inputs, and limits.
SET-08	N	Auto Run Cmd	0_Keypad 1_Digital Input 2_RS485 Serial 3_Com Card 4_Ext HOA in Auto	Source of Run Command in Auto mode. Keypad: Run command from Start/Stop button. Digital Input: Run command from digital input [IO-21-28] set to FWD or REV. If direction is set here, then dedicated FWD input is disabled. Keypad STOP is disabled. RS485 Serial: Run command from RS485 interface. Keypad STOP is disabled. Com Card: Run command from communications card. This does not include CANopen card. Ext HOA in Auto: Run command from digital input [IO-21-28] set to HOA AUTO (when HOA is in Auto position).
SET-09	N	Hand Speed Ref	0_Keypad 1_RS485 Serial 2_AV11 Analog 3_ACI Analog 4_AV12 Analog 5_Com Card	Source of speed reference when in Hand mode. Keypad input. RS-485 Interface Analog input from BMS, PLC, Potentiometer or other control device. Communications card control. When in Hand mode, PID is disabled.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > SET Menu**

CODE	AR	Display Name	Range	Description
SET-10	N	Hand Run Cmd	0_Keypad 1_Digital Input 2_RS485 Serial 3_Com Card 4_Ext HOA in Hand	Source of Run Command in Hand mode. Keypad: Run command from Start/Stop button. Digital Input: Run command from digital input [IO-21-28] set to FWD or REV. If direction is set here, then dedicated FWD input is disabled. Keypad STOP is disabled. RS485 Serial: Run command from RS485 interface. Keypad STOP is disabled. Com Card: Run command from communications card. This does not include CANopen card. Ext HOA in Hand: Run command from digital input [IO-21-28] set to HOA HAND (when HOA is in Hand position).
SET-11	Y	Accel Time	0 to 600 Sec	Time in seconds for the drive to accelerate from 0 Hz to maximum frequency. Default depends on Application [SET-00] and VFD HP rating.
SET-12	Y	Decel Time	0 to 600 Sec	When Stop Mode is set to Decelerate, time in seconds to slow down from maximum frequency to 0 Hz. Default depends on Application [SET-00] and VFD HP rating.
SET-13	Y	Low Freq Limit	0.0 to SET-14 (Hz)	The lowest frequency (speed) allowable. If speed control falls below setting, motor will continue to run at this limit.
SET-14	N	High Freq Limit	SET-13 to VFD-00 (Hz)	The highest frequency (speed) allowable. If speed control signal goes higher, motor will continue to run at this limit.
SET-15	N	Load Rotation	0_FWD & REV 1_FWD Only 2_REV Only	Allows the motor to run in the forward and reverse direction. Setting it to a specific direction prevents injury or damage to equipment.
SET-16	N	Stop Mode	0_Decel to stop 1_Coast to stop	Determines how the motor is stopped when a STOP command is initiated. Decel to stop: VFD decelerates frequency to minimum output frequency and then stops. Coast to stop: VFD stops the output instantly and motor free runs until it comes to a complete standstill.
SET-17	N	PID Mode	0_Disable 1_PID Direct 2_PID Inverse	PID control allows the VFD to maintain a process value (pressure, temperature etc.) by varying the output frequency based on the difference between a set point and actual feedback value. Direct: Output decreases as feedback increases. Inverted: Output increases as feedback increases.
SET-18	N	PID F/B Source	0_ACI 1_AV11 2_AV12	Selects an analog input terminal for PID Feedback source.
SET-19	N	PID F/B Unit	0_PSI 1_inWC 2_Feet 3_°F 4_CFM 5_GPM 6_% 7_Cust 8_inHg 9_m 10_mBar 11_Bar 12_kPa 13_°C 14_LPM 15_CMH	Measurement unit selection for feedback signal.
SET-20	N	PID F/B Max	0.0 to (variable) (Unit)	PID Sensor (Transducer) maximum rating based on transducer range.
SET-21	Y	PID Setpoint	0.0 to SET-20 (Unit)	Set the desired value for PID (pressure, temperature, GPM, etc.).
SET-22	Y	PID Lo Hz Limit	SET-13 to SET-23 (Hz)	Low frequency limit in PID mode. PID Low Frequency is limited by Low Frequency [SET-13] and PID High Frequency [SET-23].
SET-23	N	PID Hi Hz Limit	SET-22 to VFD-00 (Hz)	High frequency limit in PID mode. PID High Frequency is limited by High Frequency [SET-14] and PID Low Frequency [SET-22].



**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > SET Menu**


CODE	AR	Display Name	Range	Description
SET-24	Y	PID P-Gain	0 to 100%	Proportional-Gain determines PID control sensitivity. Greater values provide more sensitivity. However, if set too high, the system may create an output frequency oscillation and instability. Used along with PID I-Time [SET-25] to smooth and balance system response.
SET-25	Y	PID I-Time	0.0 to 100 Sec	Integral-Time determines PID response time. Lower values increase system response to the feedback signal, which reduces overshoot, but may cause system oscillation if set too low. Greater values provide slower response, which may cause overshoot of the setpoint and oscillation of output frequency.
SET-26	Y	Sleep Mode	0_Disabled 1_Sleep Only 2_Sleep + Boost	Sleep Mode selection for pressure controlled systems, such as pumping applications. Sleep+Boost increases the process control value (pressure) before going to sleep.
SET-27	Y	Sleep Check Time	5 to 120 Sec	Time delay (sleep check cycle time) before each Sleep Check process.
SET-28	Y	Sleep Delay	0 to 3000 sec	Delay before VFD triggers Sleep Mode state when all other conditions are met.
SET-29	Y	Sleep Boost Value	0 to 10%	Value added to original setpoint to provide a pressure boost before entering sleep.
SET-30	Y	Sleep Boost Timer	5 to 120 Sec	Limits duration of sleep boost operation if Sleep Boost set-point is not reached.
SET-31	Y	Wake-Up Level	0.0 to SET-21	Sets a wakeup level for VFD to quit Sleep mode and start running.
SET-32	Y	Sleep Bump Timer	5 to 120 Sec	Sets a duration time for pressure bump to increase system pressure.
SET-33	Y	Pipe Fill Timer	0.0 to 60 Min	Pipe Fill mode exit timer to switch to PID mode. If set to 0.0 min, pipe fill is disabled.
SET-34	Y	P-Fill Exit Lvl	0.0 to SET-21 (PSI)	Pipe Fill mode exit level to switch to PID mode.
SET-35	Y	Pipe Fill Freq	SET-22 to SET-23	Pipe Fill mode high frequency limit setting.
SET-36	Y	Broken Pipe Lvl	0.0 to SET-21 (PSI)	Pressure setting that starts Broken Pipe timer before VFD trips on Broken Pipe fault.
SET-37	Y	Broken Pipe Frq	SET-22 to SET-23	If VFD is running above this speed with pressure below [SET-36], Broken Pipe Delay timer starts.
SET-38	Y	Broken Pipe Dly	0 to 6000 Sec	If Broken Pipe Delay timer runs longer than this setting, VFD trips on Broken Pipe fault.
SET-39	Y	OverPress Set	0_Disabled 1_OP Trip 2-OP Auto Reset	Overpressure set OP Trip: Trip requires manual reset OP Auto Reset: Auto Restart occurs when pressure drops 5% below PID setpoint.
SET-40	Y	OverPress Level	0.0 to SET-20 (Unit)	Level the process signal (pressure) reaches to cause an overpressure condition.
SET-41	N	ULD Select	0_Disabled 1_Coast to stop 2_Decel to stop	Underload Detection protects against conditions such as a dry well, broken pump, or broken drive belt.
SET-42	Y	ULD Level	15 to 115%	Underload Level set as a percentage of FLA(SFA). If current is below this level and frequency is above ULD Frequency [SET-43] for longer than ULD Delay [SET-44] timer, VFD will trip on ULD.
SET-43	Y	ULD Frequency	0.0 to SET-22 (Hz)	If motor runs above ULD Frequency, VFD compares operating current with ULD Level [Set-42] to test for ULD condition.
SET-44	Y	ULD Delay	0 to 360 Sec	Underload Delay timer before trip.
SET-45	Y	ULD Recovery T	0 to 720 Min	Underload Recovery Time. VFD will restart from ULD trip after this time. If it trips again, time will be doubled up to 720 min. If set to 0, fault must be manually reset.
SET-46	N	ULD Recover Cnt	0 to 720 Min	Decrementing counter of recovery time from an ULD trip before VFD attempts to restart motor (Read Only).
SET-47	N	HLD Select	0_Disabled 1_Coast to stop 2_Decel to stop	High Load Detection protects the VFD and motor against damage from an over-current condition.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > SET Menu**


CODE	AR	Display Name	Range	Description
SET-48	Y	HLD Level	75 to 200%	High Load Detection level, set as a percentage of FLA(SFA). If current is above this level and frequency is above HLD Frequency [Set-49] for longer than HLD Delay [Set-50] timer, VFD will trip on HLD.
SET-49	Y	HLD Frequency	0.0 to SET-23 (Hz)	If motor runs above HLD Frequency, VFD compares operating current with HLD Level [Set-48] to test for HLD condition.
SET-50	Y	HLD Delay	0 to 360 Sec	High Load Delay timer before trip.
SET-51	Y	HLD Recovery T	0 to 720 Min	High Load Recovery Time. VFD will restart from HLD trip after this time. If it immediately trips again, time will be doubled up to 720 min. If set to 0, fault must be manually reset.
SET-52	Y	HLD Recover Cnt	0 to 720 Min	Decrementing counter of recovery time from a HLD trip before VFD attempts to restart motor (Read Only).
SET-53	Y	ACC Change Freq	(Variable)	Frequency to switch from first accel/decel rate to second accel/decel rate.
SET-54	Y	Second ACC	0 to 600 Sec	Time in seconds for drive to accelerate from 0 Hz to maximum frequency. Second acceleration occurs when frequency is above ACC Change Freq [SET-53]. For example, submersibles have to be accelerated up to 30hz in 1 second but they can accelerate from 30hz to 60hz much slower. So, we would adjust Set-53 to 30hz and the drive would follow the Set-11 ACC time up to 30hz and the Set-54 ACC time above 30hz.
SET-55	Y	Second DEC	0 to 600 Sec	When Stop Mode is set to Decelerate, time in seconds to slow down from maximum frequency to 0 Hz. Second deceleration occurs when frequency is above ACC Change Freq [SET-53]. VFD returns to main DEC time when frequency is below [Set-53]-[Set-56]
SET-56	Y	ACC/DEC Hyster	0.0 to SET-53 (Hz)	Hysteresis added to ACC Change Freq [SET-53] in changing the deceleration rate. When frequency is decreasing across ACC Change Freq [SET-53], the frequency has to reach ACC Change Freq [SET-53] - ACC/DEC Hyster [SET-56] to use first ACC/DEC [SET-11-12].
SET-57	Y	User Defined	0_ Output Current (A) 1_ Counter Value (c) 2_ Output Freq (H) 3_ DC-Bus Voltage (u) 4_ Output Voltage (E) 5_ Output Power (P) 6_ Motor Speed (r) 7_ PID Feedback (b) 8_ AV11 Value (I) 9_ ACI Value (2) 10_ AVI2 Value (3) 11_ IGBT Temp °C (i) 12_ CAP Temp °C (c) 13_ D-Input Status (i) 14_ D-Out Status (o) 15_ Ground Flt Lvl (G) 16_ DC Bus Ripple (r) 17_ PLC Data D1043 (C) 18_ Fan Speed (F) 19_ VFD Status (6) 20_ kWh Display (J) 21_ PID Setpoint (L)	Sets the parameter to display on third line of keypad (display alias).
SET-58	Y	PLC Menu	0_Disable 1_Enable	Allows access to the PLC group of parameters.
SET-59	Y	ADV2 Menu	0_Disable 2_Enable	Allows access to the ADV2 group of parameters.
SET-60	Y	HOA Mode	0_Keypad 1_Digital Input 2_RS485 Serial 3_Com Card	Sets the input that selects between Hand-Off-Auto.

## Parameter Descriptions > VFD Menu

AR = Adjustable while Running.

CODE	AR	Display Name	Range	Description
VFD-00	N	VFD Max Freq	VFD-01 to 599 Hz up to 60HP VFD-01 to 400 Hz over 60HP	The highest frequency (speed) allowable when running a motor in non-PID mode. If speed control signal goes higher, motor will not exceed this limit.
VFD-01	N	VFD Start Freq	0-10 Hz	Frequency the VFD initially starts to output. When start frequency is higher than the minimum output frequency, VFD's output will be from start frequency to the setting frequency.
VFD-02	N	VFD Base Freq	VFD-01 to VFD-00 (Hz)	Set to the motor nameplate frequency rating. VFD provides full output voltage at this frequency. 
VFD-03	N	V/F Pattern	0_Linear 1_1.5 Power 2_Squared 3_V/F Curve 1 4_V/F Curve 2 5_V/F Curve 3 6_V/F Curve 4 7_V/F Curve 5 8_V/F Curve 6 9_V/F Curve 7 10_V/F Curve 8 11_V/F Curve 9 12_V/F Curve 10 13_V/F Curve 11 14_V/F Curve 12 15_V/F Curve 13	V/F curve can be selected from 15 kinds of default settings. 0_Linear pattern maintains a linear V/Hz ratio for constant torque applications. 2_Squared pattern maintains a squared V/Hz pattern, ideal for fan or pump applications.
VFD-04	Y	Step Freq-1	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-05	Y	Step Freq-2	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-06	Y	Step Freq-3	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-07	Y	Step Freq-4	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-08	Y	Step Freq-5	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-09	Y	Step Freq-6	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-10	Y	Step Freq-7	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-11	Y	Step Freq-8	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-12	Y	Step Freq-9	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-13	Y	Step Freq-10	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-14	Y	Step Freq-11	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-15	Y	Step Freq-12	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-16	Y	Step Freq-13	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-17	Y	Step Freq-14	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-18	Y	Step Freq-15	0.0 to 600 Hz	Command frequency determined by Multi-function Input Terminals.
VFD-19	Y	ACC-2 Time	0.0 to 600 Sec	Alternate acceleration rate for use with automated Acc/Dec type [ADV-06].
VFD-20	Y	DEC-2 Time	0.0 to 600 Sec	Alternate deceleration rate for use with automated Acc/Dec type [ADV-06].
VFD-21	Y	ACC-3 Time	0.0 to 600 Sec	Alternate acceleration rate for use with automated Acc/Dec type [ADV-06].
VFD-22	Y	DEC-3 Time	0.0 to 600 Sec	Alternate deceleration rate for use with automated Acc/Dec type [ADV-06].
VFD-23	Y	ACC-4 Time	0.0 to 600 Sec	Alternate acceleration rate for use with automated Acc/Dec type [ADV-06].
VFD-24	Y	DEC-4 Time	0.0 to 600 Sec	Alternate deceleration rate for use with automated Acc/Dec type [ADV-06].

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > VFD Menu**

CODE	AR	Display Name	Range	Description
VFD-25	Y	S Start Time 1	0.0 to (variable) Sec	S-curve acceleration time leaving initial frequency.
VFD-26	Y	S Start Time 2	0.0 to (variable) Sec	S-curve acceleration time approaching next frequency.
VFD-27	Y	S End Time 1	0.0 to (variable) Sec	S-curve deceleration time leaving initial frequency.
VFD-28	Y	S End Time 2	0.0 to (variable) Sec	S-curve deceleration time approaching next frequency.
VFD-29	N	Skip Freq 1 High	0.0 to 600 Hz	Used to bypass mechanical system resonance frequencies. If the received speed reference is in the skip zone, VFD will run at Low Skip Freq until speed reference is at or above High Skip Freq. Then, speed will be ramped up based on acceleration time. 
VFD-30	N	Skip Freq 1 Low	0.0 to 600 Hz	Low frequency in skip zone 1.
VFD-31	N	Skip Freq 2 High	0.0 to 600 Hz	High frequency in skip zone 2.
VFD-32	N	Skip Freq 2 Low	0.0 to 600 Hz	Low frequency in skip zone 2.
VFD-33	N	Skip Freq 3 High	0.0 to 600 Hz	High frequency in skip zone 3.
VFD-34	N	Skip Freq 3 Low	0.0 to 600 Hz	Low frequency in skip zone 3.
VFD-35	N	VFD Duty Select	0_Variable Torque 1_Constant Torque	0_Variable Torque (Light Duty) 01_Constant Torque (Normal Duty) VFD Rated Amps [VFD-47] and Over-Current levels [PROT-07-08] are affected by this setting.
VFD-36	Y	Reset Restart	0_Disable 1_Enable	The VFD will automatically initiate operation once fault is cleared and run command is received.
VFD-37	Y	DC Brake Lvl	0.0 to 100%	Level of DC Brake Current output to the motor during start-up and stopping.
VFD-38	Y	DC Time at Run	0.0 to 60 Sec	Duration of the DC Brake current after a run command to apply DC current to motor to force stop motor for a stable start.
VFD-39	Y	DC Time at Stop	0.0 to 60 Sec	Duration of the DC Brake current after a stop command to apply DC current to the motor in order to force stop the motor.
VFD-40	Y	DC Stop Freq	0.0 to 599 Hz	Frequency when DC Brake will begin during deceleration.
VFD-41	Y	Dwell T at Acc	0.0 to 600 Sec	When increasing in frequency to Dwell Frequency at Accel, the duration to then hold at frequency before continuing to increase frequency.
VFD-42	Y	Dwell Hz at Acc	0.0 to 599 Hz	Frequency to hold when increasing in frequency.
VFD-43	Y	Dwell T at Dec	0.0 to 600 Sec	When decreasing in frequency to Dwell Frequency at Decel, the duration to then hold at frequency before continuing to decrease frequency.
VFD-44	Y	Dwell Hz at Dec	0.0 to 599 Hz	Frequency to hold when decreasing in frequency.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > VFD Menu**

CODE	AR	Display Name	Range	Description
VFD-46	N	ID Code	4_1 HP (0.75 kW), 230 V 5_1 HP (0.75 kW), 460V 6_2 HP (1.5 kW), 230V 7_2 HP (1.5 kW), 460V 8_3 HP (2.2 kW), 230V 9_3HP (2.2 kW), 460V 10_5 HP (3.7 kW), 230V 11_5 HP (3.7 kW), 460V 12_7.5 HP (5.5 kW), 230V 13_7.5 HP (5.5 kW), 460V 14_10 HP (7.5 kW), 230V 15_10 HP (7.5 kW), 460V 16_15 HP (11 kW), 230V 17_15 HP (11 kW), 460V 18_20 HP (15 kW), 230V 19_20 HP (15 kW), 460V 20_25 HP (18.5 kW), 230V 21_25 HP (18.5 kW), 460V 22_30 HP (22 kW), 230V 23_30 HP (22 kW), 460V 24_40 HP (30 kW), 230V 25_40 HP (30 kW), 460V 26_50 HP (37 kW), 230V 27_50 HP (37 kW), 460V 28_60 HP (45 kW), 230V 29_60 HP (45 kW), 460V 30_75 HP (55 kW), 230V 31_75 HP (55 kW), 230V 32_100 HP (75 kW), 230V 33_100 HP (75 kW), 460V 34_125 HP (90 kW), 230V 35_125 HP (90 kW), 460V 37_150 HP (110 kW), 460V 39_175 HP (132 kW), 460V 41_215 HP (160 kW), 460V 43_250 HP (185 kW), 460V 45_300 HP (220 kW), 460V 47_375 HP (280 kW), 460V 49_425 HP (315 kW), 460V 51_475 HP (355 kW), 460V 53_536 HP (400 kW), 460V 90_4 HP (3.0 kW), 230V 91_4 HP (3.0 kW), 460V 93_5.5 HP (4.0 kW), 460V	Displays the identity code of the VFD (Read Only).
VFD-47	N	VFD Rated Amps	(Variable)	Current rating of drive with respect to Light Duty and Normal Duty [VFD-35] (Read Only).
VFD-48	Y	Display Select	0_Freq Command 1_Output Frequency 2_Multi-Fn Display 3_Output Current	Sets the parameter that appears on second line of display.
VFD-49	N	Firmware Version	(Variable)	VFD software version (Read Only).
VFD-50	Y	Disp Filter A	0.001 to 65.535 Sec	Minimizes the current fluctuation displayed by digital keypad.
VFD-51	Y	Disp Filter KPD	0.001 to 65.535 Sec	Minimizes the display value fluctuation displayed by digital keypad.
VFD-52	N	FW Date	(Variable)	VFD software version date (Read Only).
VFD-53	Y	Jog Accel Time	0.0 to (variable) Sec	Acceleration time in jog operation to increase frequency to jog frequency.
VFD-54	Y	Jog Decel Time	0.0 to (variable) Sec	Deceleration time in jog operation to decrease frequency to 0Hz.
VFD-55	Y	JOG Frequency	0.0 to 600 Hz	Frequency commanded for jog operation.
VFD-56	N	Zero-speed Mode	0_Standby 1_Hold by DC Brake 2_Min Frequency	When commanded frequency is less than frequency min: Standby: VFD stays at 0Hz. Hold by DC Brake: apply DC Brake by minimum voltage Frequency Min: VFD runs motor at minimum frequency.
VFD-57	Y	Power-on Start	0_Disable 1_Enable	When enabled, the VFD will automatically initiate operation after powered-on with run command.

## Parameter Descriptions > I/O Menu


AR = Adjustable while running.

CODE	AR	Display Name	Range	Description
IO-00	N	ACI Input Sel	0_0-10V 1_0-20mA 2_4-20mA 3_PTC 4_PT100	Selects the format of the input signal expected at the ACI input terminals based on the type of control device to be connected—transducer, sensor, controller, etc. This setting must correspond with ACI micro switch.
IO-01	N	ACI Loss Trip	0_Disable 1_Hold Speed 2_Decel Stop 3_Trip Stop	Selects operation when ACI signal is lost.
IO-04	Y	ACI Filter T	0 to 20 Sec	ACI time filter for noisy analog signal.
IO-05	N	AVI1 Input Sel	0_0-10V 1_0-20mA 2_4-20mA 3_PTC 4_PT100	Selects the format of the input signal expected at the ACI input terminals based on the type of control device to be connected—transducer, sensor, controller, etc. This setting must correspond with AVI1 micro switch.
IO-09	Y	AVI1 Filter T	0 to 20 Sec	AVI1 time filter for noisy analog signal. The delay time helps buffer interference that could cause error in the signal input. Longer times improve signal confirmation, but the response time is delayed.
IO-10	Y	AVI2 Filter T	0 to 20 Sec	AVI2 time filter for noisy analog signal. The delay time helps buffer interference that could cause error in the signal input. Longer times improve signal confirmation, but the response time is delayed.
IO-11	Y	PID Filter Time	0.1 to 300 Sec	PID feedback signal time filter for noisy analog signal. The delay time helps buffer interference that could cause error in the signal input. Longer times improve signal confirmation, but the response time is delayed.
IO-12	Y	PID Delay Time	0 to 35 Sec	Time delay for frequency command.
IO-13	Y	AI Upper Level	-100 to 100%	High level limit of analog input.
IO-14	Y	AI Lower Level	-100 to 100%	Low level limit of analog input.
IO-20	Y	DI Filter	0 to 30 Sec	Response time of digital input terminals MI1-MI8. The delay time helps buffer interference that could cause error in the signal input. Longer times improve signal confirmation, but the response time is delayed.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > I/O Menu**

CODE	AR	Display Name	Range	Description
IO-21	Y	MI1 Define	0_No Function 1_Speed-L 2_Speed-M 3_Speed-H 4_Speed-X 5_Fault Reset 6_Jog Speed 7_Hold Speed 8_XCEL-L 9_XCEL-M 10_Ext. Trip 12_AV11 Analog Spd 13_ACI Analog Spd 14_AV12 Analog Spd 16_Digital Up 17_Digital Down 18_PID Disable 19_CLR CNT 20_Input CNT (MI6) 21_FWD Jog 22_REV Jog 25_E-Stop 26_HOA HAND 27_HOA AUTO 28_Drive Enabled 29_PLC mode bit 0 30_PLC mode bit 1 32_FO with RUN Cmd 33_FO w/o RUN Cmd 34_Damper Limit Sw 35_Shutdown N-Latch 36_Shutdown Latched 37_Flow Switch 40_Aux Motor-1 OFF 41_Aux Motor-2 OFF 42_Aux Motor-3 OFF 43_Aux Motor-4 OFF 44_Aux Motor-5 OFF 45_Aux Motor-6 OFF 46_Aux Motor-7 OFF 47_All Aux Mtr Off 48_S-Point-A 49_S-Point-B	MI1 Default = Speed-L 1_Multi-step speed command 1 2_Multi-step speed command 2 3_Multi-step speed command 3 4_Multi-step speed command 4 5_Use to reset fault after cause is corrected 6_Changes speed in jog mode to value set in VFD-55 7_When active, VFD will hold current speed 8_ACC/DEC time will be changed to VFD-19 and VFD-20 9_ACC/DEC time will be changed to VFD-21 and VFD-22 10_Trips VFD by external protective device and requires reset 12_In non-PID mode, changes speed reference to AV11 13_In non-PID mode, changes speed reference to ACI 14_In non-PID mode, changes speed reference to AV12 16_Increases speed reference when SET-07 is set to (1) 17_Decreases speed reference when SET-07 is set to (1) 18_Disables PID and switches speed reference to keypad 19_Clears pulse counter accumulated value (MI6 only) 20_Pulse counter input (MI6 only) 21_Jog Command Forward 22_Jog Command Reverse 25_VFD stops by Emergency Stop device (requires reset) 26_External HOA Hand position contact 27_External HOA Auto position contact 28_Enables and disables the drive (not a run command) 29_PLC Function Disable 29 and 30=(0) or Run 29= (1) 30_PLC Function Disable 29 and 30=(0) or Stop 30= (1) 32_VFD will start in FO Mode by FO DI and Run Command 33_VFD will start in FO Mode by FO DI (No Run Command) 34_When damper is closed, Damper LSW DI is activated 35_Activates Shutdown. When inactive, VFD operates normally 36_Activates Shutdown. Requires reset to operate normally 37_Detects water or air flow by Flow Switch 40_Aux Motor-1 in MMC mode is off sequence 41_Aux Motor-2 in MMC mode is off sequence 42_Aux Motor-3 in MMC mode is off sequence 43_Aux Motor-4 in MMC mode is off sequence 44_Aux Motor-5 in MMC mode is off sequence 45_Aux Motor-6 in MMC mode is off sequence 46_Aux Motor-7 in MMC mode is off sequence 47_All Aux Motors in MMC mode are off sequence 48_Preset Set-Point-A for PID control 49_Preset Set-Point-B for PID. (If 48 and 49 ON=S-point-AB)
IO-22	Y	MI2 Define	See [IO-21]	MI2 Default = Preset Speed-M
IO-23	Y	MI3 Define	See [IO-21]	MI3 Default = Preset Speed-H
IO-24	Y	MI4 Define	See [IO-21]	MI4 Default = Fault Reset
IO-25	Y	MI5 Define	See [IO-21]	MI5 Default = Emergency Stop
IO-26	Y	MI6 Define	See [IO-21]	MI6 Default = XCEL-L (ACC-2/ DEC-2 Time)
IO-27	Y	MI7 Define	See [IO-21]	MI7 Default = HOA Hand
IO-28	Y	MI8 Define	See [IO-21]	MI8 Default = HOA Auto
IO-29	N	FO Enable	0_Disable 1_FWD Operation 2_REV Operation	Enables Fireman's Override mode in either forward or reverse.
IO-30	Y	FO Frequency	SET-13 to SET-14 (Hz)	Preset frequency for non-PID Fireman's Override mode.
IO-31	Y	FO Fault Retry	0 to 10	Number of auto-retries during fault in Fireman's Override mode
IO-32	Y	FO Retry Delay	0 to 6000 Sec	Delay of auto-retries during fault in Fireman's Override mode
IO-33	N	FO Mode & Reset	0_PID Off Manual 1_PID Off Auto 2_PID On Manual 3_PID On Auto	Sets control method and reset method for Fireman's Override mode. For example, (1)-FO mode no-PID and auto return to normal operation.
IO-34	Y	FO PID S-Point	0 to 100%	PID Setpoint in Fireman's Override mode (when IO-33 is 2 or 3)

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > I/O Menu**



CODE	AR	Display Name	Range	Description
IO-35	Y	E-Stop Mode	0_Coast Stop 1_Decel Stop	Determines how the motor is stopped when an Emergency STOP command is initiated. Decel to stop: VFD decelerates frequency to minimum output frequency and then stops. Coast to stop: VFD stops the output instantly and motor free runs until it comes to a complete standstill.
IO-36	Y	Damper Mode	0_Disable 1_Enable	Enables damper control feature.
IO-37	Y	Damper T-Delay	0 to 6000 Sec	Provides a run time delay without a damper limit switch; or, provides a Damper Fault delay for systems that include a damper limit switch. The delay should be greater than damper opening time.
IO-38	Y	No-Flow Mode	0_Disable 1_Trip 2_Sleep	The VFD can monitor a system flow switch to provide pump protection and more reliable sleep mode operation. If any digital input is set to Flow Switch in parameters I/O-21-28 and VFD runs longer than time set in IO-39 at frequency above setting in IO-40 with open Flow Switch, VFD will trip on No Flow fault.
IO-39	Y	No Flow Delay	1 to 6000 Sec	Duration motor runs until No Flow protection becomes active.
IO-40	Y	No-Flow Freq	0.0 to (variable) Hz	0.0 to High Freq Limit [SET-14] for V/F control 0.0 to PID Hi Hz limit [SET-23] for PID control
IO-41	Y	Lube/S-Clean	0_Disabled 1_Lubrication 2_Screen Clean	Select Lubrication for machines requiring external lubrication control via solenoid or Screen Clean for actuating a solenoid to clear the suction screen.
IO-42	Y	S-Clean Timer	0 to 600 Min	Determines a time period before next 1-minute cleaning pulse.
IO-43	Y	Pre-Lube Timer	0 to 6000 Sec	Determines Pre-lubrication time before VFD starts.
IO-44	Y	Run-Lube Timer	0 to 6000 Sec	Lube relay will be activated at VFD start (run state) and after timer expires it will be deactivated.
IO-45	Y	Post-Lube Timer	0 to 6000 Sec	Lube relay is activated and post-lube timer starts when VFD stops (reaches 0.00Hz) whether it coasts to stop or decelerates.
IO-46	Y	DI NO/NC		Sets the digital inputs numbered in hex format to either N.O. or N.C. configuration. The configuration is in binary format Bit0, Bit1, Bit2, etc. corresponding to FWD, REV, DI1, DI2, etc. from the right to the left. Empty box indicates that Relay is N.O. and solid box that it is N.C. Example below shows Hex value=2 and solid box (N.C. contact configuration) for Bit1 DI (Rev). If contact wired to DI Rev is open, DI is activated. When contact is closed, DI will be deactivated.  






**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > I/O Menu**

CODE	AR	Display Name	Range	Description
IO-47	Y	Relay RA1	0_No Function 1_Run 2_FDT-1 3_FDT-2 4_FDT-3 5_FDT-4 6_FDT-5 7_Drive Ready 8_Fault 9_VFD Overheat 10_DC Brake 11_PID F/B Loss 12_Counter Done 13_Pre-Count Done 14_Alarm 15_FWD CMD 16_REV CMD 17_Analog Trigger 19_Overcurrent 2 22_Fireman 0-ride 23_Bypass 24_Motor-1 Out 25_Motor-2 Out 26_Motor-3 Out 27_Motor-4 Out 28_Motor-5 Out 29_Motor-6 Out 30_Motor-7 Out 38_Damper Output 41_Lube/S Clean 42_ACI Loss 44_Hand Mode 45_Auto Mode 47_MMC Out 49_At High Current 50_At Low Current	RA1 Default = Fault 1_During Run Mode 2_When frequency reference value is achieved 3_On above [IO-52] freq and Off below [IO-52]-[IO-53] freq 4_On above [IO-54] freq and Off below [IO-54]+[IO-55] freq 5_On up to FDT-4/5 freq 6_On above FDT-4/5 freq 7_When drive is powered and ready (no faults) 8_When drive has tripped on any fault 9_When VFD temperature reaches trip level 10_When DC injection brake is activated 11_When PID feedback source signal value is abnormal 12_When pulse counter achieves the counter set-value 13_When pulse counter achieves pre-count value 14_When alarm is triggered by any alarm condition 15_When VFD operates in Forward direction 16_When VFD operates in Reverse direction 17_When analog signal reaches a trigger level 19_When VFD trips on Overcurrent 2 22_When Fireman's Override mode is activated 23_When drive switches from Soft-Start mode to Bypass 24_When Motor-1 is enabled in MMC control 25_When Motor-2 is enabled in MMC control 26_When Motor-3 is enabled in MMC control 27_When Motor-4 is enabled in MMC control 28_When Motor-5 is enabled in MMC control 29_When Motor-6 is enabled in MMC control 30_When Motor-7 is enabled in MMC control 38_When Damper motor output is activated 41_When Lube or Screen Clean solenoid output is activated 42_When ACI analog input signal value is abnormal 44_When VFD control is in Hand mode 45_When VFD control is in Auto mode 47_Aux motor start output in MMC control 49_When current reaches High Current trigger level 50_When current is below Low Current trigger level
IO-48	Y	Relay RA2	See [IO-47]	RA2 Default = Run
IO-49	Y	Relay RA3	See [IO-47]	RA3 Default = FDT-4
IO-50	Y	CNT Attained 0	0 to 65500	Active increment counter triggered by MI6 when IO-26 is set to 20:Input CNT. After completion of counting, the relay output becomes active if IO-47,48, or 49 is set to 13:PreCount Done. The relay becomes active for 1msec. The counter then returns to 0. When the display shows c5555, the drive has counted 5,555 times. If display shows c5555*, it means that real counter value is between 55,550 to 55,559.
IO-51	Y	CNT Attained 1	0 to 65500	Increment counter triggered by MI6 when IO-26 is set to 20:Input CNT. After completion of counting, the relay output becomes active if IO-47,48, or 49 is set to 12:Count Done. The relay stays active for same number of counts then becomes inactive. The cycle then repeats.
IO-52	Y	FDT-2 Frequency	0.0 to 600 Hz	Once VFD output frequency is within the range of (FDT-2 Frequency - FDT-2 Bandwidth) and (FDT-2 Frequency + FDT-2 Bandwidth), then relay output becomes active if IO-47, 48, or 49 is set to 3:FDT-2.
IO-53	Y	FDT-2 Bandwidth	0.0 to 600 Hz	This bandwidth represent half the frequency span in FDT-2 Frequency detection.
IO-54	Y	FDT-3 Frequency	0.0 to 600 Hz	Once VFD output frequency is within the range of (FDT-3 Frequency - FDT-3 Bandwidth) and (FDT-3 Frequency + FDT-3 Bandwidth), then relay output becomes active if IO-47, 48, or 49 is set to 4:FDT-3.
IO-55	Y	FDT-3 Bandwidth	0.0 to 600 Hz	This bandwidth represent half the frequency span in FDT-3 Frequency detection.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > I/O Menu**

CODE	AR	Display Name	Range	Description
IO-56	Y	I Hi/Lo Setting	0 to 100%	When any relay is set to (49) At High Current in IO-47-49 and motor current is at or above IO-56 set level (% of FLA), corresponding relay will be activated. When any relay is set to (50) At Low Current in IO-47-49 and motor current is below IO-56 set level (% of FLA), corresponding relay will be activated
IO-57	Y	FDT-4/5 Setting	0.0 to 60 Hz	Frequency setting for FDT-4 and FDT-5 functions. 
IO-58	Y	Relay NO/NC		Sets the relay outputs numbered in hex format to either N.O. or N.C. configuration. The configuration is in binary format Bit0, Bit1, Bit2, etc. corresponding to RA1, RA2, etc. from right to left. Empty box indicates that Relay is N.O. and solid box that it is N.C. Example below shows solid box (N.C. contact configuration) for Bit0 DO (RA1). The physical N.O. contact of RA1 relay is always closed (relay is activated) until the selected function in IO-47-49 is activated, then contact will be open. 
IO-59	Y	AFM1 Out Select	0_ Output FREQ 1_ Output AMP (rms) 2_ Output voltage 3_ DC Bus voltage 4_ Power Factor 5_ Power 6_ AV11 % 7_ AC1 % 8_ AV12 % 9_ Constant Output	Defines functionality of Analog Output 1 (AFM1).
IO-60	Y	AFM1 Gain	0 to 500%	Adjusts the analog voltage level output of AFM1.
IO-61	Y	AFM2 Out Select	See [IO-59]	Defines functionality of Analog Output 2 (AFM2).
IO-62	Y	AFM2 Gain	0 to 500%	Adjusts the analog voltage level output of AFM2.
IO-63	Y	AFM1 mA Select	0_ 0-20mA output 1_ 4-20mA output	Selects current range of AFM1 output.
IO-64	Y	AFM2 mA Select	0_ 0-20mA output 1_ 4-20mA output	Selects current range of AFM2 output.
IO-65	Y	AFM1 Filter Time	0 to 20 Sec	Noise filtering of AFM1 output.
IO-66	Y	AFM2 Filter Time	0 to 20 Sec	Noise filtering of AFM2 output.
IO-67	Y	MO by AI Level	0_ AV11 1_ AC1 2_ AV12	When input signal selected is higher than AI Upper Level [IO-13], then MO becomes active. Once input signal decreases below AI Lower Level [IO-14], then MO becomes inactive.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > I/O Menu**

CODE	AR	Display Name	Range	Description
IO-68	Y	Fault Out Opt 1	0.0 to 65535	<p>Select fault codes that activate relay output when fault becomes active. Displays fault code groups in hex format as follows:</p> <p>Bit0 = Current fault                      Bit4 = PID Feedback fault            Bit1 = Voltage fault                    Bit5 = EXI fault            Bit2 = Overload fault                 Bit6 = Communication fault            Bit3 = System fault</p> <p>Relay output [IO-47-49] must be set to (8) Fault.</p> 
IO-69	Y	Fault Out Opt 2	0.0 to 65535	See [IO-68]
IO-70	Y	Fault Out Opt 3	0.0 to 65535	See [IO-68]
IO-71	Y	Fault Out Opt 4	0.0 to 65535	See [IO-68]
IO-72	Y	FO Bypass	0_Disable Bypass 1_Enable Bypass	Enables Bypass for Fire Override.
IO-73	Y	FO Bypass Delay	0 to 6550 Sec	Time delay between Fire Override becoming active and enabling relay output for FO indication.
IO-74	N	D-Inputs Status		<p>Displays status of digital inputs numbered in hex format. The input status is in binary format. Empty box indicates that N.O. DI is deactivated and solid box that it is activated. It shows DIs FWD, REV, DI1, DI2... status from the right to the left Bit0=1, Bit1=2, Bit3=4, Bit4=8, Bit5=16, etc. Example below shows hex value=5 and solid boxes (activated) for Bit0 (value=1) DI (FWD) and Bit2 (value=4) DI (DI1). The contacts wired to those inputs should be closed to deactivate input and open to activate it.</p> 
IO-75	N	D-Relays Status		<p>Displays status of digital outputs (DOs) numbered in hex format. The output status is in binary format. Empty box indicates that output Relay is deactivated and solid box that it is activated. It shows DOs RA1, RA2... status from the right to the left Bit0, Bit1, Bit2, Bit3, etc. Example below shows hex value=1 and solid box (activated) for Bit0 (RA1). The N.O. contact of RA1 relay is closed until selected function is activated.</p> 

## Parameter Descriptions > ADV Menu

AR = Adjustable while running.

CODE	AR	Display Name	Range	Description
ADV-00	Y	Upper Bound Int	0 to 100%	Upper limit for the integral gain (I), which limits the output frequency. Upper Limit Freq = VFD Max Freq Main [VFD-00] x Upper Bound Int [ADV-00]. Too large integral value will cause a slow response to sudden load changes. This could cause motor stall or machine damage.
ADV-01	Y	PID Out Limit	0 to 110%	Maximum PID command limit. Percentage of Maximum Output Frequency [VFD-00].
ADV-02	Y	Password Input	0 to 65535	Password protect from modifying parameters.
ADV-03	N	Parameter Reset	0_Disabled 1_Write protect 2_Reset KWH 3_Reset all Param 4_Reset M Run T	Select stored data to be reset.
ADV-05	Y	Password Lock	0_Unlocked 1_Locked	When setting password protection for the first time, set password in Password Input [ADV-02] and then Password Lock [ADV-05] becomes 1-Locked. To permanently disable password protection, unlock parameters by entering password in Password Input [ADV-02] and then set Password Lock [ADV-05] to 0-Unlocked. If drive is unlocked by a password and password lock is not set to 0-Unlocked, the next reboot of the VFD will lock the VFD again.
ADV-06	Y	Acc/Dec Type	0_Linear Acc/Dec 1_Auto Acc/L-Dec 2_L-Acc/Auto Dec 3_Auto Acc/Dec 4_Lin, Auto Stall	Provides automated acceleration and deceleration with stall prevention. 0_Linear Acc/Dec: Accelerates and decelerates according to the setting of SET-11-12 and VFD-19-24. 1_Auto Acc/L-Dec: Auto detects the load torque and accelerates for the fastest acceleration time and smoothest start current. Deceleration is linear according to setting of SET-11-12 and VFD-19-24. 2_L-Acc/Auto Dec: Linear acceleration according to setting SET-11-12 and VFD-19-24. Auto detects the load re-generation and stops the motor smoothly with the fastest decel time. 3_Auto Acc/Dec: Auto detects load for smoothest operation for acceleration and deceleration. 4_Lin, Auto Stall: Stall prevention by auto accel./decel being limited by SET-11-12 and VFD-19-24.
ADV-07	N	Acc/Dec Format	0_Unit 0.01 Sec 1_Unit 0.1 Sec	Precision of acceleration and deceleration.
ADV-08	Y	Energy Saving	0_Disable 1_Enable	When the output frequency is constant, the output voltage will auto decrease by the load reduction. The drive will operate with minimum power.
ADV-09	Y	E-Saving Gain	10 to 1000%	Determines speed of adjusting output voltage in relationship to load reduction. If the motor oscillates or has a quick temperature rise, the value should be increased.
ADV-10	N	MMC Mode	0_Disabled (default) 1_Equal Run Time 2_Soft Start mode 3_Lead-Lag 4_Run Time Alt 5_Rotate Lead	Type of operation for Multi-Motor Control.
ADV-11	N	Motor Quantity	1 (default) to 7	Number of motors in MMC relay control setup. Limit is 3 without I/O card. When I/O card is installed, selections 1-7 are available.
ADV-12	N	Aux Mtr Stop Hz	0 to VFD-00	When output frequency is less than value and remains for duration of ADV-15, motors will be shut down one by one.
ADV-13	N	Alt Run Time	0.0 to 60000 Min	Duration of running a motor before switching to another motor.
ADV-14	N	S-Start ON Dly	0.0 to 3600 Sec	Delay time before switching on motor.
ADV-15	N	S-Start Off Dly	0.0 to 3600 Sec	Delay time before switching off motor.
ADV-16	Y	Mtr Switch Tmr	0.0 to 3600 Sec	When output duration reaches value, the system will start preparing to switch motors.
ADV-17	Y	Mtr Switch Hz	Set-22 to Set 23 (Hz)	When the output frequency reaches value, the system will start preparing to switch motors.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > ADV Menu**

CODE	AR	Display Name	Range	Description
ADV-18	Y	Lag Start Freq	ADV-23 to Set-23	Running above ADV-18 frequency is one of the conditions for starting Lag pump. Lag Start Frequency parameter is used for ADV-10 selection (3) Lead-Lag MMC control. Default= 59.50Hz.
ADV-19	Y	Lag Start Delay	0.0 to 600 Sec	Sets a delay time to start Lag pump when both frequency and pressure conditions are met.
ADV-20	Y	Lag Start Level	0.1 to 10%	Sets percentage of [Set-20 PID F/B Max] value to determine [MMC Below Setpoint] level for Lag pump starting. ADV-20 parameter is used for ADV-10 selection (3) Lead-Lag MMC control.
ADV-21	Y	Lead Freq Drop	0.0 to SET-23 (Hz)	PID High Frequency Limit drop value with ADV-22 Decel Time at Lag pump start to prevent system overpressure condition. ADV-21 parameter is used for ADV-10 selection (3) Lead-Lag MMC control.
ADV-22	Y	MMC Decel Time	0.0 to 600 Sec	Sets deceleration time for PID High Frequency limit value change from [Set-23 PID High Freq Limit] to [Set-23 PID High Freq Limit]-[ADV-21] at Lag pump start. ADV-22 parameter is used for ADV-10 selection (3) Lead-Lag MMC control.
ADV-23	Y	Lag Stop Freq	SET-22 to ADV-18 (Hz)	Running below ADV-23 frequency is one of the conditions for stopping Lag pump. This parameter is used for ADV-10 selection (3) Lead-Lag MMC control.
ADV-24	Y	Lag Stop Delay	0.0 to 600 Sec	Sets delay time to stop Lag pump when both frequency and pressure. ADV-24 parameter is used for ADV-10 selection (3) Lead-Lag MMC control.
ADV-25	Y	Lag Stop Level	0.1 to ADV-20 (%)	Sets percentage value of [Set-20 PID F/B Max] value to determine [MMC At Setpoint] level for Lag pump stopping. ADV-25 parameter is used for ADV-10 selection (3) Lead-Lag MMC control.
ADV-26	Y	Lead Freq Bump	0.0 to (SET-23)*0.4 Hz	PID Low Freq Limit increase value with ADV-27 Accel Time at Lag pump stop to prevent system underpressure condition. ADV-26 parameter is used for ADV-10 selection (3) Lead-Lag MMC control.
ADV-27	Y	MMC Accel Time	0.0 to 600 Sec	Sets acceleration time for PID Low Frequency limit value change from [Set-22 PID Low Freq Limit] to [Set-22 PID Low Freq Limit]+[ADV-26] at Lag pump stop.
ADV-28	Y	Power on Delay	0.0 to 6000 Sec	This timer provides run delay at VFD power-up with run command present to prevent multiple starts during power surges.
ADV-29	Y	Run Delay Timer	0.0 to 6000 Sec	This timer provides a delay at every VFD start when run command is applied. Timer starts before every VFD start by run command, auto-restarts, fault reset, sleep wake-up, etc. FO (Fire Override) mode will disable this timer.
ADV-30	Y	Backspin Timer	0.0 to 6000 Sec	Duration after stop state that the drive disables output. Protects drive from motor backspinning due to column of water backflowing through pump.
ADV-34	Y	Min Run Timer	0.0 to 6000 Sec	Once drive starts motor, the motor continuously runs for this length of time even though a stop command is present.
ADV-55	Y	AVR Select	0_Enable AVR 1_Disable AVR 2_Disable AVR Dec	Auto Voltage Regulation automatically regulates the drive output voltage to the motor rated voltage.

## Parameter Descriptions > PROTECTION Menu

AR = Adjustable while running.

CODE	AR	Display Name	Range	Description
PROT-00	N	Decel Method	0_Normal 1_Over Fluxing 2_Traction Energy	0_VFD follows SET-12 Deceleration time 1_VFD prevents DC bus Over voltage by over-fluxing the motor at PROT-14 voltage. The Decel time can be longer than SET-12 value. 2_VFD prevents DC Bus Over voltage by changing output frequency and voltage. The Decel time can be longer than SET-12 value.
PROT-01	Y	Preheat Level	0 to 100%	Percentage of nominal current applied to the motor as DC voltage to heat the VFD and motor. Slowly increase the percentage to reach the sufficient preheating temperature.
PROT-02	Y	Preheat Duty	0 to 100%	Sets output current cycle of preheating, which corresponds to 0-10 seconds. 0% - no output current 50% - 5 seconds OFF and 5 seconds ON 100% - continuous output current
PROT-03	Y	LV Level	(Varies with VFD rating)	Sets the Low Voltage (Lv) level. Recommended setting is motor voltage minus 10%. If incoming power varies too much, the setting may need to be 15% less than motor voltage. If DC bus voltage drops to Lv level, the VFD stops output to the motor with motor free run to stop. If fault occurs during acceleration, deceleration, constant speed, or stop, then fault indication is LvA, Lvd, Lvn, and LvS, respectively. Manual reset is required. To enable auto restart after a momentary power loss, consult PROT-37 and PROT-38 for VFD handling of fault. The hysteresis recovery level is based on VFD frame size and VFD voltage rating.
PROT-04	Y	OV Stall level	(Varies with VFD rating)	Set Over-Voltage Stall Level. If braking unit or braking resistor is connected, set level to 0 to disable.
PROT-05	Y	OV Stall Prevent	0_Standard 1_Advanced	Set Over-Voltage Stall Prevention operation. 0:Standard - Frequency maintains during deceleration. 1:Advanced - Frequency increases during acceleration, deceleration, or constant speed.
PROT-06	Y	SW Brake V Lvl	(Variable)	Sets the DC-bus voltage at which the DC Brake is activated. Defaults are based on VFD Rating.
PROT-07	Y	OCA Level	0 to 130%	Set Over-Current during Acceleration level. Value is based on VFD's rated current and selection of VFD-35 for Light Duty or Normal Duty.
PROT-08	Y	OCN Level	0 to 130%	Set Over-Current during Operation level. Value is based on VFD's rated current and selection of VFD-35 for Light Duty or Normal Duty.
PROT-12	Y	OL-2 Type	0_Disable 1_Alarm at Speed 2_Trip at Speed 3_Alarm at Run 4_Trip at Run	Select Overload Detection operation. Setting 1 and 2 protects from Overload once VFD reaches constant speed. Setting 3 and 4 protects from Overload throughout run of the motor.
PROT-13	Y	OL-2 Level	10 to 200%	Set Overload Detection level with respect to the rated current of the VFD.
PROT-14	Y	OL-2 Delay	0.0 to 60 Sec	Duration output current exceeds the overload detection level causing an Overload condition. The hysteresis for the Overload condition is 5% of detection level.
PROT-16	Y	ETH Type	0_Disable 1_Self Cooled 2_Force Cooled	Set type of motor for Electronic Thermal Relay protection. For 1:Self-Cooled, the motor rated current percentage level is 40% at 0Hz and linear increases to 100% at motor rated frequency.
PROT-17	Y	ETH Delay	30 to 600 Sec	Sets time the output current is higher than 150% before tripping on electronic thermal overload. The overload level with respect to time is based on I <sup>2</sup> t curve.
PROT-18	Y	OH Warn	0.0 to 110 °C	Set Heat Sink Over-heat warning level. When temperature exceeds 110C, the drive stops with an IGBT over-heat fault. Cooling fan is activated when temperature reaches 15C less than value. The cooling fan deactivates for 35C less than value.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > PROTECTION Menu**

CODE	AR	Display Name	Range	Description
PROT-19	Y	PTC Select	0_Alarm and Run 1_Alarm and Decel 2_Alarm and Coast 3_Disabled	Set operation when PTC, PT100, or KTY84 exceed level 2.
PROT-20	Y	PTC Level	0 to 100%	Set detection level of PTC. The corresponding value for 100% is the analog input maximum value
PROT-21	Y	OPO Trip	0_Alarm and Run 1_Alarm and Decel 2_Alarm and Coast 3_Disabled	Select operation for Output Phase Loss.
PROT-22	Y	OPO Delay	0 to 65.535 Sec	Duration of output phase loss until operation occurs.
PROT-23	Y	OPO Current	0 to 100%	Set level of output phase loss.
PROT-24	Y	OPO Decel	0 to 65.535 Sec	DC Brake Time of output phase loss.
PROT-25	Y	LvX Auto Reset	0_Disable 1_Enable	Set low voltage fault operation to auto reset. Once DC bus voltage returns, the VFD clears fault and restarts motor.
PROT-26	Y	IPO Check	0.0 to 600 Sec	Set how often to check for input phase loss.
PROT-27	Y	IPO Ripple	(Varies with VFD rating)	An input phase loss is detected when DC bus ripple is higher than IPO Ripple for duration of IPO Check plus 30 seconds.
PROT-28	Y	IPO Trip	0_Alarm and Decel 1_Alarm and Coast	Operation when input phase loss is detected.
PROT-29	Y	Derating Type	0_Carrier by L_T 1_Limit Current 2_Limit Carrier	Set how the VFD derates itself. 0 - Limit the carrier wave to reach max load current and temperature. 1 - Limit the current to use max carrier frequency. 2 - Limit the carrier wave to reach max load current and temperature except when output current is the derating ratio x 130% of output current in light load.
PROT-30	Y	PT100 Level 1	0.0 to 10 V	Level the PT100 reaches for duration for PT100 L-1 Delay causing drive to back frequency down to PT100 L-1 Freq.
PROT-31	Y	PT100 Level 2	0.0 to 10 V	Level the PT100 reaches causing PTC Select [Prot-19] operation.
PROT-32	Y	PT100 L-1 Freq	0.0 to 599 Hz	Frequency the VFD reduces to after reaching PT100 Level 1 for duration of PT100 L-1 Delay.
PROT-33	Y	PT100 L-1 Delay	0.0 to 6000 Sec	Duration PT100 has to be above PT100 Level 1 to cause frequency reduction to PT100 L-1 Freq.
PROT-34	Y	Ground Fault Lvl	0 to 6553.5%	Percentage of light-load current that current phase unbalance has to reach for duration of G-Fault Delay [Prot-35] for ground fault to occur.
PROT-35	Y	G-Fault Delay	0 to 6553.5 Sec	Duration of current phase unbalance for ground fault to occur.
PROT-36	Y	STO Alarm Type	0_STO Latching 1_STO Non-Latch	
PROT-37	Y	IPF S-Search	0_Disable 1_At Last Freq 2_At Min Freq	Speed search treatment after Instantaneous Power Failure (IPF).
PROT-38	Y	Max IPF Time	0 to 20 Sec	Duration power loss has to occur for output to be turned off (coast stop).
PROT-39	Y	SS Current Lmt	20 to 200%	Following a momentary power loss, the drive will start speed search operation if the output current is greater than PROT-39 value.
PROT-40	Y	SS After Fault	0_Disable 1_At Last Freq 2_At Min Freq	Speed search treatment after fault,
PROT-41	Y	Auto Restarts	0 to 10	Number of auto restart attempts after fault.
PROT-42	Y	SS Normal Start	0_Disable 1_At Max Freq 2_At Start Freq 3_At Min Freq	Speed search treatment for normal start command.
PROT-43	Y	Spd Search Gain	1 to 200%	Voltage gain percentage for speed search operation. Reduce value if overload or overcurrent fault occurs.
PROT-44	Y	IPF Restart Dly	0 to 5 Sec	Delay for restart after an Instantaneous Power Failure. Set value high enough to allow residual regeneration voltage to disappear.

## PARAMETER REFERENCE TABLES

### Parameter Descriptions > COMM Menu

CODE	AR	Display Name	Range	Description
PROT-45	Y	Fan Control	0_At Power-Up 1_Delayed Stop 2_During Run 3_By Temperature 4_Disabled	Determines operation of fan. Recommend not to set to 4-Disabled since this will reduce performance of drive.
PROT-46	Y	Last Flt Freq	0.0 to SET-14 Hz	Output frequency at last fault (Read Only)
PROT-47	Y	Last Flt IGBT T	-3277 to 3276.7 °C	IGBT temperature at last fault (Read Only)
PROT-48	Y	Last Flt Cap T	-3277 to 3276.7 °C	Capacitance temperature at last fault (Read Only)
PROT-49	Y	Last Flt MFI	(Read Only)	Status of Multi-function input terminals at last fault
PROT-50	Y	Last Flt MFO	(Read Only)	Status of Multi-function output terminals at last fault
PROT-51	Y	1st Fault		First register of fault listing.
PROT-52	Y	2nd Fault		Second register of fault listing.
PROT-53	Y	3rd Fault		Third register of fault listing.
PROT-54	Y	4th Fault		Fourth register of fault listing.
PROT-55	Y	5th Fault		Fifth register of fault listing.
PROT-56	Y	6th Fault		Sixth register of fault listing.

### Parameter Descriptions > COMM Menu

AR = Adjustable while running.

CODE	AR	Display Name	Range	Description
Comm-00	Y	COM1 Address	1 to 254	RS485 address of VFD.
Comm-01	Y	COM1 Speed	4.8 to 115.2 Kbps	RS485 baud rate. All devices on RS485 communication must have the same baud rate.
Comm-02	Y	COM1 Loss	0_Alarm and Run 1_Alarm_Decel 2_Alarm_Coast 3_Disable	Select operation when communication is lost.
Comm-03	Y	COM1 Loss Delay	0.0 to 100 Sec	Duration of communication loss before initiating operation.
Comm-04	Y	COM1 Protocol	1_7, N, 2 for ASCII 2_7, E, 1 for ASCII 3_7, O, 1 for ASCII 4_7, E, 2 for ASCII 5_7, O, 2 for ASCII 6_8, N, 1 for ASCII 7_8, N, 2 for ASCII 8_8, E, 1 for ASCII 9_8, O, 1 for ASCII 10_8, E, 2 for ASCII 11_8, O, 2 for ASCII 12_8, N, 1 for RTU 13_8, N, 2 for RTU 14_8, E, 1 for RTU 15_8, O, 1 for RTU 16_8, E, 2 for RTU 17_8, O, 2 for RTU	RS485 Protocol: Data Bits - Parity - Stop Bits - Message Format
Comm-05	Y	Response Delay	0.0 to 200 ms	Duration VFD waits before responding to received communication.
Comm-06	N	Main Frequency	0.0 to 599 Hz	When Auto Speed Ref [SET-07] is set to RS485 Interface, the last frequency command is stored in this parameter. After rebooting from an abnormal turn-off or momentary power loss, the VFD will continue operation with last frequency.
Comm-07	Y	Block Transf 1	0000h to FFFFh	Block transfer allows selection of a group of parameters for transfer through communication code 03H.
Comm-08	Y	Block Transf 2	0000h to FFFFh	See [Comm-07]
Comm-09	Y	Block Transf 3	0000h to FFFFh	See [Comm-07]
Comm-10	Y	Block Transf 4	0000h to FFFFh	See [Comm-07]



**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > COMM Menu**

CODE	AR	Display Name	Range	Description
Comm-11	Y	Block Transf 5	0000h to FFFFh	See [Comm-07]
Comm-12	Y	Block Transf 6	0000h to FFFFh	See [Comm-07]
Comm-13	Y	Block Transf 7	0000h to FFFFh	See [Comm-07]
Comm-14	Y	Block Transf 8	0000h to FFFFh	See [Comm-07]
Comm-15	Y	Block Transf 9	0000h to FFFFh	See [Comm-07]
Comm-16	Y	Block Transf 10	0000h to FFFFh	See [Comm-07]
Comm-17	Y	Block Transf 11	0000h to FFFFh	See [Comm-07]
Comm-18	Y	Block Transf 12	0000h to FFFFh	See [Comm-07]
Comm-19	Y	Block Transf 13	0000h to FFFFh	See [Comm-07]
Comm-20	Y	Block Transf 14	0000h to FFFFh	See [Comm-07]
Comm-21	Y	Block Transf 15	0000h to FFFFh	See [Comm-07]
Comm-22	Y	Block Transf 16	0000h to FFFFh	See [Comm-07]
Comm-23	N	Com Decoding	0_20xx 1_60xx	Select address starting range for communication via RS485, CANopen, and Communication Card.
Comm-24	N	BACnet MAC ID	0 to 127	BACnet address of VFD.
Comm-25	N	BACnet Speed	9.6 to 76.8 Kbps	BACnet baud rate.
Comm-26	N	Device ID Lo	0 to 65535	BACnet Device ID L
Comm-27	N	Device ID Hi	0 to 63	BACnet Device ID H
Comm-28	N	Max Address	0 to 127	BACnet max address.
Comm-29	N	Password	0 to 65535	BACnet password.
Comm-30	N	Com Card ID	0_No Com Card 1_DevNet Slave 2_P-bus DP Slave 3_CANopen S/M 4_Mbus-TCP Slave 5_E-Net/IP Slave 6_FELE BT Card	Identification of installed communication card.
Comm-31	N	Com Card FW	N/A	Firmware version of communication card.
Comm-32	N	Product code	N/A	Part number of communication card.
Comm-33	N	Error code	N/A	Error status of communication card.
Comm-34	Y	D-Net Card Addr	(Variable)	DeviceNet or Profibus address of VFD.
Comm-35	Y	D-Net Speed	0_125 Kbps 1_250 Kbps 2_500 Kbps 3_1 Mbps	DeviceNet baud rate.
Comm-36	Y	D-Net Type	0_Standard 1_Special	DeviceNet Standard is when D-Net Speed [Comm-35] is set to 125Kbps, 250Kbps, and 500Kbps in standard speeds. DeviceNet Special is for other speeds similar to CANopen.
Comm-37	Y	M-bus IP Type	0_Static IP 1_DHCP	Set the Modbus TCP IP manually with Static IP or automatically by host control with DHCP.
Comm-38	Y	IP Address 1	0 to 65535	First (most significant) octet of IP address. (0-255) XXX.---.---.---
Comm-39	Y	IP Address 2	0 to 65535	Second octet of IP address. (0-255) ---.XXX.---.---
Comm-40	Y	IP Address 3	0 to 65535	Third octet of IP address. (0-255) ---.---.XXX.---
Comm-41	Y	IP Address 4	0 to 65535	Fourth (least significant) octet of IP address. (0-255) ---.---.---.XXX
Comm-42	Y	Address Mask 1	0 to 65535	First (most significant) octet of Mask address. (0-255) XXX.---.---.---
Comm-43	Y	Address Mask 2	0 to 65535	Second octet of Mask address. (0-255) ---.XXX.---.---
Comm-44	Y	Address Mask 3	0 to 65535	Third octet of Mask address. (0-255)

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > PLC Menu**

CODE	AR	Display Name	Range	Description
Comm-45	Y	Address Mask 4	0 to 65535	Fourth (least significant) octet of Mask address. (0-255) ---.---.---.XXX
Comm-46	Y	G-way Address 1	0 to 65535	First (most significant) octet of Gateway address. (0-255) XXX.---.---.---
Comm-47	Y	G-way Address 2	0 to 65535	Second octet of Gateway address. (0-255)
Comm-48	Y	G-way Address 3	0 to 65535	Third octet of Gateway address. (0-255)
Comm-49	Y	G-way Address 4	0 to 65535	Fourth (least significant) octet of Gateway address. (0-255)
Comm-50	Y	Mbus TCP Pass L	0 to 99	Communication card password for Modbus TCP (Low word)
Comm-51	Y	Mbus TCP Pass H	0 to 99	Communication card password for Modbus TCP (High word)
Comm-52	Y	Mbus Card Reset	0_Disable 1_Reset	Sets the communication card to default values for Modbus TCP.
Comm-53	Y	Mbus TCP Config	0_IP Filter 1_I-net Par On 2_Login Pass	Once IP address parameters are set, then set Modbus TCP Config to 1:Internet Parameters to load parameters. Once login password is set, then set Modbus TCP Config to 2:Login Password to load password.
Comm-54	N	Mbus TCP Status	N/A	When the communication card is set with a password, this bit is enabled, When the password is cleared, this bit is disabled.

**Parameter Descriptions > PLC Menu**

CODE	Display Name	Range	Description
PLC-00	DI used by PLC	0 to 65535	Status of PLC external input terminal.
PLC-01	DO used by PLC	0 to 65535	Status of PLC external output terminal.
PLC-02	Analog by PLC	0 to 65535	Status of PLC external analog output terminals.
PLC-03	PLC Buffer 0	0 to 65535	Used for PLC or HMI programming.
PLC-04	PLC Buffer 1	0 to 65535	Used for PLC or HMI programming.
PLC-05	PLC Buffer 2	0 to 65535	Used for PLC or HMI programming.
PLC-06	PLC Buffer 3	0 to 65535	Used for PLC or HMI programming.
PLC-07	PLC Buffer 4	0 to 65535	Used for PLC or HMI programming.
PLC-08	PLC Buffer 5	0 to 65535	Used for PLC or HMI programming.
PLC-09	PLC Buffer 6	0 to 65535	Used for PLC or HMI programming.
PLC-10	PLC Buffer 7	0 to 65535	Used for PLC or HMI programming.
PLC-11	PLC Buffer 8	0 to 65535	Used for PLC or HMI programming.
PLC-12	PLC Buffer 9	0 to 65535	Used for PLC or HMI programming.
PLC-13	PLC Buffer 10	0 to 65535	Used for PLC or HMI programming.
PLC-14	PLC Buffer 11	0 to 65535	Used for PLC or HMI programming.
PLC-15	PLC Buffer 12	0 to 65535	Used for PLC or HMI programming.
PLC-16	PLC Buffer 13	0 to 65535	Used for PLC or HMI programming.
PLC-17	PLC Buffer 14	0 to 65535	Used for PLC or HMI programming.
PLC-18	PLC Buffer 15	0 to 65535	Used for PLC or HMI programming.
PLC-19	PLC Buffer 16	0 to 65535	Used for PLC or HMI programming.
PLC-20	PLC Buffer 17	0 to 65535	Used for PLC or HMI programming.
PLC-21	PLC Buffer 18	0 to 65535	Used for PLC or HMI programming.
PLC-22	PLC Buffer 19	0 to 65535	Used for PLC or HMI programming.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > PLC Menu**

CODE	Display Name	Range	Description
PLC-23	PLC Com Type	-12_PLC Control -10_Internal Master -8_Internal Slave 8 -7_Internal Slave 7 -6_Internal Slave6 -5_Internal Slave 5 -4_Internal Slave 4 -3_Internal Slave 3 -2_Internal Slave 2 -1_Internal Slave 1 0_Modbus 485 1_BACnet	Setup PLC controller for single VFD or with multiple VFD's.
PLC-24	PLC force to 0	0 to 65535	Defines reset value of the frequency command before PLC scans time sequence. Bit0 Before PLC scan, set up PLC target frequency=0 Bit1 Before PLC scan, set up PLC target torque=0. Bit2 Before PLC scan, set up the speed limit of torque control mode=0.
PLC-25	PLC Address	1 to 254	Address of PLC with respect to communication link.

## Parameter Descriptions > Option Menu

AR = Adjustable while running.

CODE	AR	Display Name	Range	Description
Option-00	N	M10 Define	0_No Function 1_Speed-L 2_Speed-M 3_Speed-H 4_Speed-X 5_Fault Reset 6_Jog Speed 7_Hold Speed 8_XCEL-L 9_XCEL-M 10_Ext. Trip 12_AV11 Analog Spd 13_ACI Analog Spd 14_AV12 Analog Spe 16_Digital Up 17_Digital Down 18_PID Disable 19_CLR CNT 20_Input CNT (M16) 21_FWD Jog 22_REV Jog 25_E-Stop 26_HOA HAND 27_HOA AUTO 28_Drive Enabled 29_PLC mode bit 0 30_PLC mode bit 1 32_FO with RUN Cmd 33_FO w/o RUN Cmd 34_Damper Limit Sw 35_Shutdown N-Latch 36_Shutdown Latched 37_Flow Switch 40_Aux Motor-1 OFF 41_Aux Motor-2 OFF 42_Aux Motor-3 OFF 43_Aux Motor-4 OFF 44_Aux Motor-5 OFF 45_Aux Motor-6 OFF 46_Aux Motor-7 OFF 47_All Aux Mtr Off	Defines functionality of input MI10 on I/O extension card. 1_Multi-step speed command 1 2_Multi-step speed command 2 3_Multi-step speed command 3 4_Multi-step speed command 4 5_Use to reset fault after cause is corrected 6_Changes speed in jog mode to value set in VFD-55 7_When active, VFD will hold current speed 8_ACC/DEC time will be changed to VFD-19 and VFD-20 9_ACC/DEC time will be changed to VFD-21 and VFD-22 10_Trips VFD by external protective device and requires reset 12_In non-PID mode, changes speed reference to AV11 13_In non-PID mode, changes speed reference to ACI 14_In non-PID mode, changes speed reference to AV12 16_Increases speed reference when SET-07 is set to (1) 17_Decreases speed reference when SET-07 is set to (1) 18_Disables PID and switches speed reference to keypad 19_Clears pulse counter accumulated value (M16 only) 20_Pulse counter input (M16 only) 21_Jog Command Forward 22_Jog Command Reverse 25_VFD stops by Emergency Stop device (requires reset) 26_External HOA Hand position contact 27_External HOA Auto position contact 28_Enables and disables the drive (not a run command) 29_PLC Function Disable 29 and 30=(0) or Run 29=(1) 30_PLC Function Disable 29 and 30=(0) or Stop 30=(1) 32_VFD will start in FO Mode by FO DI and Run Command 33_VFD will start in FO Mode by FO DI (No Run Command) 34_When damper is closed, Damper LSW DI is activated 35_Activates Shutdown. When inactive, VFD operates normally 36_Activates Shutdown. Requires reset to operate normally 37_Detects water or air flow by Flow Switch 40_Aux Motor-1 in MMC mode is off sequence 41_Aux Motor-2 in MMC mode is off sequence 42_Aux Motor-3 in MMC mode is off sequence 43_Aux Motor-4 in MMC mode is off sequence 44_Aux Motor-5 in MMC mode is off sequence 45_Aux Motor-6 in MMC mode is off sequence 46_Aux Motor-7 in MMC mode is off sequence 47_All Aux Motors in MMC mode are off sequence
Option-01		M11 Define	See [Option-00]	Defines functionality of input MI11 on I/O extension card.
Option-02		M12 Define	See [Option-00]	Defines functionality of input MI12 on I/O extension card.
Option-03		M13 Define	See [Option-00]	Defines functionality of input MI13 on I/O extension card.
Option-04		M14 Define	See [Option-00]	Defines functionality of input MI14 on I/O extension card.
Option-05		M15 Define	See [Option-00]	Defines functionality of input MI15 on I/O extension card.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > Option Menu**

CODE	AR	Display Name	Range	Description
Option-06		Relay exp. RA100	0_No Function 1_Run 2_FDT-1 3_FDT-2 4_FDT-3 5_FDT-4 6_FDT-5 7_Drive Ready 8_Fault 9_VFD Overheat 10_DC Brake 11_PID F/B Loss 12_Counter Done 13_Pre-Count Done 14_Alarm 15_FWD CMD 16_REV CMD 17_Analog Trigger 19_Overcurrent 2 22_Fireman O-ride 23_Bypass 24_Motor-1 Out 25_Motor-2 Out 26_Motor-3 Out 27_Motor-4 Out 28_Motor-5 Out 29_Motor-6 Out 30_Motor-7 Out 38_Damper Output 41_Lube/S Clean 42_ACI Loss 44_Hand Mode 45_Auto Mode 47_MMC Out 49_At High Current 50_At Low Current	RA1 Default = Fault 1_During Run Mode 2_When frequency reference value is achieved 3_On above [IO-52] freq and Off below [IO-52]-[IO-53] freq 4_On above [IO-54] freq and Off below [IO-54]+[IO-55] freq 5_On up to FDT-4/5 freq 6_On above FDT-4/5 freq 7_When drive is powered and ready (no faults) 8_When drive has tripped on any fault 9_When VFD temperature reaches trip level 10_When DC injection brake is activated 11_When PID feedback source signal value is abnormal 12_When pulse counter achieves the counter set-value 13_When pulse counter achieves pre-count value 14_When alarm is triggered by any alarm condition 15_When VFD operates in Forward direction 16_When VFD operates in Reverse direction 17_When analog signal reaches a trigger level 19_When VFD trips on Overcurrent 2 22_When Fireman's Override mode is activated 23_When drive switches from Soft-Start mode to Bypass 24_When Motor-1 is enabled in MMC control 25_When Motor-2 is enabled in MMC control 26_When Motor-3 is enabled in MMC control 27_When Motor-4 is enabled in MMC control 28_When Motor-5 is enabled in MMC control 29_When Motor-6 is enabled in MMC control 30_When Motor-7 is enabled in MMC control 38_When Damper motor output is activated 41_When Lube or Screen Clean solenoid output is activated 42_When ACI analog input signal value is abnormal 44_When VFD control is in Hand mode 45_When VFD control is in Auto mode 47_Aux motor start output in MMC control 49_When current reaches High Current trigger level 50_When current is below Low Current trigger level
Option-07		Relay exp. RA11	See [Option-06]	Defines functionality of output relay RA11 on I/O extension card.
Option-08		Relay exp. RA12	(Same as Option-06)	Defines functionality of output relay RA12 on I/O extension card.
Option-09		Relay exp. RA13	(Same as Option-06)	Defines functionality of output relay RA13 on I/O extension card.
Option-10		Relay exp. RA14	(Same as Option-06)	Defines functionality of output relay RA14 on I/O extension card.
Option-11		Relay exp. RA15	(Same as Option-06)	Defines functionality of output relay RA15 on I/O extension card.
Option-12		Relay exp. RA16	(Same as Option-06)	Defines functionality of output relay RA16 on I/O extension card.
Option-13		Relay exp. RA17	(Same as Option-06)	Defines functionality of output relay RA17 on I/O extension card.
Option-14		Relay exp. RA18	(Same as Option-06)	Defines functionality of output relay RA18 on I/O extension card.
Option-15		Relay exp. RA19	(Same as Option-06)	Defines functionality of output relay RA19 on I/O extension card.
Option-16		Relay exp. RA20	(Same as Option-06)	Defines functionality of output relay RA20 on I/O extension card.
Option-17		IO Card Type	No Definition EMC-BPS01 No Definition No Definition EMC-D611A EMC-D42A EMC-R6AA No Definition	Defines I/O card type.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > ADV2 Menu**

## Parameter Descriptions > ADV2 Menu

AR = Adjustable while running.

CODE	AR	Display Name	Range	Description
ADV2-00	N	PID D-Gain	0 to 1 sec	Differential gain value for PID operation.
ADV2-01	Y	Sleep Ctrl By	0_PID Output 1_PID F/B	When set to Output, units become Hz. When set to Feedback, units become %.
ADV2-03	Y	Mtr Brake Delay	0.0 to 65 Sec	Delay after start command when the corresponding multi-function output terminal (10: DC Brake) will be OFF.
ADV2-04	Y	AFM1 Rev Value	0_0-10 V 1_0 V 2_5-0 V	0_0-10V: AFM1 output is 0-10V when in REV. 1_0V: AFM1 output is 0V when in REV, 0-10V in FWD direction. 2_5-0V: AFM1 output is 5-0V when in REV, 5-10V in FWD direction.
ADV2-05	Y	AFM2 Rev Value	0_0-10 V 1_0 V 2_5-0 V	0_0-10V: AFM2 output is 0-10V when in REV. 1_0V: AFM2 output is 0V when in REV, 0-10V in FWD direction. 2_5-0V: AFM2 output is 5-0V when in REV, 5-10V in FWD direction.
ADV2-06	Y	AFM1 DC Lvl	0 to 100%	Used with Multi-Function Output IO-59 set to 2:Output voltage. Output emits constant voltage 0 to 100% corresponding to 0-10V.
ADV2-07	Y	AFM2 DC Lvl	0 to 100%	Used with Multi-Function Output IO-61 set to 2:Output voltage. Output emits constant voltage 0 to 100% corresponding to 0-10V.
ADV2-08	Y	Analog Curve	0_Regular Curve 1_AVI1 3-Point 2_ACI 3-Point 3_AVI1+ACI 3 Point 4_AVI2 3 Point 5_AVI1+AVI2 3 Point 6_ACI+AVI2 3 Point 7_3x Als 3-Point	The analog input signal can be setup for linear curve or 3-point (piece-wise) curve corresponding voltage/current input to frequency output. If using AVI1, ADV2-09 < ADV2-11 < ADV2-13. If using ACI, ADV2-15 < ADV2-17 < ADV2-19. If using AVI2, ADV2-21 < ADV2-23 < ADV2-25. If analog input is not selected, the analog input uses bias and gain to set the linear curve. The output frequency will become 0% when the analog input value is lower than low point setting.
ADV2-09	Y	AVI1 Low Value	(Variable)	Lowest analog input value for AVI1 that corresponds to frequency output of ADV2-10.
ADV2-10	Y	AVI1 Low %	-100 to 100%	Frequency output corresponding to ADV2-09 input.
ADV2-11	Y	AVI1 Mid Value	(Variable)	Middle analog input value for AVI1 that corresponds to frequency output of ADV2-12.
ADV2-12	Y	AVI1 Mid %	-100 to 100%	Frequency output corresponding to ADV2-11 input.
ADV2-13	Y	AVI1 High Value	(Variable)	Highest analog input value for AVI1 that corresponds to frequency output of ADV2-14.
ADV2-14	Y	AVI1 High %	-100 to 100%	Frequency output corresponding to ADV2-13.
ADV2-15	Y	ACI Low Value	(Variable)	Lowest analog input value for ACI that corresponds to frequency output of ADV2-16.
ADV2-16	Y	ACI Low %	-100 to 100%	Frequency output corresponding to ADV2-15 input.
ADV2-17	Y	ACI Mid Value	(Variable)	Middle analog input value for ACI that corresponds to frequency output of ADV2-18.
ADV2-18	Y	ACI Mid %	-100 to 100%	Frequency output corresponding to ADV2-17 input.
ADV2-19	Y	ACI High Value	(Variable)	Highest analog input value for ACI that corresponds to frequency output of ADV2-20.
ADV2-20	Y	ACI High %	-100 to 100%	Frequency output corresponding to ADV2-19.
ADV2-21	Y	AVI2 Low Value	0 to 10 V	Lowest analog input value for AVI2 that corresponds to frequency output of ADV2-22.
ADV2-22	Y	AVI2 Low %	-100 to 100%	Frequency output corresponding to ADV2-21 input.
ADV2-23	Y	AVI2 Mid Value	0 to 10 V	Middle analog input value for AVI2 that corresponds to frequency output of ADV2-24.
ADV2-24	Y	AVI2 Mid %	-100 to 100%	Frequency output corresponding to ADV2-23 input.
ADV2-25	Y	AVI2 High Value	0 to 10 V	Highest analog input value for AVI2 that corresponds to frequency output of ADV2-26.
ADV2-26	Y	AVI2 High %	-100 to 100%	Frequency output corresponding to ADV2-25.
ADV2-27	Y	dEb Offset V	0 to 200 V	Decel Energy Backup Error (dEb) Offset Voltage that the DC Bus reduces by to initiate dEb operation. Varies by VFD Rating.

**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > ADV2 Menu**

CODE	AR	Display Name	Range	Description
ADV2-28	Y	dEb Mode Select	0_Disable 1_Auto Dec/Stop 2_AutoDec/Restart	Select Decel Energy Backup Error (dEb) operation when DC Bus voltage drops by ADV2-27. This feature is used to detect power loss.
ADV2-30	Y	PID Mode Select	0_Serial PID 1_Parallel PID	0_Serial: VFD uses conventional PID control structure. 1_Parallel: Proportional, Integral, and Derivative gains are independent.
ADV2-31	N	PID Unit Format	0_1 1_0.1 2_0.01	Select precision of PID operation.
ADV2-32	N	PID Ref Source	0_Keypad 1_AV11 Analog 2_ACI Analog 3_AV12 Analog 4_RS485	Select source of PID setpoint.
ADV2-52	Y	LD Set Point	SET-19 to (variable)	Adjustable setting for Low Demand pressure set-point from 0 to [Set-20 F/B Max]x 0.95. It can be adjusted to lower or higher than HD (Main) pressure set-point value to provide desired pressure and prevent over-pressure trip at pump start in Low Demand situation.
ADV2-53	Y	LD Max Freq	SET-23 to SET-22	PID High Frequency Limit setting for Low Demand. Adjust to lower frequency setting to prevent overpressure trips during run but enough to maintain pressure at LD Set-point.

## Parameter Descriptions > Motor Menu

AR = Adjustable while running.

CODE	AR	Display Name	Range	Description
Motor-00	N	Motor A-Tuning	0_None 1_IM Rotating 2_IM No-Rotation 3_PM Rotating 4_PM No-Rotation	Performs a motor test to measure the motor characteristics. Select motor type Induction Motor (IM) or Permanent Magnet (PM) motor and if the motor is allowed to rotate during autotune operation.
Motor-01	N	Motor Rs Value	0.0 to 65.535 Ohm	Induction Motor rotor resistance
Motor-02	N	Motor Rr Value	0.0 to 65.535 Ohm	Induction Motor stator resistance
Motor-03	N	Motor Lm Value	0.0 to 6553.5 mH	Induction Motor rotor inductance
Motor-04	N	Motor Lx Value	0.0 to 6553.5 mH	Induction Motor stator inductance
Motor-05	N	Control Method	0_VF 1_Sensorless	Determines the control method of the motor as either a volts to frequency relationship (Induction Motor) or Sensorless Vector Control (SVC) (Permanent Magnet).
Motor-06	N	Motor Type	0_Induction Motor 1_PM-SPM 2_PM-IPM	Identifies the type of motor being used. PM-SPM: Surface Permanent Magnet Motor PM-IPM: Internal Permanent Magnet Motor
Motor-07	N	PM Poles	0 to 65535	Identifies the number of poles in Permanent Magnet Motor.
Motor-08	N	PM Inertia	0.0 to 6553.5 Kg*m <sup>2</sup>	Identifies the inertia in Permanent Magnet Motor. This value is automatically calculated.
Motor-09	N	PM Rs	0.0 to 65.535 Ohm	Permanent Magnet Motor stator resistance.
Motor-10	N	PM Ld	0.0 to 655.35 mH	Permanent Magnet Motor inductance d-axis.
Motor-11	N	PM Lq	0.0 to 655.35 mH	Permanent Magnet Motor inductance q-axis.
Motor-12	Y	PM PG Angle	0 to 360 degree	Permanent Magnet Motor offset angle.
Motor-13	Y	PM Ke Coeff	0 to 65535	Coefficient for optimal PM motor control
Motor-14	Y	Rotor Zeroing	0_Disabled 1_1/4 FLA Current 2_Hi Freq Inject 3_Pulse Inject	Permanent Magnet Motor rotor initial angle position detection method. Recommendation: "2" for IPM; "3" for SPM. If there is a bad effect, then set as "1".
Motor-15	Y	Torque Filter T	0.001 to 10 Sec	Response time in controlling torque to motor.
Motor-16	Y	Slip Filter T	0.001 to 10 Sec	Response time in controlling slip compensation.
Motor-17	Y	Torque Cmp Gain	0 to 10*	Gain value for output voltage increase to compensate for voltage drop on stator resistance at high motor loads in torque compensation function. * For PM motors max value is 5000.
Motor-18	Y	Slip Cmp Gain	0 to 10	Gain value for output frequency increase to provide slip compensation at high motor loads
Motor-19	Y	Slip Dev Level	0 to 100%	Slip percentage level to cause over slip trip. Setting of 0 is No Detection.
Motor-20	Y	Slip Dev Det T	0 to 10 Sec	Duration slip percentage has to be at before causing over slip trip.
Motor-21	Y	Over Slip Trip	0_Alarm and Run 1_Alarm and Decel 2_Alarm and Coast 3_Disabled	Operation when over slip trip occurs.
Motor-22	Y	Motor Hunt Gain	0 to 10000	Gain value in detecting shaft speed of a synchronous motor. A sudden load change can cause shaft speed to fluctuate.
Motor-23	Y	Auto restart	0 to 6000 sec	If the number of internal faults defined by [Prot-41] occurs within this duration, then an auto restart of the VFD will occur.
Motor-24	Y	I/F Current	0 to 150%	VFD to regulates output current to this value which is based on percentage of nominal motor current.
Motor-25	Y	PM Bandwidth HS	0 to 600 Hz	Allowable frequency bandwidth around desired frequency in order to adjust operating frequency to prevent vibrations in motor operation.
Motor-26	Y	PMSVC Fltr Gain	0 to 655.35 Sec	Gain value in adjusting the operating frequency from the desired frequency to prevent vibrations in motor operation.
Motor-27	Y	Freq I/F to PM	0 to 599 Hz	When increasing frequency, the frequency to switch modes from I/F mode to PMSVC mode.



**PARAMETER REFERENCE TABLES**  
**Parameter Descriptions > Motor Menu**

CODE	AR	Display Name	Range	Description
Motor-28	Y	Freq PM to I/F	0 to 599 Hz	When decreasing frequency, the frequency to switch modes from PMSVC mode to I/F mode.
Motor-29	Y	I/F fltr time	0 to 6 Sec	Low-pass filter time of current being commanded from I/F Current [Motor-24].
Motor-30	Y	Angle Det Pulse	0 to 3	Value is a multiplier of nominal motor current which is magnitude of pulse during the angle detection. This is only used when Rotor Zeroing [Motor-14] is set to 2 or 3.
Motor-31	Y	Zero voltage T	0 to 60 Sec	Duration the output is 0V to establish a static startup. Once the system is at a static startup. The VFD can accurately estimate angles. This parameter is applicable when SS Normal Start [Prot-42] is not set to 0.
Motor-32	Y	Injection Freq	0 to 1200 Hz	Frequency used to determine angle of motor during High Frequency Injection. Injection Frequency should be at least 100Hz larger than motor's nominal frequency. Carrier frequency should be 10 times larger than Injection Frequency.
Motor-33	Y	Injection V	0 to 200 V	Voltage used to determine angle of motor during High Frequency Injection.
Motor-34	N	Run Time Min	0 to 1439 min	Minutes of the motor run time. Less than 60 seconds is not recorded.
Motor-35	N	Run Time Days	0 to 65535 day	Days of the motor run time.



# SPECIFICATIONS

## Common Specifications

Cooling Method		On/Off control: CX-061A-2V and below, CX-038A-4V and below PWM Control: CX-075A-2V and above, CX-045A-4V and above, All CX-xxA-6V models	
Short Circuit Rating		The drive is suitable for use on a circuit capable of delivering not more than 100,000 symmetrical amperes (rms) when protected by suitable Class J fuses. Refer to <a href="#">“Branch Circuit Protection” on page 30.</a>	
Agency Approvals		UL and cUL listed, CE, TUV, KC, EAC marked (except 575/690V models), GB/T12668-2	
CONTROL	Control Method	V/F, Slip Compensation, Torque compensation, Sensorless Vector with auto-tune (no disconnecting from the load), Permanent Magnet (except 575/690V models)	
	Frequency Setting Resolution	Digital Reference: 0.01 Hz Analog Reference: 0.03x Max Output Hz / 60 Hz (±11 bit)	
	Frequency Accuracy	Digital: ± 0.01 % of Max. Output Frequency, -10°C-+40°C Analog: ± 0.1 % of Max. Output Frequency, 25±10°C	
	V/F Control Curve	Linear, Squared, S-Pattern, User Defined Pattern	
	Overload Capacity	120% variable torque for 1 min 120% constant torque for 1 min, 160% for 3 seconds	
	Torque Boost	Manual FWD & REV Torque Boost adjustment (0 - 15 %) and Auto Torque Boost	
	Current Limit	Variable Torque: 130% torque current, Constant Torque: 160% torque current	
	Starting Torque	Up to 150% above 0.5Hz	
OPERATION	Operation Method	Keypad / Terminals / Communication	
	Frequency Setting	Analog: 0 - 10VDC, ±10VDC, and 4 - 20mA Digital: Keypad or Communication	
	Input Signals	Start Signal	Forward, Reverse and Jog
		Multi-Step	Up to 18 Speeds can be set including Jog and Reverse direction (Use binary coded combinations of Programmable Digital Inputs)
		Multi Step Accel/Decel Time	0.1- 6,000 sec, Max 4 rates can be set via Multi- Function Terminals. Accel/Decel Pattern: Linear, U-Curve or S-Curve
		Emergency Stop	Immediately Interrupts the VFD Output in any control method
		Jog	Jog Operation with adjustable Jog frequency
	Output Signals	Fault Reset	Resets VFD via digital input, or communication. Some critical faults must be reset by recycling power.
		Three Multi-Function Relays	One SPDT and two SPST type relays with contacts rated 1.2A at 250VAC and 3A at 30VDC. Each relay can be programmed for different functions including Fault and Run status.
		Two Analog Outputs	Programmable and scalable analog outputs with 0-10VDC or 4-20mA selections by DIP switches.
	Hardware Disable	VFDs have redundant hardware safety inputs STO and SCM for external N.C. contact.	
Operation Functions	DC Braking, Frequency Limit, Jump Frequencies, Set Rotation Direction, Auto Restart, Auto-Tuning, PID Control, Flying Start, Flux Braking, Pre-PID, Sleep mode, MMC, Motor Pre-heat, Speed limiting by VFD temperature, etc.		
PROTECTION	VFD Fault Trips	Over Voltage, Low Voltage, Over Current, Overload Protection, Short Circuit Protection, Ground Fault, VFD Overheat, Motor Overheat, Output Phase Open, External Trip, CPU Communication Error, Loss of Speed Command, Hardware Fault, etc	
	VFD Alarm	Stall Prevention, Overload Alarm, Thermal Sensor Fault	
DISPLAY	Keypad	Operation Information	Output Frequency, Output Current, Output Voltage, Frequency Reference, DC Voltage, kWattmeter, Run-time, Last Trip Info, etc.
		Fault History	The VFD stores 6 last faults with Hz, A, VFD mode and trip time for each fault.
ENVIRONMENT	Ambient Temperature	UL Type 1: 14°F- 104? (-10?- 40?); De-rate VFD by 20% to increase rating to 122? (50?) or De-rate VFD by 40% to increase rating to 140? (60?). UL Open Type: 14°F- 122? (-10?- 50?); De-rate VFD by 20% to increase rating to 140? (60?)	
	Storage Temperature	-13°F- 158? (-25? - 70?)	
	Ambient Humidity	Up to 95 % RH. (Non-Condensing)	
	Altitude	Max. 3,300ft (1,000m). De-rate VFD by 1% or 0.5? for every additional 330 feet (100m) up to 6,561 feet (2000m). De-rating by 20% is adequate for altitude up to 10,000 feet.	
	Vibration	1.0mm, peak to peak value range from 2Hz to 13.2 Hz; 0.7G-1.0G range from 13.2Hz to 55Hz; 1.0G range from 55Hz to 512 Hz. Complies with IEC 60068-2-6.	
Environmental Conditions	Pollution degree 2. No Corrosive Gas, Combustible Gas, Oil Mist or Dust. IEC60364-1/IEC60664-1		

## SPECIFICATIONS

### 200~230V Class 1-125HP (0.75~90kW)

## 200~230V Class 1~125HP (0.75~90kW)

Model (CX-xxx-2V) UL Type 1 <sup>(1)</sup>		005A	007A	010A	015A	021A	031A	046A	061A	075A	090A	105A	146A	180A	215A	276A	322A
Frame Size		<b>A</b>					<b>B</b>			<b>C</b>			<b>D</b>		<b>E</b>		
Variable Torque (Light Duty) Motor Rating <sup>(2)</sup>	FLA[A]	5	7.5	10	15	21	31	46	61	75	90	105	146	180	215	276	322
	HP <sup>(2)</sup>	1	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100	120
	kW	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90
	Capacity [kVA]	2	3	4	6	8.4	12	18	24	30	36	42	58	72	86	110	128
Constant Torque (Normal Duty) Motor Rating <sup>(2)</sup>	FLA[A]	3	5	8	11	17	25	33	49	65	75	90	120	146	180	216	255
	HP <sup>(2)</sup>	0.5	1	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100
	kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	19	22	30	37	45	55	75
	Capacity [kVA]	1.2	2	3.2	4.4	6.8	10	13	20	26	30	36	48	58	72	86	20
Output Ratings	Max Carrier Freq	2-15kHz												2-9kHz			
	Voltage <sup>(3)</sup>	3 $\phi$ 200 - 240 VAC <sup>(3)</sup>															
	Frequency	0.01 - 599 Hz												0.01 - 400 Hz			
Input Ratings	Voltage <sup>(4)</sup>	3 $\phi$ 200 (-15%) - 240 VAC (+10 %)															
	Frequency	50/60 Hz ( $\pm$ 5 %)															
Efficiency		96 %					96.5 %					97 %					
Weight kg (lbs.)		2.6 $\pm$ 0.3 (5.8 $\pm$ 0.7)					5.4 $\pm$ 1 (11.9 $\pm$ 2.2)			9.8 $\pm$ 1.5 (21.6 $\pm$ 3.3)			38.5 $\pm$ 1.5 (84.9 $\pm$ 3.3)		64.8 $\pm$ 1.5 (142.9 $\pm$ 3.3)		
DC Choke		None											Built-in 3%				

<sup>1</sup> UL Open Type VFD with installed UL Type 1 kit.

<sup>2</sup> Variable torque (Light Duty) motor rating based on a 120% overload for 1 minute. Constant Torque (Normal Duty) motor rating based on 120% overload for 1 minute and 160% overload for 3 seconds. The motor horsepower ratings are based on VFD nominal voltage and standard 4-pole induction motor design. Operation at lower input voltages or motors with six or more poles may require derating the drive depending on actual motor FLA rating.

<sup>3</sup> The VFD cannot produce output voltage greater than input voltage.

<sup>4</sup> The input voltage setting determines Low Voltage Trip level and input to output voltage ratio.

## 380~480V Class 1~75HP (5.5~55kW)

Model (CX-xxx-4V) UL Type 1 <sup>(1)</sup>		003A	004A	005A	008A	010A	013A	018A	024A	032A	038A	045A	060A	073A	091A	110A
Frame Size		<b>A</b>						<b>B</b>				<b>C</b>			<b>D0</b>	
Variable Torque (Light Duty) Motor Rating <sup>(2)</sup>	FLA[A]	3	4.2	5.5	8.5	10.5	13	18	24	32	38	45	60	73	91	110
	HP <sup>(2)</sup>	1	2	3	5	5	7.5	10	15	20	25	30	40	50	60	75
	kW	0.75	1.5	2.2	3.7	4	5.5	7.5	11	15	18.5	22	30	37	45	55
	Capacity [kVA]	2.4	3.3	4.4	6.8	8.4	10.4	14.3	19	25	30	36	48	58	73	88
Constant Torque (Normal Duty) Motor Rating <sup>(2)</sup>	FLA[A]	1.7	3	4	6	9	10.5	12	18	24	32	38	45	60	73	91
	HP <sup>(2)</sup>	0.5	1	2	3	5	5	7.5	10	15	20	25	30	40	53	60
	kW	0.4	0.75	1.5	2.2	3.7	4	5.5	7.5	11	15	18.5	22	30	37	45
	Capacity [kVA]	2.2	2.4	3.2	4.8	7.2	8.4	10.4	14.3	19	25	30	36	48	58	73
Output Ratings	Max Carrier Freq	2-15kHz										2-10kHz				
	Voltage <sup>(3)</sup>	3φ 380 - 480 VAC <sup>(3)</sup>														
	Frequency	0.01 - 599 Hz														
Input Ratings	Voltage <sup>(4)</sup>	3φ 380 (-15%) - 480 VAC (+10 %)														
	Frequency	50/60 Hz (± 5 %)														
Efficiency		96 %						96.5 %						97 %		
Weight kg (lbs.)		2.6 ± 0.3 (5.8 ± 0.7)						5.4 ± 1 (11.9 ± 2.2)				9.8 ± 1.5 (21.6 ± 3.3)			27 ± 1 (59.5 ± 2.2)	
DC Choke		None													Built-in 3%	

- <sup>1</sup> UL Open Type VFD with installed UL Type 1 kit.
- <sup>2</sup> Variable torque (Light Duty) motor rating based on a 120% overload for 1 minute. Constant Torque (Normal Duty) motor rating based on 120% overload for 1 minute and 160% overload for 3 seconds. The motor horsepower ratings are based on VFD nominal voltage and standard 4-pole induction motor design. Operation at lower input voltages or motors with six or more poles may require derating the drive depending on actual motor FLA rating.
- <sup>3</sup> The VFD cannot produce output voltage greater than input voltage.
- <sup>4</sup> The input voltage setting determines Low Voltage Trip level and input to output voltage ratio.

## SPECIFICATIONS

### 380~480V Class 100~675HP (75~500kW)

## 380~480V Class 100~675HP (75~500kW)

Model (CX-xxx-4V) UL Type 1 <sup>(1)</sup>		150A	180A	220A	260A	310A	370A	460A	530A	616A	683A	770A	930A
Frame Size		<b>D</b>		<b>E</b>		<b>F</b>		<b>G</b>		<b>H</b>			
Variable Torque (Light Duty) Motor Rating <sup>(2)</sup>	FLA[A]	150	180	220	260	310	370	460	530	616	683	770	930
	HP <sup>(2)</sup>	100	125	150	175	215	250	300	375	425	475	536	675
	kW	75	90	110	132	160	185	220	280	315	355	400	500
	Capacity [kVA]	120	143	175	207	247	295	367	422	491	544	613	773
Constant Torque (Normal Duty) Motor Rating <sup>(2)</sup>	FLA[A]	110	150	180	220	260	310	370	460	550	616	683	866
	HP <sup>(2)</sup>	75	100	125	150	175	215	250	300	375	425	475	600
	kW	55	75	90	110	132	160	185	220	280	315	355	450
	Capacity [kVA]	88	120	143	175	207	247	295	367	438	491	544	720
Output Ratings	Max Carrier Freq	2-10kHz	2-9kHz										
	Voltage <sup>(3)</sup>	3 $\phi$ 380 - 480 VAC <sup>(3)</sup>											
	Frequency	0.01 - 599 Hz											
Input Ratings	Voltage <sup>(4)</sup>	3 $\phi$ 380 (-15%) - 480 VAC (+10 %)											
	Frequency	50/60 Hz ( $\pm$ 5 %)											
Efficiency		97 %						97.5 %					
Weight kg (lbs.)		38.5 $\pm$ 1.5 (84.9 $\pm$ 3.3)		64.8 $\pm$ 1.5 (142.9 $\pm$ 3.3)		86.5 $\pm$ 1.5 (190.7 $\pm$ 3.3)		134 $\pm$ 4 (295.4 $\pm$ 8.9)		38.5 $\pm$ 1.5 (84.9 $\pm$ 3.3)			
DC Choke		Built-in 3%											

<sup>1</sup> UL Open Type VFD with installed UL Type 1 kit.

<sup>2</sup> Variable torque (Light Duty) motor rating based on a 120% overload for 1 minute. Constant Torque (Normal Duty) motor rating based on 120% overload for 1 minute and 160% overload for 3 seconds. The motor horsepower ratings are based on VFD nominal voltage and standard 4-pole induction motor design. Operation at lower input voltages or motors with six or more poles may require derating the drive depending on actual motor FLA rating.

<sup>3</sup> The VFD cannot produce output voltage greater than input voltage.

<sup>4</sup> The input voltage setting determines Low Voltage Trip level and input to output voltage ratio.

## 525~600V Class 1~150HP (1.5~175kW)

Model (CX-xxx-6V) UL Type 1 <sup>(1)</sup>		003A	004A	006A	009A	012A	018A	024A	030A	036A	045A	054A	067A	086A	104A	125A	150A	
Frame Size		A			B				C			D		E				
Variable Torque (Light Duty) Motor Rating <sup>(2)</sup>	FLA[A]	3	4.3	6.7	9.9	12.1	18.7	24.2	30	36	45	54	67	86	104	125	150	
	HP <sup>(2)</sup>	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100	125	150	
	kW	1.5	2.2	3.7	5.5	7.5	11	15	22	30	37	45	55	75	90	110	132	
	Capacity [kVA]	3	4.3	6.7	9.9	12.1	18.6	24.1	36	43	54	65	80	103	124	149	179	
Constant Torque (Normal Duty) Motor Rating <sup>(2)</sup>	FLA[A]	2.5	3.6	5.5	8.2	10	15.4	20	24	30	36	45	54	67	86	104	125	
	HP <sup>(2)</sup>	1	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100	125	
	kW	0.75	1.5	2.2	3.7	5.5	7.5	11	18.5	22	30	37	45	55	75	90	110	
	Capacity [kVA]	2.5	3.6	5.5	8.2	10	15.4	19.9	29	36	43	54	65	80	103	124	149	
Output Ratings	Max Carrier Freq	2-15kHz							2-9kHz									
	Voltage <sup>(3)</sup>	3 $\phi$ 525 - 600 VAC <sup>(2)</sup>																
	Frequency	0.01 - 599 Hz																
Input Ratings	Voltage <sup>(4)</sup>	3 $\phi$ 525 (-15%) - 600 VAC (+10 %)																
	Frequency	50/60 Hz ( $\pm$ 5 %)																
Efficiency		97 %			98 %				97 %									
Weight kg (lbs.)		3 $\pm$ 0.3 (6.6 $\pm$ 0.7)			4.8 $\pm$ 1 (10.6 $\pm$ 2.2)				10 $\pm$ 1.5 (22 $\pm$ 3.3)			39 $\pm$ 1.5 (86 $\pm$ 3.3)		61 $\pm$ 1.5 (134.5 $\pm$ 3.3)				
DC Choke		None										Built-in 3%						

<sup>1</sup> UL Open Type VFD with installed UL Type 1 kit.

<sup>2</sup> Variable torque (Light Duty) motor rating based on a 120% overload for 1 minute. Constant Torque (Normal Duty) motor rating based on 120% overload for 1 minute and 160% overload for 3 seconds. The motor horsepower ratings are based on VFD nominal voltage and standard 4-pole induction motor design. Operation at lower input voltages or motors with six or more poles may require derating the drive depending on actual motor FLA rating.

<sup>3</sup> The VFD cannot produce output voltage greater than input voltage.

<sup>4</sup> The input voltage setting determines Low Voltage Trip level and input to output voltage ratio.

## SPECIFICATIONS

### 525-690V Class 150-675HP (160-630kW)

## 525-690V Class 150-675HP (160-630kW)

Model (CX-xxx-6V) UL Type 1 <sup>(1)</sup>		180A	220A	290A	350A	430A	465A	590A	675A
Frame Size		<b>F</b>		<b>G</b>		<b>H</b>			
Variable Torque (Light Duty) Motor Rating <sup>(2)</sup>	FLA [A]	180	220	290	350	430	465	590	675
	HP <sup>(2)</sup>	150	200	250	350	400	450	500	675
	kW	160	200	250	315	400	450	560	630
	Capacity [kVA]	215	263	347	418	494.5	534.7	678.5	776
Constant Torque (Normal Duty) Motor Rating <sup>(2)</sup>	FLA [A]	150	180	220	290	350	385	465	675
	HP <sup>(2)</sup>	150	150	200	250	350	400	450	500
	kW	132	160	200	250	315	355	450	630
	Capacity [kVA]	179	215	239	347	402.5	442.7	534.7	776
Output Ratings	Max Carrier Freq	2-9kHz							
	Voltage <sup>(3)</sup>	3 $\phi$ 525 - 690 VAC <sup>(2)</sup>							
	Frequency	0.01 - 599 Hz							
Input Ratings	Voltage <sup>(4)</sup>	3 $\phi$ 525 (-15%) - 690 VAC (+10 %)							
	Frequency	50/60 Hz ( $\pm$ 5 %)							
Efficiency		97 %			98 %				
Weight kg (lbs.)		88 $\pm$ 1.5 (194 $\pm$ 3.3)		135 $\pm$ 4 (297.6 $\pm$ 8.8)		243 $\pm$ 5 (535.7 $\pm$ 11)			
DC Choke		Built-in 3%							

<sup>1</sup> UL Open Type VFD with installed UL Type 1 kit.

<sup>2</sup> Variable torque (Light Duty) motor rating based on a 120% overload for 1 minute. Constant Torque (Normal Duty) motor rating based on 120% overload for 1 minute and 160% overload for 3 seconds. The motor horsepower ratings are based on VFD nominal voltage and standard 4-pole induction motor design. Operation at lower input voltages or motors with six or more poles may require derating the drive depending on actual motor FLA rating.

<sup>3</sup> The VFD cannot produce output voltage greater than input voltage.


<sup>4</sup> The input voltage setting determines Low Voltage Trip level and input to output voltage ratio.




## De-Rating Tables

### Carrier Frequency De-Rating


#### 230 V Carrier Frequency De-Rating



#### 460 V Carrier Frequency De-Rating



#### 600 V Carrier Frequency De-Rating




## SPECIFICATIONS

### Applicable Standards

---

### Ambient Temperature De-Rating



### Applicable Standards

1. UL508C – UL/cUL
2. CE
  - a. Low Voltage
    - EN61800-5-1
  - b. EMC
    - EN61000-3-12
    - IEC61000-6-2
    - IEC61000-4-2
    - IEC61000-4-4
    - IEC61000-4-6
    - EN61800-3
    - IEC61000-6-4
    - IEC61000-4-3
    - IEC61000-4-5
    - IEC61000-4-8
3. C-Tick
4. ROHS

# GLOSSARY

Acronym/ Term	Definition	Description
AWG	American Wire Gauge	A standardized measurement of wire diameters important for determining current-carrying capacity.
BAS	Building Automation System	A computer-based control system that controls and monitors a building's mechanical and electrical equipment.
BMS	Building Management System	A computer-based control system that controls and monitors a building's mechanical and electrical equipment.
BPC	Bypass Controller	
EMI	Electromagnetic Interference	See RFI.
FLA	Full Load Amperes	The nameplate amperage rating of the motor when it is running at its designed horsepower and on the motors designed voltage.
GFCI	Ground Fault Circuit Interrupter	A fast-acting circuit breaker designed to shut off electric power in the event of a ground-fault within as little as 1/40 of a second.
GPM	Gallons per Minute	A unit of volumetric flow rate in the United States.
HMI	Human Machine Interface	An interface that permits interaction between a human and a machine, such as a display and keyboard.
HOA	Hand/Off/Auto switching	
IGBT	Insulated Gate Bipolar Transistor	A three-terminal power semiconductor device used as an electronic switch to synthesize complex waveforms with pulse-width modulation in a variable-frequency drive (VFD).
IP	International Protection rating	Used as protection measures for motors, electrical devices and motors.
LDT	Load Detection Trip	
MCCB	Molded Case Circuit Breaker	An MCCB provides protection by combining a temperature sensitive device with a current sensitive electromagnetic device.
MMS	Manual Motor Starter	An electromechanical protection device used to switch motors ON/OFF manually and to provide fuseless protection against short-circuit, overload and phase failures.
MOL	Motor Overload	
NEC	National Electrical Code	A regionally adoptable standard for the safe installation of electrical wiring and equipment in the United States.
NEMA	National Electrical Manufacturer Association	The largest trade association of electrical equipment manufacturers in the United States. NEMA publishes more than 700 standards for electrical enclosures, motors and magnet wire, AC plugs and receptacles, etc.
PFC	Power Factor Correction	
PID	Proportional Integral Derivative	A control loop feedback mechanism used in applications requiring continuously modulated control.
PLC	Programmable Logic Controller	A digital computer used for automation of typically industrial electromechanical processes.
PMA	Pump and Motor Assembly	
PSC	Permanent Split Capacitor	
PWM	Pulse Width Modulation	A modulation technique used to control the power supplied to electrical devices, especially for motor speed control.
RFI	Radio Frequency Interference	A disturbance generated by an external source that affects an electrical circuit by electromagnetic induction, electrostatic coupling, or conduction.

## GLOSSARY

Acronym/ Term	Definition	Description
RMS	Root Mean Square	Refers to the most common mathematical method of defining the effective voltage or current of an AC wave.
RTU	Remote Terminal Unit	A Modbus RS-485 connection following a simple client-server model.
SFA	Service Factor Amperes	The amount of a periodic overload at which a motor can operate without overload or damage.
TDH	Total Dynamic Head	The total equivalent height that a fluid is to be pumped, taking into account friction losses in the pipe.
VAC	Voltage Alternating Current	
VDC	Voltage Direct Current	
VFD	Variable Frequency Drive	A type of adjustable-speed drive used in electro-mechanical drive systems to control AC motor speed and torque by varying motor input frequency and voltage.

---

**NOTES**

---

**NOTES**

---

## STANDARD LIMITED WARRANTY

Except as set forth in an Extended Warranty, for one (1) year from the date of installation, but in no event more than two (2) years from the date of manufacture, Franklin hereby warrants to the purchaser (“Purchaser”) of Franklin’s products that, for the applicable warranty period, the products purchased will (i) be free from defects in workmanship and material at the time of shipment, (ii) perform consistently with samples previously supplied and (iii) conform to the specifications published or agreed to in writing between the purchaser and Franklin. This limited warranty extends only to products purchased directly from Franklin. If a product is purchased other than from a distributor or directly from Franklin, such product must be installed by a Franklin Certified Installer for this limited warranty to apply. This limited warranty is not assignable or transferable to any subsequent purchaser or user.

- a. THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, WRITTEN OR ORAL, STATUTORY, EXPRESS, OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. PURCHASER’S SOLE AND EXCLUSIVE REMEDY FOR FRANKLIN’S BREACH OF ITS OBLIGATIONS HEREUNDER, INCLUDING BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OR OTHERWISE, UNLESS PROVIDED ON THE FACE HEREOF OR IN A WRITTEN INSTRUMENT MADE PART OF THIS LIMITED WARRANTY, SHALL BE FOR THE PURCHASE PRICE PAID TO FRANKLIN FOR THE NONCONFORMING OR DEFECTIVE PRODUCT OR FOR THE REPAIR OR REPLACEMENT OF NONCONFORMING OR DEFECTIVE PRODUCT, AT FRANKLIN’S ELECTION. ANY FRANKLIN PRODUCT WHICH FRANKLIN DETERMINES TO BE DEFECTIVE WITHIN THE WARRANTY PERIOD SHALL BE, AT FRANKLIN’S SOLE OPTION, REPAIRED, REPLACED, OR A REFUND OF THE PURCHASE PRICE PAID. Some states do not allow limitations on how long an implied warranty lasts, therefore, the limitations and exclusions relating to the products may not apply.
- b. WITHOUT LIMITING THE GENERALITY OF THE EXCLUSIONS OF THIS LIMITED WARRANTY, FRANKLIN SHALL NOT BE LIABLE TO THE PURCHASER OR ANY THIRD PARTY FOR ANY AND ALL (i) INCIDENTAL EXPENSES OR OTHER CHARGES, COSTS, EXPENSES (INCLUDING COSTS OF INSPECTION, TESTING, STORAGE, OR TRANSPORTATION) OR (ii) DAMAGES, INCLUDING CONSEQUENTIAL, SPECIAL DAMAGES, PUNITIVE OR INDIRECT DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS, LOST TIME AND LOST BUSINESS OPPORTUNITIES, REGARDLESS OF WHETHER FRANKLIN IS OR IS SHOWN TO BE AT FAULT, AND REGARDLESS OF WHETHER THERE IS OR THERE IS SHOWN TO HAVE BEEN A DEFECT IN MATERIALS OR WORKMANSHIP, NEGLIGENCE IN MANUFACTURE OR DESIGN, OR A FAILURE TO WARN.
- c. Franklin’s liability arising out of the sale or delivery of its products, or their use, whether based upon warranty contract, negligence, or otherwise, shall not in any case exceed the cost of repair or replacement of the product and, upon expiration of any applicable warranty period, any and all such liability shall terminate.
- d. Without limiting the generality of the exclusions of this limited warranty, Franklin does not warrant the adequacy of any specifications provided directly or indirectly by a purchaser or that Franklin’s products will perform in accordance with such specifications. This limited warranty does not apply to any products that have been subject to misuse (including use in a manner inconsistent with the design of the product), abuse, neglect, accident or improper installation or maintenance, or to products that have been altered or repaired by any person or entity other than Franklin or its authorized representatives.
- e. Unless otherwise specified in an Extended Warranty authorized by Franklin for a specific product or product line, this limited warranty does not apply to performance caused by abrasive materials, corrosion due to aggressive conditions or improper voltage supply.



For technical assistance, parts, or repair, please contact:

**800.348.2420 | [franklin-electric.com](http://franklin-electric.com)**

Form 10000005064 Rev. 000 09/20

