

Installation instructions

Instructions de montage


Instruzioni di montaggio

Montageanweisung


Instrucciones de montaje


Montagevoorschrift

Monteringsanvisning



```
http://192.168.1.254
User: admin
Password: loytec4u
```





⚠ PROTECTIVE EARTH MUST BE CONNECTED!

Connectors

POWER1 85-264 VAC	1	Power supply AC input
	2	Power supply AC input
POWER2 24 VDC	3	Power supply DC input earth ground
	4	Power supply DC input MINUS
	5	Power supply DC input PLUS ⚠ do not connect PLUS to GND
BACnet MS/TP	6	Input GND
	7	Input +
	8	Input -
EIA-485	9	Input GND
	10	Input +
	11	Input -

TRS connector
Stereo 3.5 mm





Extension cable
Nr. 61006001

Modular
connector
6p6c (RJ12)

black GND
green TEMP
red +3 V
white DIGIN1
blue GND
yellow DIGIN0

Weidmüller BLZP 5.08/03/180



Status LEDs


MS/TP	GREEN flashing	Traffic on BACnet MS/TP port
CNIP	GREEN flashing	Traffic on BACnet IP port
LINK	GREEN	Ethernet link
ACT	GREEN flashing	Ethernet traffic
ONLINE	GREEN	Node is online
PWR	GREEN	Power
STAT	OFF	Normal operation

Buttons

RESET	Reset
STATUS	Send "I AM" message

MAC address

Serial number of the device



Document 88076901
2010-01
Printed in Austria
Data is subject to change



<http://www.loytec.com>
support@loytec.com