# Switching Power Supplies PS5R-V Series





# STANDARDS COMPLIANCE


Applicable Standards	Mark	File No. or Organization
UL508 UL1310 <sup>1</sup> ANSI/ISA 12.12.01 CSA C22.2 No.107.1 CSA C22.2 No.213 CSA C22.2 No.223 <sup>1</sup>	cULus	UL/c-UL Listed File No. E467154, E177168
EN60950-1 EN50178		TÜV SÜD <sup>2</sup>
EN61204-3 EN50581	CE	EU Low Voltage Directive, EMC Directive RoHS Directive
SEMI F47	—	EPRI
Note 1: PS58-VA /VB/VC /VD/VE	only	

Note 1: PS5R-VA/VB/VC/VD/VE only Note 2: EN60950-1, EN50178 only

# PART NUMBERS

Output Capacity	Part Number	Input Voltage	Output Voltage	Output Current
	PS5R-VA05		5V	1.5A
7.5W	PS5R-VA12		12V	0.6A
	PS5R-VA24		24V	0.3A
10W	PS5R-VB05		5V	2.0A
15W	PS5R-VB12	100 to 240V AC (Voltage range: 85 to 264V AC / 100 to 370V DC)	12V	1.3A
1500	PS5R-VB24 (\ PS5R-VC12 A		24V	0.65A
30W			12V	2.5A
3000	PS5R-VC24		24V	1.3A
60W	PS5R-VD24		24V	2.5A
90W	PS5R-VE24		24V	3.75A
120W	PS5R-VF24		24V	5.0A
240W	PS5R-VG24		24V	10.0A

#### Part Number Structure



# **PRODUCT DESCRIPTION**

DIN-rail mount switching power supplies with global approvals for both industrial and hazardous locations

# **KEY FEATURES**

- Compact size preserves panel space
- Slim size (width):
  22.5mm (10W/15W/30W)
  36mm (60W/90W)
  46mm (120W)
  60mm (240W)
- Universal Voltage Input: 85-264V AC/100-370V DC
- Wide operating temperature range
- Spring-up terminals accept ring & fork terminals
- Approved for use in Class I Division 2 hazardous locations
- Can be installed in 6 directions
- 10W ~ 90W meet NEC Class 2 output ratings
- Overcurrent protection with auto-reset
- Meets SEMI F47 Sag Immunity (208V AC input)
- RoHS compliant
- Five-year factory warranty



# **SPECIFICATIONS**


		5V DC output	PS5R-VA05	PS5R-VB05	-	-	-	•	-
	Model	12V DC output 24V DC output	PS5R-VA12 PS5R-VA24	PS5R-VB12 PS5R-VB24	PS5R-VC12 PS5R-VC24	- PS5R-VD24	- PS5R-VE24	- PS5R-VF24	- PS5R-VG24
)utput	t Capacity	211 Do output	7.5W	15W (5V Model is 10W)	30W	60W	90W	120W	240W
Ra	ated Input Voltage Single-phase two-wire	j <sup>1</sup>		100 to 240V AC (Voltage range: 85 to 264V AC/100 to 370V DC) (Load $\leq$ 80% at 100-105V DC)					
Fr	requency				50/6	60 Hz			
	· O · (T )	100V AC	5V: 0.20A 12V, 24V: 0.18A	5V: 0.25A 12V, 24V: 0.35A	0.7A	1.3A	1.1A	1.4A	2.7A
	iput Current (Typ.)	230V AC	5V: 0.12A 12V, 24V: 0.10A	5V: 0.14A 12V, 24V: 0.19A	0.3A	0.8A	0.6A	0.7A	1.2A
	rush Current (Typ.)	100V AC	15A			18A			14A
(18	(Ta=25°C, cold start)      230V AC        Leakage Current      120V AC        230V AC      230V AC		36A		45A 0.5m	A max.		41A	30A
Le						A max.			
	fficiency (Typ.) it rated output) <sup>2</sup>	100V AC	5V: 74%, 12V: 79%, 24V: 80%	5V: 77%, 12V: 82%, 24V: 84%	12V: 83%, 24V: 85%	86%		88% 89%	89%
		230V AC 100V AC	5V: 73%, 12V: 77%, 24V: 76%	5V: 73%, 12V: 80%, 24V: 81%	12V: 85%, 24V: 87%	86%		0.99	90%
Po	ower Factor (Typ.)	230V AC	—	—	—	—	0.86	0.92	0.96
	ated Voltage/Curre		5V/1.5A, 12V/0.6A, 24V/0.3A	5V/2.0A <sup>3</sup> , 12V/1.3A, 24V/0.65A	12V/2.5A, 24V/1.3A	24V/2.5A	24V/3.75A	24V/5A	24V/10A
A	djustable Voltage F		45	±10%	401/ 40 041/ 45	40	±5%	±10%	
	utput Holding Time yp.) (at rated output)	100V AC	45ms	5V: 53ms, 12V: 34ms, 24V: 36ms 5V: 330ms 12V: 215ms	12V: 13ms, 24V: 15ms	13ms	20ms	30ms	
(1)	yp.) (at rateu output)	230V AC	285ms	24V: 230ms	12V: 110ms 24V: 110ms	105ms	30ms	33ms	40ms
St	tart Time (at rated inpu	it and output)	500ms max. 5V, 12V: 200ms max	500ms max.	600ms max.	800n	ns max.	700ms max.	800ms max.
Ri	ise Time (at rated input		24V: 250ms max	5V, 12V: 200ms max. 24V: 250ms max.			200ms max.		
;	Input Fluctuatio		51/- 2.5% may	12V, 24V: 1.0% max.	0.4%	6 max.	1.0% max.		
5	Temperature Cl		0.04%/°C max. (-10 to +65°C )	0.05%/°C max. (-10 to +65°C )	12V: 0.05%/°C max. (-10 to +50°C) 24V: 0.05%/°C max. (-10 to +55°C)	0.05%/°C max. (-10 to +55°C )	0.05%/°C max. (-10 to +50°C )	0.05%/°C max. (-25 to +55°C )	0.05%/°C max. (-25 to +50°C)
.b 11			5V: 8% p-p max. (-25 to -10°C) 12V: 6% p-p max. (-25 to -10°C) 24V: 4% p-p max. (-25 to -10°C)	5V: 8% p-p max. (-25 to -10°C) 12V: 6% p-p max. (-25 to -10°C) 24V: 4% p-p max. (-25 to -10°C)	12V: 6% p-p max. (-25 to -10°C) 24V: 4% p-p max. (-25 to -10°C) 4% p-p max. (-25 to -10°C)				
Ripple (including noise)		5V: 5% p-p max. (-10 to +0°C) 12V: 2.5% p-p max. (-10 to +0°C) 24V: 1.5% p-p max. (-10 to +0°C)	5V: 5% p-p max. (-10 to +0°C) 12V: 2.5% p-p max. (-10 to +0°C) 24V: 1.5% p-p max. (-10 to +0°C)	12V: 2.5% p-p max. (-10 to +0°C) 24V: 1.5% p-p max. (-10 to +0°C)		1.5% p	-p max. (-10 to +0°C)		
			5V: 2.5% p-p max. (0 to +65°C) 12V: 1.5% p-p max. (0 to +65°C) 24V: 1% p-p max. (0 to +65°C)	5V: 2.5% p-p max. (0 to +65°C) 12V: 1.5% p-p max. (0 to +65°C) 24V: 1% p-p max. (0 to +65°C)	12V: 1.5% p-p max. (0 to +50°C) 24V: 1% p-p max. (0 to +55°C)	1% p-p max. (0 to +55°C)	1% p-p max. (0 to +50°C)	1% p-p max. (0 to +55°C)	1% p-p max. (0 t +50°C)
vercurre	ent Protection			105% min. (auto	reset)		101% min. (auto reset)	105% min. (au	to reset)
peratio	on Indicator				LED (	(green)			
Ве	etween input and output	terminals		3,000V AC, 1 minute					
Be	etween input and ground	terminals			2,000V A	C, 1 minute			
Be Be Be	etween output and grour	d terminals			500V AC	, 1 minute			
	on Resistance			Between input and output terminal			round terminals: 100M	IO min (500V/DC meager)	
	ng Temperature <sup>4</sup> (No 1	ireezing)	-25	to +75°C	-25 to +70°C			-25 to +65°C	
	ng Humidity (no conde	0.	20			, 90% RH		23 10 103 0	
	e Temperature (No free				-25 to	0 +75°C			
orage	e Humidity (no condens	sation)			20 to 9	90% RH			
ibratio	on Resistance		10 to 55Hz, amplitude 0.375mm, 2 hours each in 3 axes (when used with BNL6 end clips) (when used with BNL6 end clips) (when used with BNL6 end clips) 10 to 55Hz, amplitude 0.375mm, 2 hours each in 3 axes (when used with BNL6 end clips) 10 to 55Hz, amplitude 0.375mm, 2 hours each in 3 axes (when used with BNL6 end clips) 10 to 55Hz, amplitude 0.375mm, 2 hours each in 3 axes (when used with BNL6 end clips) 10 to 55Hz, amplitude 0.375mm, 2 hours each in 3 axes (when used with BNL6 end clips) 10 to 55Hz, amplitude 0.375mm, 2 hours each in 3 axes (when used with BNL6 end clips) 10 to 55Hz, amplitude 0.375mm, 2 hours each in 3 axes (when used with BNL6 end clips) 10 to 55Hz, amplitude 0.375mm, 2 hours each in 3 axes (when used with BNL6 end clips)				10 to 55 Hz, amplitude 0.375mm, 2 hours eac in 3 axes (when used with part n BNL6 mounting clips)		
hock R	Resistance				300 m/s <sup>2</sup> (30G), 3 tim	nes each in 6 directions	3	brice che chpsy	
kpecte	ed Life <sup>5</sup>			8 years minimum (	at the rated input, 50% load, opera			lirection)	
	EMI				EN61204	-3 (Class B)			
MC	EMS				EN61204-3	3 (industrial)			
afety S	Standards				10 Class 2, ANSI/ISA-12.12.01 , 213, 223 EN60950-1, EN50178			UL508 (Listing) ANS CSA C22.2 No. 107.1, 213	I/ISA-12.12.01 EN60950-1, EN501
ther S	tandard				SEMI F47 (at 20	18V AC input only)			
egree	of Protection		IP20 (EN60529)						
imensi	ions (mm)		75H × 45W × 70D	90H × 22.5	W × 95D	95H × 36	SW × 108D	115H × 46W × 121D	125H × 60W × 125
Veight	(approx.)		130g	140g	150g	260g	310g	470g	960g
							0		


At normal temperature and humidity unless otherwise specified. Note 1: DC input voltage is not subject to safety standards. When using on DC input, connect a fuse to the input terminal for DC input protection. Note 2: Under stable state. Note 3: PSSR-VBD5 (SV DC/2 0A) is 10W (Up to 3.0A at Ta = 0 to 40°C. Not subject to safety standards above 2.0A.) Note 4: See the output derating curves. Note 5: Calculation of the expected life is based on the actual life of the aluminum electrolytic capacitor. The expected life depends on operating conditions.

# **CHARACTERISTICS**

# **Operating Temperature vs. Output Current (Derating Curves)**

Conditions: Natural air cooling (Operating temperature is the temperature around the switching power supply.)





Intermittent Operation


105 and over

100

Output Current (%)

Output Voltage (%)

0



, Mounting A


Mounting A

# **Operating Temperature Approved by Safety Standards**


Part Number	UL508, CSA C22.2 No.107.1, ANSI/ISA12.12.01, EN60950-1, EN50178					
r urt rumber	Mounting A	Mounting B	Mounting C	Mounting D	Mounting E	Mounting F
PS5R-VA05, -VA12, -VA24	65	60	60	60	65	60
PS5R-VB05, -VB12, -VB24	65	60	60	60	60	60
PS5R-VC12	50	45	45	45	45	45
PS5R-VC24	55	55	50	45	45	45
PS5R-VD24	55	40	40	40	45	35
PS5R-VE24	50	40	40	40	45	40
PS5R-VF24	55	40	45	40	45	35
PS5R-VG24	50	35	30	30	45	30

#### **MOUNTING STYLE**










Up Λ

(Downward)

**Front Panel PS5R-VA** 


PS5R-VB/VC



# С ĕ

<sup>+V</sup> O

PS5R-VD/VE/VF PS5R-VG



Marking	Name	Description
L, N	AC Input Terminal	Voltage range: 85 to 264V AC/100 to 370V DC
	Ground Terminal	Be sure to connect this terminal to a proper ground.
+V, -V	DC Output Terminals	+V: Positive output terminal -V: Negative output terminal
VR.ADJ	Output Voltage Adjustment	Allows adjustment within $\pm 10\%$ . (VE = $\pm 5\%$ ) Turning clockwise increases the output voltage. Turning counterclockwise decreases the output voltage.
DC ON	Operation Indicator (green)	Illuminates when the output voltage is on.

#### ACCESSORIES Panel Mounting Bracket<sup>2</sup>

Applicable Switching Power Supply	Part Number	Remarks
PS5R-VB	PS9Z-5R1B	—
PS5R-VC	PS9Z-5R2B	For side mounting
PS5R-VD PS5R-VE	PS9Z-5R1C	—
PS5R-VF	PS9Z-5R1E	_
PS5R-VG	PS9Z-6R1F	—
r 30n-Vd	PS9Z-6R2F	For side mounting


⊡ O

Note 2: Used when installing on a panel directly, PS5R-VA model does not require panel mounting bracket.

# DIN Rail (35mm-wide)


Length	Part Number	Material
1000mm	BNDN1000	Aluminum


# **End Clip**




#### **DIMENSIONS (MM)**

**PS5R-VA** 







**PS5R-VD/VE** 




PS5R-VB/VC




**PS5R-VF** 



#### PS5R-VG






**MTBF\*** 

PS5R-VA:	1,150,000H minimum	
PS5R-VB:	900,000H minimum	
PS5R-VC:	650,000H minimum	
PS5R-VD:	450,000H minimum	MIL-HDBK-217FN2 (GB, 30°C)
PS5R-VE:	380,000H minimum	(00, 50 6)
PS5R-VF:	350,000H minimum	
PS5R-VG:	290,000H minimum	

\*MTBF stands for Mean Time Between Failure, which is calculated according to statistical device failures, and indicates reliability of a device. It is the statistical representation of the likelihood of the unit to fail and does not necessarily represent the expected life of a product.

**Panel Mounting Bracket** 



# **SAFETY PRECAUTIONS**


The PS5R-V should be placed in a proper enclosure. It is designed to be used with general electrical equipment and industrial electric devices

- Do not use switching power supplies with electric equipment whose malfunction or inadvertent operation may damage the human body or life directly.
- Make sure that the input voltage and output current do not exceed the ratings. If the input voltage and output current exceed the ratings, electric shock, fire, or malfunction may occur.
- Do not touch the terminals of the switching power supply while input voltage is applied, otherwise electric shock may occur.
- Provide the final product with protection against malfunction or damage that may be caused by malfunction of the switching power supply.
- Operating temperatures should not exceed the ratings. Be sure to note the derating characteristics. If the operating temperature exceeds the ratings, electric shock, fire, or malfunction may occur.
- Blown fuses indicate that the internal circuits are damaged. Contact IDEC for repair. Do not just replace the fuse and reoperate, otherwise electric shock, fire, or malfunction may occur
- Do not use the switching power supplies to charge rechargeable batteries.
- Do not overload or short-circuit the switching power supply for a long period of time, otherwise the internal elements may be damaged.
- Do not disassemble, repair, or modify the power supplies, otherwise the high voltage internal part may cause electric shock, fire, or malfunction.
- The fuse inside the PS5R-V switching power supply is for AC input. Use an external fuse for DC input.

# **OPERATING INSTRUCTIONS**

#### Notes for installation

- Do not close the top or bottom openings of the PS5R-V to allow for heat radiation by convection.
- When mounting multiple PS5R-V switching power supplies side by side, maintain a minimum of 10 mm clearance. Observe the derating curves in consideration of the ambient temperature.




- When the derating voltage may exceed the recommended value, provide forced air-cooling.
- Make sure to wire the ground terminal correctly.
- For wiring, use wires of heat resistance of 60°C or higher (PS5R-VB: 80°C or higher). Use copper wire of the following sizes, according to the rated current.

Terminal	Wire Size (allowable current)	Wire Type
Input	AWG 18 to 14	
Output	AWG18 to 14 (AWG18: 7A, AWG16: 10A, AWG14: 15A)	Copper Solid/Stranded

Cross-Sectional are AWG18: 0.82mm<sup>2</sup>, AWG16: 1.31mm<sup>2</sup>, AWG14: 2.0mm<sup>2</sup>

#### Applicable crimp terminal (reference)



· Recommended tightening torque of the input and output terminals is 1.0 to 1.3Nm (0.8N·m for UL).

# **Mounting on DIN Rails**

1. Use a 35mm-wide DIN rail.

2.Place the PS5R-V on the DIN rail as shown with input terminal side up (①), and press the PS5R-V towards the DIN rail (2). Make sure that the PS5R-V is installed firmly.

3. Use BNL6 end clips to ensure power supplies do not slide off the end of the DIN rail. Use of BNL8 end clips is recommended when excessive vibration or shock is anticipated.


#### Removal


Insert a flat screwdriver into the slot in the clamp, and pull out until it clicks (①). The lock mechanism is released and the PS5R-V can be removed (2). When mounting the PS5R-V again, push in the latch first. Mounting Removal



# Installing a Panel Mounting Bracket

Panel Mounting Bracket (PS9Z-5R1D, PS9Z-6R1F)





② Install the tab on the panel mounting bracket into the slot on the power supply.


③ Install the brackets as shown on the left.



LOCK

④ Ensure that the panel mounting bracket is locked by the latch.

#### Panel Mounting Bracket (PS9Z-5R2B)



госк

 Pull out the latch to UNLOCK position.

LOCK r st




② Insert the tab on the panel mounting bracket into the slot on the power supply.

③ Push in the latch to LOCK position.

④ Ensure that the panel mounting bracket is locked by the latch.

# Installing PS9Z-6R2F Side-mount Panel Mounting Bracket

Install the bracket on the switching power supply using four M3  $\times$  6 countersunk screws supplied with the bracket. Recommended tightening torque is 0.5 to 0.6N.m (should be in the center positions)



#### Adjustment of Output Voltage

The output voltage can be adjusted within  $\pm 10\%$  (VE:  $\pm 5\%$ ) of the rated output voltage by using the VR.ADJ control on the front. Turning the VR.ADJ clockwise increases the output voltage. Turning the VR.ADJ counterclockwise decreases the output voltage.

#### **Overcurrent Protection**

The output voltage drops automatically when an overcurrent flows due to an overload or short circuit. Normal voltage is automatically restored when the load returns to normal conditions.

#### Insulation/Dielectric Test

When performing an insulation/dielectric test, short-circuit the input (between L and N) and output (between +V and -V). Do not apply or interrupt the voltage quickly, otherwise surge voltages may be generated and the PSSR-V may be damaged.

#### **Notes for Operation**

- Output interruption may indicate blown fuses. Contact IDEC.
- The PS5R-V switching power supply contains an internal fuse for AC input. When using DC input, install an external fuse. To avoid blown fuses, select a fuse in consideration of the rated current of the internal fuse.

#### **Rated Current of Internal Fuses**

Part Number	Internal FuseRated Current
PS5R-VB/VC	2A
PS5R-VD/VE/VF	4A
PS5R-VG	6.3A

 Avoid overload and short-circuit for a long period of time, otherwise the internal elements may be damaged.

#### WARRANTY

IDEC warranties the PS5R-V switching power supply for a period of five years from the date of shipment.

#### Scope

IDEC agrees to repair or replace the PS5R-V switching power supply if the product has been operated under the following conditions. The maximum value of output capacity is within the range shown in "Operating Temperature vs.

Output Current on page 3.

- 1. Average operating temperature (ambient temperature of switching power supply) is 40  $^\circ\mathrm{C}$  maximum.
- 2. The load is 80% maximum.
- 3. Input voltage is the rated input voltage.
- 4. Standard mounting style

• DC input operation is not subject to safety standards.

#### **Rust and Scratches on Metal parts**


Bonded metal parts are used for the PS5R-V. Rust on the edge and scratches on the surfaces may be developed depending on the storage condition, but the performance of the PS5R-V is not affected.

#### Noise

Small acoustic noise inside the PS5R-V may be heard depending on the input voltage and load, but the performance of the PS5R-V is not affected.

#### **Series Operation**

Series operation is allowed. Connect Schottky barrier diodes D as shown below. Select a Schottky diode in consideration of the rated current. The diode's reverse voltage must be higher than the PS5R-V's output voltage.




#### Parallel Operation

Parallel operation is not possible to increase the output capacity, because the internal elements and load may be damaged.

#### **Backup Operation**

Backup operation is a connection method of two switching power supplies in parallel for emergency. Normally one switching power supply has a sufficient output. If one switching power supply fails, another one operates to continue the output. Make sure that the sum of power consumption by load and diode is not greater than the rated wattage (rated voltage × rated current) of one switching power supply.



Select a diode in consideration of:

Diode's current must be more than double the PS5R-V's output current. Take heat dissipation into consideration.

IDEC shall not be liable for other damages including consequential, contingent or incidental damages. Warranty does not apply if the PS5R-V switching power supply was subject to:

- 1. Inappropriate handling, or operation beyond specifications.
- 2. Modification or repair by other than IDEC.
- 3. Failure caused by other than the PS5R-V switching power supply.
- 4. Failure caused by natural disasters.



©2016 IDEC Corporation. All Rights Reserved. PS9Y-DS500-2 12/16 5K