

# ROOM HUMIDITY TRANSDUCER RH100B Series

The RH100B series uses a highly accurate and reliable Thermoset Polymer based capacitance humidity sensor and state-of-the-art digital linearization and temperature compensated circuitry in an attractive, low profile enclosure to monitor room humidity levels.

An optional temperature sensor is available.

#### **SPECIFICATION:**

	Thermoset Polymer based capacitive
Accuracy at 25°C:	±2, 3, or 5% RH, (5% to 95% RH)
Measurement Range: Temperature Dependence: Hysteresis:	0 to 100% RH ±0.05% RH/ ℃
Repeatability:	±0.5% RH typical
Linearity: Sensor Response Time: Stability:	15 seconds typical
Operating Temperature: Operating Humidity:	0° to 50°C (32° to 122°F) 0 to 95% RH
Power Supply:	non-condensing 18 to 35 Vdc, 15 to 26 Vac
Consumption: Input Voltage Effect:	22 mA maximum Negligible over specified
Protection Circuitry:	operating range Reverse voltage protected and output limited
Output Signal:	
Output Drive at 24 Vdc:	(jumper-selectable)
Internal Adjustments:	output Clearly marked ZERO and SPAN pots
Wiring Connections:	
Optional Temp. Sensor:	Various RTDs and thermistors available as two-wire resistance
Enclosure: Dimensions:	

#### PART NUMBER SELECTED

#### **PRODUCT SELECTION INFORMATION:**

MODEL	Product Description		
RH100B	Room Designer Humidity Transducer		
	CODE	CODE Accuracy	
	02 2%   03 3%   05 5%		
		CODE	Optional Temperature Sensor
		L C F	100Ω Platinum, IEC 751, 385 Alpha, thin film 1000Ω Platinum, IEC 751, 385 Alpha, thin film 1801Ω, NTC Thermistor, ±0.2°C
		E D J	3,000Ω, NTC Thermistor, ±0.2°C 10,000Ω, type 3, NTC Thermistor, ±0.2°C 10,000Ω, type 2, NTC Thermistor, ±0.2°C
		K M B G	20,000Ω, NTC Thermistor, ±0.2°C 1000 Ω Nickel, Class B, DIN 43760 10k Ω Type 3, NTC Therm, ±0.2 C c/w 11K shunt Resistor 2.252KΩ Thermistor, ±0.2 C
<u> </u>	Ļ		
RH100B	03	D	

Greystone Energy Systems, Inc. reserves the right to make design modifications without prior notice.

### **TYPICAL INSTALLATION:**


## For complete installation and wiring details, please refer to the product installation instructions.

The SS plate type sensor installs directly on a standard electrical box and should be mounted five feet from the floor of the area to be controlled. Do not mount the sensor near doors, opening windows, supply air diffusers or other known air disturbances. Avoid areas where the sensor is exposed to vibrations or rapid temperature changes.

A terminal is provided for connection to the Building Automation System.

Greystone Energy Systems, Inc. (506) 85 150 English Drive, Moncton, NB North A Canada E1E 4G7 e-mail: www.greystoneenergy.com

(506) 853-3057 Fax: (506) 853-6014 North America: 1-800-561-5611 e-mail: mail@greystoneenergy.com rgy.com



COMPLIANT

V.06/13